

Programmable Controller

MELSEC iQ-R
series

MELSEC iQ-R AnyWireASLINK Master Module User's Manual (Startup)

-RJ51AW12AL

Powered by

Anywire

This product was jointly developed and manufactured by Mitsubishi and Anywire Corporation.

*Note that the warranty on this product differs from that on other programmable controller products.
(Refer to "WARRANTY" in this manual.)

AnyWireASLINK

COPYRIGHT

This document is protected by the law of copyright, whereby all rights established therein remain with the company Mitsubishi Electric Corporation. Reproduction of this document or parts of this document is only permissible within the limits of the legal determination of Copyright Law. Alteration or abridgement of the document is not permitted without the explicit written approval of the company Mitsubishi Electric Corporation.

PRECAUTIONS REGARDING WARRANTY AND SPECIFICATIONS

The RJ51AW12AL was jointly developed and manufactured by Mitsubishi and Anywire Corporation. Note that there are differences in warranty.

- Warranty

Item	RJ51AW12AL	Other programmable controller products (e.g. MELSEC iQ-R series)
Gratis warranty term	12 months after delivery or 18 months after manufacturing	36 months after delivery or 42 months after manufacturing
Repair term after discontinuation of production	1 year	7 years



SAFETY PRECAUTIONS

(Read these precautions before using this product.)

Before using this product, please read this manual and the relevant manuals carefully and pay full attention to safety to handle the product correctly.

The precautions given in this manual are concerned with this product only. For the safety precautions of the programmable controller system, refer to the MELSEC iQ-R Module Configuration Manual.

In this manual, the safety precautions are classified into two levels: "⚠ WARNING" and "⚠ CAUTION".

 WARNING	Indicates that incorrect handling may cause hazardous conditions, resulting in death or severe injury.
 CAUTION	Indicates that incorrect handling may cause hazardous conditions, resulting in minor or moderate injury or property damage.

Under some circumstances, failure to observe the precautions given under "⚠ CAUTION" may lead to serious consequences.

Observe the precautions of both levels because they are important for personal and system safety.

Make sure that the end users read this manual and then keep the manual in a safe place for future reference.

WARNING

- Configure safety circuits external to the programmable controller to ensure that the entire system operates safely even when a fault occurs in the external power supply or the programmable controller. Failure to do so may result in an accident due to an incorrect output or malfunction.
 - (1) Emergency stop circuits, protection circuits, and protective interlock circuits for conflicting operations (such as forward/reverse rotations or upper/lower limit positioning) must be configured external to the programmable controller.
 - (2) When the programmable controller detects an abnormal condition, it stops the operation and all outputs are:
 - Turned off if the overcurrent or overvoltage protection of the power supply module is activated.
 - Held or turned off according to the parameter setting if the self-diagnostic function of the CPU module detects an error such as a watchdog timer error.
 - (3) All outputs may be turned on if an error occurs in a part, such as an I/O control part, where the CPU module cannot detect any error. To ensure safety operation in such a case, provide a safety mechanism or a fail-safe circuit external to the programmable controller. For a fail-safe circuit example, refer to "General Safety Requirements" in the MELSEC iQ-R Module Configuration Manual.
 - (4) Outputs may remain on or off due to a failure of a component such as a relay and transistor in an output circuit. Configure an external circuit for monitoring output signals that could cause a serious accident.
 - In an output circuit, when a load current exceeding the rated current or an overcurrent caused by a load short-circuit flows for a long time, it may cause smoke and fire. To prevent this, configure an external safety circuit, such as a fuse.
 - For the operating status of each station after a communication failure, refer to manuals for the network used. For the manuals, please consult your local Mitsubishi representative. Incorrect output or malfunction due to a communication failure may result in an accident.
 - When connecting an external device with a CPU module or intelligent function module to modify data of a running programmable controller, configure an interlock circuit in the program to ensure that the entire system will always operate safely. For other forms of control (such as program modification, parameter change, forced output, or operating status change) of a running programmable controller, read the relevant manuals carefully and ensure that the operation is safe before proceeding. Improper operation may damage machines or cause accidents.
-

[Design Precautions]

WARNING

- Especially, when a remote programmable controller is controlled by an external device, immediate action cannot be taken if a problem occurs in the programmable controller due to a communication failure. To prevent this, configure an interlock circuit in the program, and determine corrective actions to be taken between the external device and CPU module in case of a communication failure.
 - Do not write any data to the "system area" and "write-protect area" of the buffer memory in the module. Also, do not use any "use prohibited" signals as an output signal from the CPU module to each module. Doing so may cause malfunction of the programmable controller system. For the "system area", "write-protect area", and the "use prohibited" signals, refer to the user's manual for the module used. For areas used for safety communications, they are protected from being written by users, and thus safety communications failure caused by data writing does not occur.
 - If a communication cable is disconnected, the network may be unstable, resulting in a communication failure of multiple stations. Configure an interlock circuit in the program to ensure that the entire system will always operate safely even if communications fail. Failure to do so may result in an accident due to an incorrect output or malfunction. When safety communications are used, an interlock by the safety station interlock function protects the system from an incorrect output or malfunction.
 - An AnyWireASLINK system has no control function for ensuring safety.
-

[Design Precautions]

CAUTION

- Do not install the control lines or communication cables together with the main circuit lines or power cables. Doing so may result in malfunction due to electromagnetic interference. Keep a distance of 100mm or more between them.
 - During control of an inductive load such as a lamp, heater, or solenoid valve, a large current (approximately ten times greater than normal) may flow when the output is turned from off to on. Therefore, use a module that has a sufficient current rating.
 - After the CPU module is powered on or is reset, the time taken to enter the RUN status varies depending on the system configuration, parameter settings, and/or program size. Design circuits so that the entire system will always operate safely, regardless of the time.
 - Do not power off the programmable controller or reset the CPU module while the settings are being written.
Doing so will make the data in the flash ROM and SD memory card undefined. The values need to be set in the buffer memory and written to the flash ROM and SD memory card again. Doing so also may cause malfunction or failure of the module.
 - When changing the operating status of the CPU module from external devices (such as the remote RUN/STOP functions), select "Do Not OPEN in Program" for "Open Method Setting" of "Module Parameter". If "OPEN in Program" is selected, an execution of the remote STOP function causes the communication line to close. Consequently, the CPU module cannot reopen the line, and external devices cannot execute the remote RUN function.
-

[Security Precautions]

WARNING

- To maintain the security (confidentiality, integrity, and availability) of the programmable controller and the system against unauthorized access, denial-of-service (DoS) attacks, computer viruses, and other cyberattacks from external devices via the network, take appropriate measures such as firewalls, virtual private networks (VPNs), and antivirus solutions.
-

[Installation Precautions]

WARNING

- Shut off the external power supply (all phases) used in the system before mounting or removing the module. Failure to do so may result in electric shock or cause the module to fail or malfunction.
-

[Installation Precautions]

CAUTION

- Use the programmable controller in an environment that meets the general specifications in the Safety Guidelines (IB-0800525). Failure to do so may result in electric shock, fire, malfunction, or damage to or deterioration of the product.
 - To mount a module, place the concave part(s) located at the bottom onto the guide(s) of the base unit, and push in the module until the hook(s) located at the top snaps into place. Incorrect interconnection may cause malfunction, failure, or drop of the module.
 - To mount a module with no module fixing hook, place the concave part(s) located at the bottom onto the guide(s) of the base unit, push in the module, and fix it with screw(s). Incorrect interconnection may cause malfunction, failure, or drop of the module.
 - When using the programmable controller in an environment of frequent vibrations, fix the module with a screw.
 - Tighten the screws within the specified torque range. Undertightening can cause drop of the component or wire, short circuit, or malfunction. Overtightening can damage the screw and/or module, resulting in drop, short circuit, or malfunction. For the specified torque range, refer to Page 29 Tightening torque in this manual.
 - When using an extension cable, connect it to the extension cable connector of the base unit securely. Check the connection for looseness. Poor contact may cause malfunction.
 - When using an SD memory card, fully insert it into the SD memory card slot. Check that it is inserted completely. Poor contact may cause malfunction.
 - Securely insert an extended SRAM cassette or a battery-less option cassette into the cassette connector of the CPU module. After insertion, close the cassette cover and check that the cassette is inserted completely. Poor contact may cause malfunction.
 - Do not directly touch any conductive parts and electronic components of the module, SD memory card, extended SRAM cassette, battery-less option cassette, or connector. Doing so can cause malfunction or failure of the module.
-

[Wiring Precautions]

WARNING

- Shut off the external power supply (all phases) used in the system before installation and wiring. Failure to do so may result in electric shock or cause the module to fail or malfunction.
- After installation and wiring, attach a blank cover module (RG60) to each empty slot before powering on the system for operation. Also, attach an extension connector protective cover^{*1} to each unused extension cable connector as necessary. Directly touching any conductive parts of the connectors while power is on may result in electric shock.

^{*1} For details, please consult your local Mitsubishi Electric representative.

[Wiring Precautions]

CAUTION

- Individually ground the FG and LG terminals of the programmable controller with a ground resistance of 100 ohms or less. Failure to do so may result in electric shock or malfunction.
 - Use applicable solderless terminals and tighten them within the specified torque range. If any spade solderless terminal is used, it may be disconnected when the terminal screw comes loose, resulting in failure.
 - Check the rated voltage and signal layout before wiring to the module, and connect the cables correctly. Connecting a power supply with a different voltage rating or incorrect wiring may cause fire or failure.
 - Connectors for external devices must be crimped or pressed with the tool specified by the manufacturer, or must be correctly soldered. Incomplete connections may cause short circuit, fire, or malfunction.
 - Securely connect the connector to the module. Poor contact may cause malfunction.
 - Do not install the control lines or communication cables together with the main circuit lines or power cables. Doing so may result in malfunction due to noise. Keep a distance of 100mm or more between those cables.
 - Place the cables in a duct or clamp them. If not, dangling cable may swing or inadvertently be pulled, resulting in damage to the module or cables or malfunction due to poor contact. Do not clamp the extension cables with the jacket stripped. Doing so may change the characteristics of the cables, resulting in malfunction.
 - Check the interface type and correctly connect the cable. Incorrect wiring (connecting the cable to an incorrect interface) may cause failure of the module and external device.
 - Tighten the terminal screws or connector screws within the specified torque range. Undertightening can cause drop of the screw, short circuit, fire, or malfunction. Overtightening can damage the screw and/or module, resulting in drop, short circuit, fire, or malfunction.
For the specified torque range, refer to Page 29 Tightening torque in this manual.
 - When disconnecting the cable from the module, do not pull the cable by the cable part. For the cable with connector, hold the connector part of the cable. For the cable connected to the terminal block, loosen the terminal screw. Pulling the cable connected to the module may result in malfunction or damage to the module or cable.
-

[Wiring Precautions]

CAUTION

- Prevent foreign matter such as dust or wire chips from entering the module. Such foreign matter can cause a fire, failure, or malfunction.
 - When a protective film is attached to the top of the module, remove it before system operation. If not, inadequate heat dissipation of the module may cause a fire, failure, or malfunction.
 - Programmable controllers must be installed in control panels. Connect the main power supply to the power supply module in the control panel through a relay terminal block. Wiring and replacement of a power supply module must be performed by qualified maintenance personnel with knowledge of protection against electric shock. For wiring, refer to the MELSEC iQ-R Module Configuration Manual.
 - For Ethernet cables to be used in the system, select the ones that meet the specifications in the user's manual for the module used. If not, normal data transmission is not guaranteed.
 - Do not apply the 24VDC power before wiring the entire AnyWireASLINK system. If the power is applied before wiring, normal data transmission is not guaranteed.
 - Connect a 24VDC external power supply to the device(s) in an AnyWireASLINK system.
-

[Startup and Maintenance Precautions]

WARNING

- Do not touch any terminal while power is on. Doing so will cause electric shock or malfunction.
 - Correctly connect the battery connector. Do not charge, disassemble, heat, short-circuit, solder, or throw the battery into the fire. Also, do not expose it to liquid or strong shock. Doing so will cause the battery to produce heat, explode, ignite, or leak, resulting in injury and fire.
 - Shut off the external power supply (all phases) used in the system before cleaning the module or retightening the terminal screws, connector screws, or module fixing screws. Failure to do so may result in electric shock.
-

[Startup and Maintenance Precautions]

CAUTION

- When connecting an external device with a CPU module or intelligent function module to modify data of a running programmable controller, configure an interlock circuit in the program to ensure that the entire system will always operate safely. For other forms of control (such as program modification, parameter change, forced output, or operating status change) of a running programmable controller, read the relevant manuals carefully and ensure that the operation is safe before proceeding. Improper operation may damage machines or cause accidents.
 - Especially, when a remote programmable controller is controlled by an external device, immediate action cannot be taken if a problem occurs in the programmable controller due to a communication failure. To prevent this, configure an interlock circuit in the program, and determine corrective actions to be taken between the external device and CPU module in case of a communication failure.
 - Do not disassemble or modify the modules. Doing so may cause failure, malfunction, injury, or a fire.
 - Use any radio communication device such as a cellular phone or PHS (Personal Handy-phone System) 25cm or more away in all directions from the programmable controller. Failure to do so may cause malfunction.
 - Shut off the external power supply (all phases) used in the system before mounting or removing the module. Failure to do so may cause the module to fail or malfunction.
 - Tighten the screws within the specified torque range. Undertightening can cause drop of the component or wire, short circuit, or malfunction. Overtightening can damage the screw and/or module, resulting in drop, short circuit, or malfunction.
 - After the first use of the product, do not perform each of the following operations more than 50 times (IEC 61131-2/JIS B 3502 compliant).
Exceeding the limit may cause malfunction.
 - Mounting/removing the module to/from the base unit
 - Inserting/removing the extended SRAM cassette or battery-less option cassette to/from the CPU module
 - Mounting/removing the terminal block to/from the module
 - After the first use of the product, do not insert/remove the SD memory card to/from the CPU module more than 500 times. Exceeding the limit may cause malfunction.
 - Do not touch the metal terminals on the back side of the SD memory card. Doing so may cause malfunction or failure of the module.
 - Do not touch the integrated circuits on the circuit board of an extended SRAM cassette or a battery-less option cassette. Doing so may cause malfunction or failure of the module.
 - Do not drop or apply shock to the battery to be installed in the module. Doing so may damage the battery, causing the battery fluid to leak inside the battery. If the battery is dropped or any shock is applied to it, dispose of it without using.
 - Startup and maintenance of a control panel must be performed by qualified maintenance personnel with knowledge of protection against electric shock. Lock the control panel so that only qualified maintenance personnel can operate it.
 - Before handling the module, touch a conducting object such as a grounded metal to discharge the static electricity from the human body. Failure to do so may cause the module to fail or malfunction.
-

[Operating Precautions]

CAUTION

- When changing data and operating status, and modifying program of the running programmable controller from an external device such as a personal computer connected to an intelligent function module, read relevant manuals carefully and ensure the safety before operation. Incorrect change or modification may cause system malfunction, damage to the machines, or accidents.
 - Do not power off the programmable controller or reset the CPU module while the setting values in the buffer memory are being written to the flash ROM in the module. Doing so will make the data in the flash ROM and SD memory card undefined. The values need to be set in the buffer memory and written to the flash ROM and SD memory card again. Doing so can cause malfunction or failure of the module.
-

[Disposal Precautions]

CAUTION

- When disposing of this product, treat it as industrial waste.
 - When disposing of batteries, separate them from other wastes according to the local regulations. For details on battery regulations in EU member states, refer to the MELSEC iQ-R Module Configuration Manual.
-

[Transportation Precautions]

CAUTION

- When transporting lithium batteries, follow the transportation regulations. For details on the regulated models, refer to the MELSEC iQ-R Module Configuration Manual.
 - The halogens (such as fluorine, chlorine, bromine, and iodine), which are contained in a fumigant used for disinfection and pest control of wood packaging materials, may cause failure of the product. Prevent the entry of fumigant residues into the product or consider other methods (such as heat treatment) instead of fumigation. The disinfection and pest control measures must be applied to unprocessed raw wood.
-

CONDITIONS OF USE FOR THE PRODUCT

- (1) MELSEC programmable controller ("the PRODUCT") shall be used in conditions;
- i) where any problem, fault or failure occurring in the PRODUCT, if any, shall not lead to any major or serious accident; and
 - ii) where the backup and fail-safe function are systematically or automatically provided outside of the PRODUCT for the case of any problem, fault or failure occurring in the PRODUCT.
- (2) The PRODUCT has been designed and manufactured for the purpose of being used in general industries. MITSUBISHI ELECTRIC SHALL HAVE NO RESPONSIBILITY OR LIABILITY (INCLUDING, BUT NOT LIMITED TO ANY AND ALL RESPONSIBILITY OR LIABILITY BASED ON CONTRACT, WARRANTY, TORT, PRODUCT LIABILITY) FOR ANY INJURY OR DEATH TO PERSONS OR LOSS OR DAMAGE TO PROPERTY CAUSED BY the PRODUCT THAT ARE OPERATED OR USED IN APPLICATION NOT INTENDED OR EXCLUDED BY INSTRUCTIONS, PRECAUTIONS, OR WARNING CONTAINED IN MITSUBISHI ELECTRIC USER'S, INSTRUCTION AND/OR SAFETY MANUALS, TECHNICAL BULLETINS AND GUIDELINES FOR the PRODUCT.
- ("Prohibited Application")
- Prohibited Applications include, but not limited to, the use of the PRODUCT in;
- Nuclear Power Plants and any other power plants operated by Power companies, and/or any other cases in which the public could be affected if any problem or fault occurs in the PRODUCT.
 - Railway companies or Public service purposes, and/or any other cases in which establishment of a special quality assurance system is required by the Purchaser or End User.
 - Aircraft or Aerospace, Medical applications, Train equipment, transport equipment such as Elevator and Escalator, Incineration and Fuel devices, Vehicles, Manned transportation, Equipment for Recreation and Amusement, and Safety devices, handling of Nuclear or Hazardous Materials or Chemicals, Mining and Drilling, and/or other applications where there is a significant risk of injury to the public or property.
- Notwithstanding the above restrictions, Mitsubishi Electric may in its sole discretion, authorize use of the PRODUCT in one or more of the Prohibited Applications, provided that the usage of the PRODUCT is limited only for the specific applications agreed to by Mitsubishi Electric and provided further that no special quality assurance or fail-safe, redundant or other safety features which exceed the general specifications of the PRODUCTS are required. For details, please contact the Mitsubishi Electric representative in your region.
- (3) Mitsubishi Electric shall have no responsibility or liability for any problems involving programmable controller trouble and system trouble caused by DoS attacks, unauthorized access, computer viruses, and other cyberattacks.

INTRODUCTION

Thank you for purchasing the Mitsubishi Electric MELSEC iQ-R series programmable controllers.

This manual describes the procedures, system configuration, and wiring of the relevant product listed below.

Before using this product, please read this manual and the relevant manuals carefully and develop familiarity with the functions and performance of the MELSEC iQ-R series programmable controller to handle the product correctly.

When applying the program examples provided in this manual to an actual system, ensure the applicability and confirm that it will not cause system control problems.

Please make sure that the end users read this manual.

This module was jointly developed by Mitsubishi and Anywire Corporation. The module allows the AnyWireASLINK® system to be connected to a MELSEC iQ-R series programmable controller system.

Relevant product

RJ51AW12AL

COMPLIANCE WITH EMC AND LOW VOLTAGE DIRECTIVES

Method of ensuring compliance

To ensure that Mitsubishi Electric programmable controllers maintain the EMC and Low Voltage Directives or other regulations when incorporated into other machinery or equipment, certain measures may be necessary. Please refer to one of the following manuals.

- MELSEC iQ-R Module Configuration Manual (SH-081262ENG)
- Safety Guidelines (IB-0800525)

Certification marks on the side of the programmable controller indicate compliance with the relevant regulations.

Additional measures

To ensure that this product maintains EMC and Low Voltage Directives, please refer to one of the following manuals.

- MELSEC iQ-R Module Configuration Manual (SH-081262ENG)
- Safety Guidelines (IB-0800525)

MEMO

CONTENTS

COPYRIGHT	1
PRECAUTIONS REGARDING WARRANTY AND SPECIFICATIONS	1
SAFETY PRECAUTIONS	2
CONDITIONS OF USE FOR THE PRODUCT	10
INTRODUCTION	10
COMPLIANCE WITH EMC AND LOW VOLTAGE DIRECTIVES	11
RELEVANT MANUALS	14
TERMS	15
GENERIC TERMS AND ABBREVIATIONS	15
CHAPTER 1 PART NAMES	16
CHAPTER 2 SPECIFICATIONS	18
2.1 Performance Specifications	18
CHAPTER 3 FUNCTION LIST	20
CHAPTER 4 PROCEDURES BEFORE OPERATION	22
CHAPTER 5 SYSTEM CONFIGURATION	24
5.1 System Configuration of AnyWireASLINK	24
5.2 Power Supply to the AnyWireASLINK System	25
Method of supplying the power to the remote module	25
Scope of the power supply with transmission cables (DP and DN)	25
CHAPTER 6 WIRING	29
6.1 Terminal Block	29
6.2 Wiring Method	30
6.3 Wiring Product	32
6.4 Connecting Remote Module or Terminating Unit	33
CHAPTER 7 COMMUNICATION EXAMPLE	35
7.1 Communication of RJ51AW12AL with Remote Module	35
System configuration example	35
RJ51AW12AL setting	36
Settings of the remote module	38
Checking the system status	38
Program example	39
APPENDIX	41
Appendix 1 External Dimensions	41
INDEX	44
REVISIONS	46
WARRANTY	47
INFORMATION AND SERVICES	48
TRADEMARKS	48

RELEVANT MANUALS


The following manuals are relevant to this product.

Manual name [manual number]	Description
MELSEC iQ-R Module Configuration Manual [SH-081262ENG]	Common information on the hardware configuration of all modules, overview of each system configuration, and specifications of the power supply module, base unit, SD memory card, and battery.
MELSEC iQ-R AnyWireASLINK Master Module User's Manual (Startup) [SH-081584ENG] (this manual)	Specifications, procedures before operation, system configuration, wiring, and communication examples of the AnyWireASLINK master module
MELSEC iQ-R AnyWireASLINK Master Module User's Manual (Application) [SH-081585ENG]	Functions, parameter settings, programming, troubleshooting, I/O signals, and buffer memory of the AnyWireASLINK master module
GX Works3 Operating Manual [SH-081215ENG]	System configuration, parameter settings, and online operations of GX Works3
iQ Sensor Solution Reference Manual [SH-081133ENG]	Online operations of iQ Sensor Solution

This manual does not include detailed information on the following:

- General Specifications
- Applicable combinations of CPU modules and the other modules, and the number of mountable modules
- Installation

For details, refer to the following.

 MELSEC iQ-R Module Configuration Manual

TERMS

Unless otherwise specified, this manual uses the following terms.

Term	Description
Address	Device information set to a remote module to identify each node on the AnyWireASLINK network
Address writer	A hand-held device to read/write parameters and addresses from/to a remote module
AnyWireASLINK	A reduced wiring network where sensors at the end of a control system are connected to a programmable controller. With this system, the RJ51AW12AL can detect sensor disconnection and a user can set the I/O operations of a remote module on the RJ51AW12AL without using I/O areas of the CPU module.
Buffer memory	Memory in an intelligent function module for storing data such as setting values and monitored values. For CPU modules, it refers to memory to store data such as setting values and monitor values of the Ethernet function, or data used for data communication of the multiple CPU system function.
Device	A memory of a CPU module to store data. Devices such as X, Y, M, D, and others are provided depending on the intended use.
Engineering tool	A tool used for setting up programmable controllers, programming, debugging, and maintenance
ID	A parameter to identify whether the module is an input module or output module based on its address
Intelligent function module	A module that has functions other than input and output, such as an A/D converter module and D/A converter module
Module label	A label that represents one of memory areas (I/O signals and buffer memory areas) specific to each module in a given character string. For the module used, GX Works3 automatically generates this label, which can be used as a global label.
Power cable (24V, 0V)	A cable that connects a 24VDC external power supply to the RJ51AW12AL. This cable is also used when the isolation (4-line) type remote module and the RJ51AW12AL are connected.
RAS	An abbreviation for Reliability, Availability, and Serviceability. This term refers to usability of automated equipment.
Terminating unit	A waveform shaper
Transmission cable (DP, DN)	A signal cable that connects a remote module and the RJ51AW12AL
Transmission cycle time	Time for updating I/O data of the RJ51AW12AL and all the remote modules


GENERIC TERMS AND ABBREVIATIONS

Unless otherwise specified, this manual uses the following generic terms and abbreviations.

Generic term/abbreviation	Description
ASLINKAMP	A generic term for sensor amplifiers that have an AnyWireASLINK interface
ASLINKER	A generic term for I/O devices that have an AnyWireASLINK interface
Bit remote module	A generic term for remote modules that communicate bit data only with the RJ51AW12AL. There are following types of bit remote module: <ul style="list-style-type: none">• Bit input remote module• Bit output remote module• Bit I/O combined remote module Some remote modules can be operated as a word remote module depending on the setting.
CPU module	A generic term for the MELSEC iQ-R series CPU modules
Remote module	A generic term for modules that communicate data with the RJ51AW12AL. There are following types of remote module: <ul style="list-style-type: none">• Bit remote module• Word remote module
Word remote module	A generic term for remote modules that communicate word data only with the RJ51AW12AL. There are following types of word remote module: <ul style="list-style-type: none">• Word input remote module• Word output remote module• Word I/O combined remote module Some remote modules can be operated as a bit remote module depending on the setting.

1 PART NAMES

This chapter describes the names of each part of the RJ51AW12AL.



No.	Name	Description
(1)	RUN LED	Indicates the operating status. On: Normal operation Off: Error (MELSEC iQ-R AnyWireASLINK Master Module User's Manual (Application))
	ERR LED	Indicates the error status of the module. On, flashing: Error (MELSEC iQ-R AnyWireASLINK Master Module User's Manual (Application)) Off: Normal operation
	LINK LED ^{*1}	Indicates the link status. On: Communications not executed or during the AnyWireASLINK version compatibility inspection Flashing: Communications in progress Off: Communications not executed
	SET LED ^{*1}	Indicates the address detection status. On: Automatic address detection in progress or the EEPROM error Flashing: Address write in progress Off: Before or after automatic address detection
	ALM LED ^{*1}	Indicates the warning status. On: DP/DN disconnection, no response from the remote module, AnyWireASLINK version compatibility inspection error, or backup/restoring unsupported error Flashing (2-second intervals): DP-DN short circuit, 24V-DP short circuit Flashing (0.4-second intervals): A 24VDC power supply is not being supplied or the voltage is low. Off: Normal operation
(2)	SET switch	Switch for automatic detection of the remote module ID (address)
(3)	Transmission cable terminal block	A terminal block of the AnyWireASLINK (Page 29 Signal name of the terminal block)
(4)	Production information marking	Displays the production information of the module (16 digits).

^{*1} The initialization processing of the RJ51AW12AL is performed when the CPU module is reset or power off and on the system. At this time, the LINK LED, SET LED, and ALM LED turn on for an instant.

2 SPECIFICATIONS

2.1 Performance Specifications

The following table lists the performance specifications of the RJ51AW12AL.

Item	Description
Transmission clock	27.0kHz
Maximum total wiring length	200m ^{*1}
Transmission system	DC transmission line total frame cyclic transmission cyclic system
Connection type	Bus topology (multidrop system, T-branch system, tree branch system, star topology)
Transmission protocol	Dedicated protocol (AnyWireASLINK)
Error control	Checksum, double-verification system
Number of bit data points/number of word data points	<ul style="list-style-type: none"> Number of bit data points: 512 bits maximum (input 256 bits/output 256 bits) Number of word data points: 1024 words maximum (input 512 words/output 512 words)^{*3}
Number of connected remote modules	128 maximum (varies depending on the current consumption of each remote module)
External interface (power supply part/communication part)	Push-in type 7-piece spring clamp terminal block (📖 Page 29 Terminal Block)
Transmission cable (DP, DN)	📖 Page 32 Applicable wires and cables
Power supply cable (24V, 0V)	📖 Page 32 Applicable wires and cables
Applicable bar solderless terminal	<ul style="list-style-type: none"> Processing of a 1.25mm² wire: Al 1,5-10 Processing of a 0.75mm² wire: Al 0,75-10 GY
Transmission cable supply current ^{*2}	<ul style="list-style-type: none"> When using a 1.25mm² cable: 2A maximum When using a 0.75mm² cable: 1.2A maximum
Maximum number of writes to EEPROM	100000 times maximum
Internal current consumption (5VDC)	0.2A
External power supply	Voltage: 21.6 to 27.6VDC (24VDC -10 to +15%), ripple voltage 0.5Vp-p or lower Recommended voltage: 26.4VDC (24VDC +10%) Transmission cable supply current: 2A maximum ^{*2} Module current consumption: 0.1A
Number of occupied I/O points	32 points (I/O assignment: intelligent 32 points)
External dimensions	Height
	Width
	Depth
Weight	0.13kg

- *1 For remote modules with transmission cables (DP, DN), the length of the transmission cables (DP, DN) is included in the total wiring length.
 For wiring of 50m or more with 4 wires (DP, DN, 24V, 0V), insert the noise filter for power supply cables between the power supply and cables. For details, refer to the manual for the AnyWireFILTER (ANF-01) manufactured by Anywire Corporation.
- *2 For the relation of the total wiring length, wire diameter of transmission cables (DP, DN), and transmission cable supply current, refer to the following.
 On some remote modules with cables, the wire diameter of module-integrated transmission cables (DP, DN) may be smaller than 0.75mm². However, they can be used without any problem, provided that the wire diameter of transmission cables (DP, DN) meets the following requirements.

Wire diameter of transmission cables (DP, DN)	Transmission cable supply current		
	Total wiring length of 50m or less	Total wiring length of 50 to 100m	Total wiring length of 100 to 200m
1.25mm ²	2A maximum	1A maximum	0.5A maximum
0.75mm ²	1.2A maximum	0.6A maximum	0.3A maximum

- *3 The performance specification differs depending on the production information of the RJ51AW12AL. (📖 MELSEC iQ-R AnyWireASLINK Master Module User's Manual (Application))

3 FUNCTION LIST

This chapter describes the functions of the RJ51AW12AL. For details on the functions, refer to the following.

📖 MELSEC iQ-R AnyWireASLINK Master Module User's Manual (Application)

AnyWireASLINK transmission

Function	Description
Bit transmission	Exchanges I/O data of maximum 512 bits (input 256 bits, output 256 bits) between the RJ51AW12AL and a remote module.
Word transmission ^{*1}	Exchanges I/O data of maximum 1024 words (input 512 words, output 512 words) between the RJ51AW12AL and a remote module.
Double verification	A double verification is an error control system. In this system, cycle data in AnyWireASLINK transmission is recognized as valid data if the data matches with the data of the last transmission or is ignored as invalid data if the data does not match with the last data. A double verification ensures reliability of communication.
Remote module parameter read/write	In AnyWireASLINK, parameter information of a remote module and the AnyWireASLINK system in addition to I/O information are sent and received between the RJ51AW12AL and a remote module. Execute this function to check or change parameter information of a remote module.

^{*1} The availability of the function differs depending on the production information of the RJ51AW12AL. (📖 MELSEC iQ-R AnyWireASLINK Master Module User's Manual (Application))


Address setting


Function	Description
Automatic address detection function	Enables the RJ51AW12AL to detect and store the ID (address) of the connected remote module when the SET switch on the RJ51AW12AL is pressed.
Remote address change function	Changes an ID (address) of a remote module using the buffer memory area without an address writer.
Same ID used detection function	Checks whether the same ID is used for multiple remote modules through automatic address detection or same address used check. The LEDs of the relevant remote modules are forcibly turned on.
Module with no ID setting detection function	Detects remote modules with no ID assigned (default ID) through automatic address detection or same address used check.

RAS

Function	Description
Transmission cable short detection function	Protects the system by detecting the current out of the specifications of the AnyWireASLINK system across DP-DN or 24V-DP and stopping the transmission.
Disconnected transmission cable location detection function	Notifies the ID of a remote module that has been separated from the RJ51AW12AL because of disconnection in the transmission cables (DP, DN) between the RJ51AW12AL and the remote module, to locate the disconnection in the transmission cables (DP, DN) from the upper system.
Transmission cable voltage drop detection function	Detects a voltage drop in the 24VDC external power supply, enabling the RJ51AW12AL to detect a failure in the 24VDC external power supply or a wiring error from the upper system.

Others

Function	Description
Parameter access error detection function	Allows parameter access errors to be detected.
Error status automatic recovery function	Allows for automatically clearing error flag for DP/DN disconnection errors and parameter access errors after the error status is cleared.
Remote module information acquisition function at start-up	Allows for automatic acquisition of information of remote modules when the CPU module is reset or power off and on the system.
Backup/restoring function	<p>Backs up various information of the connected remote module into the SD memory card of the CPU module. This function restores the information backed up on the SD memory card of the CPU module into the connected remote module.</p> <p>For details, refer to the following.</p> <p> iQ Sensor Solution Reference Manual</p>
Easy replacement function for one remote module ^{*1}	Allows for automatically setting addresses and device parameters without an address writer when a remote module is replaced with the same type of it.
Word data start address setting function ^{*1}	Allows for setting start addresses of word data transmission. This function shortens the word transmission cycle time.
AnyWireASLINK version compatibility inspection function ^{*1}	Inspects whether a remote module that does not support the word transmission is connected to the RJ51AW12AL or not.

^{*1} The availability of the function differs depending on the production information of the RJ51AW12AL. ( MELSEC iQ-R AnyWireASLINK Master Module User's Manual (Application))

4 PROCEDURES BEFORE OPERATION

This chapter describes the procedures before operation.

1. Configuring a system

Configure an AnyWireASLINK system and set parameters which are required for start-up.

- WIRING (📖 Page 29 WIRING)
- Parameter setting (📖 MELSEC iQ-R AnyWireASLINK Master Module User's Manual (Application))
- Address setting of remote modules (📖 MELSEC iQ-R AnyWireASLINK Master Module User's Manual (Application))
- Automatic address detection function (📖 MELSEC iQ-R AnyWireASLINK Master Module User's Manual (Application))

2. Powering on the system

Power on and start the system in the order shown below.

- Turn on the 24VDC external power supply for the AnyWireASLINK system.
- Turn on the power supply of the programmable controller.

3. Checking operations with the LEDs

Check whether communications are established normally.

When the communications are established normally, the following LED on/off statuses are as follows.

- RUN LED: On
- ERR LED: Off
- LINK LED: Flashing
- SET LED: Off
- ALM LED: Off

4. Programming

Create a program. For details, refer to the following.

📖 Page 35 COMMUNICATION EXAMPLE


Point 🔍

- If the programmable controller is powered on before the 24VDC external power supply in the AnyWireASLINK system, a transmission cable voltage drop detection error may occur.
 - To power off the system, power off the programmable controller, and turn off the 24VDC external power supply in the AnyWireASLINK system.
-

5 SYSTEM CONFIGURATION

5.1 System Configuration of AnyWireASLINK

An AnyWireASLINK system consists of the RJ51AW12AL, remote modules, and a terminating unit. The remote modules and a terminating unit are products manufactured by Anywire Corporation.



- (1) RJ51AW12AL
- (2) Remote module (ASLINKER)
- (3) Remote module (ASLINKAMP)
- (4) Terminating unit
- (5) Cylinder, switch, or others
- (6) Sensor head
- (7) Link connector

For the number of connectable remote modules, refer to the following.

📖 Page 18 Performance Specifications



For applicable CPU modules and the number of mountable modules, refer to the following.


📖 MELSEC iQ-R Module Configuration Manual

5.2 Power Supply to the AnyWireASLINK System

Method of supplying the power to the remote module

Connect a 24VDC external power supply to the RJ51AW12AL.

The power consumed in the internal control circuits of all the remote modules and the external load power connected to non-isolation remote modules are supplied collectively from the 24VDC external power supply connected to the RJ51AW12AL.

( Page 18 Performance Specifications)

Scope of the power supply with transmission cables (DP and DN)

The current consumption of the system must satisfy all the following conditions for the RJ51AW12AL.

Item	Calculation formula	Description
Condition 1	$I(A) = (I_{hin} \times m) + (I_{ho} \times n) + (I_{zdin} \times p) + (I_{zdo} \times q) \leq \text{The maximum value of transmission cable supply current}$	<p>I_{hin}: Current consumption of the non-isolation input remote module/I/O combined remote module</p> <p>I_{ho}: Current consumption of the non-isolation output remote module</p> <p>I_{zdin}: Current consumption of the isolation input remote module/I/O combined remote module</p> <p>I_{zdo}: Current consumption of the isolation output remote module</p> <p>m: Number of connected non-isolation input remote modules/I/O combined remote modules</p> <p>n: Number of connected non-isolation output remote modules</p> <p>p: Number of connected isolation input remote modules/I/O combined remote modules</p> <p>q: Number of connected isolation output remote modules</p>
Condition 2	$V_m(V) - \Delta V(V) \geq 20V$	V_m : Supply voltage for the RJ51AW12AL
Condition 3	$V_m(V) - \Delta V(V) \geq \text{The lowest allowable voltage of the connected load}$	ΔV : Cable-to-cable voltage drop

Description of the condition 1

■ Constants related to the non-isolation remote module (I_{hin}, I_{ho})


In the non-isolation remote module, the current required for the internal control circuit and the connected load is supplied with transmission cables (DP, DN).

■ I_{hin}(A): Current consumption of the non-isolation input remote module/I/O combined remote module

= Current consumption of the non-isolation input remote module/I/O combined remote module + Current consumption of connected load (three-wire sensor) × Number of points

■ I_{ho}(A): Current consumption of the non-isolation output remote module

= Current consumption of the non-isolation output remote module + Current consumption of connected load × Number of points



- (1) 24VDC external power supply
- (2) Non-isolation remote module
- (3) Internal control circuit
- (4) Power supply generation
- (5) Connected load

Point


- The 24VL and 0VL terminals of a remote module are used to supply the power to the connected load.
- For the current consumption of a non-isolation remote module, refer to the manual for the remote module used.

■ Constants related to the isolation remote module (Izdin, Izdo)

In the isolation remote module, only the current required for the internal control circuit is supplied with the transmission cables (DP, DN), whereas that for the connected load is supplied from the power cables (24V, 0V).

■ Izdin(A): Current consumption of the isolation input remote module/I/O combined remote module

■ Izdo(A): Current consumption of the isolation output remote module



- (1) 24VDC external power supply
- (2) Isolation remote module
- (3) Internal control circuit
- (4) Load driving circuit (photocoupler)
- (5) Connected load

Point

- In isolation remote modules, the current consumption of the connected load is not subject to the current restriction condition for the AnyWireASLINK system.
- For the current consumption of isolation remote modules, refer to the manual for the remote module used.

■ Transmission cable supply current (I(A))

The transmission cable supply current in the AnyWireASLINK system is determined by the following formula. (Number of connected modules: m, n, p, q)

$$I(A) = (I_{hin} \times m) + (I_{ho} \times n) + (I_{zdin} \times p) + (I_{zdo} \times q)$$

■ Maximum transmission cable supply current

For the maximum transmission cable supply current, refer to the following.

☞ Page 18 Performance Specifications

Description of the conditions 2 and 3

■Vm: Supply voltage for the RJ51AW12AL

- Voltage: 21.6 to 27.6VDC (24VDC -10 to +15%), ripple voltage 0.5Vp-p or lower
- Recommended voltage: 26.4VDC (24VDC +10%)

■ΔV(V): Cable-to-cable voltage drop

Calculation formula	Description
$\Delta V(V) = \text{Transmission cable supply current } I(A) \times \text{Cable resistance } R(\Omega)$	<p>■Transmission cable supply current (I(A))</p> <p>☞ Page 27 Transmission cable supply current (I(A))</p> <p>■Cable resistance R (Ω)</p> <p>= Cable length (m) × Conductor resistance (Ω/m) × 2</p> <ul style="list-style-type: none"> • Wire diameter 1.25mm² → Conductor resistance 0.015Ω/m • Wire diameter 0.75mm² → Conductor resistance 0.025Ω/m

Calculation example

The example shows how to check whether the total wiring length of 100m is sufficient to configure a system in the following conditions.

■Condition

Item	Description
Non-isolation bit input remote module (ASLINKER)	Number of bit data points
	2 points
	Module current consumption
	15mA
	Number of modules
	24
Connected load (three-wire sensor)	Three-wire sensor current consumption
	13mA
	Number of sensors
	2
	Power supply voltage
	24VDC ±10%
Transmission cable (DP, DN)	Wire diameter
	1.25mm ²
Supply voltage for the RJ51AW12AL	Power supply voltage
	24VDC

■Calculation result

Item	Calculation formula	Result
Condition 1	$I(A) = (I_{in} \times m) = I(A) \leq \text{The maximum transmission cable supply current}$ $\Rightarrow (0.015 + (0.013 \times 2)) \times 24 = 0.984A \leq 1A$	Satisfied
Condition 2	$V_m(V) - \Delta V(V) \geq 20V$ $\Rightarrow 24 - (0.984 \times 100 \times 0.015 \times 2) = 24 - 2.95 = 21.05V \geq 20V$	Satisfied
Condition 3	$V_m(V) - \Delta V(V) \geq \text{The lowest allowable voltage of the connected load}$ $\Rightarrow \text{The lowest limit of the allowable voltage range for connected load} = 24 - 24 \times 0.1 = 21.6V$ $\Rightarrow 21.05V < 21.6V$	Not satisfied

The calculation results of the conditions 1) to 3) show that the system cannot be configured.

However, the system can be configured if the power supply for the RJ51AW12AL is changed to 24.55VDC or higher.

6 WIRING

This chapter describes the wiring of the RJ51AW12AL.

6.1 Terminal Block

Type of the terminal block

The following terminal block is used in the RJ51AW12AL.

Name	Model	Contact
Transmission cable terminal block	FMC1,5/7-STF-3,81	PHOENIX CONTACT GmbH & Co. KG (www.phoenixcontact.com)

Tightening torque

Tighten terminal block screws within the following tightening torque range.

Screws tightened	Tightening torque range
Terminal block mounting screw	0.2 to 0.3N·m

To connect the terminal block, a flathead screwdriver having a tipped size of 0.4×2.5mm is required.


Before removing the transmission cable terminal block, check that the terminal block mounting screws on the both sides are completely loosened (removed from the socket).

Pulling with excessive force while the terminal block mounting screws on the both sides are still tightened may damage the devices.

Before tightening, check that there are no short circuits due to the disconnected or frayed wires. Then tighten the terminal block mounting screws on the both sides securely.

Signal name of the terminal block

The following shows the signal names of the terminal block.

Terminal block	Signal name	Description
	IN	24V 0V Power supply terminals for driving the transmission circuit of the AnyWireASLINK system and for a remote module. Connect to a 24VDC external power supply.
	OUT	24V 0V Terminals for connecting isolation (4-wire) remote modules. If the modules are connected to these terminals, supplying power for each module from the 24VDC external power supply is not necessary.
	DP	AnyWireASLINK transmission signal terminals DP: Transmission cable (+), DN: Transmission cable (-) Connect to the DP and DN terminals on the remote module or terminating unit.
	DN	
	LG	Connected to the neutral point of the noise filter inserted between the 24V and 0V terminals. Ground the LG terminal with the functional ground terminal (FG terminal) on the programmable controller at a single point.

6.2 Wiring Method

This section describes the wiring to the transmission cable terminal block of the RJ51AW12AL.


Wiring to the transmission cable terminal block

■Connecting a cable

Insert a cable with a bar solderless terminal into a wire insertion opening and fully push the cable. Then, pull the cable slightly to check that it is clamped securely.


■Disconnecting a cable

Hold down the open/close button of a cable to disconnect with a flathead screwdriver. Pull out the cable with the open/close button held down.



Precautions

- In the AnyWireASLINK system, signals and power are supplied to a remote module with two transmission cables: DP and DN. Therefore, use a stranded wire of 0.75mm² or larger as the main line.
- Wires such as general-purpose wires, cabtyre cables, and flat cables can be used.
- Do not run multiple transmission cables (DP, DN) using a multicore cable. Run multiple transmission cables (DP, DN) are affected by noise, causing a malfunction.



- The voltage should not fall below the lower limit of the allowable voltage range due to a voltage drop caused by the cable. If the voltage falls below the lower limit, malfunctions may occur.
- Do not connect soldered cables directly to the terminals. Doing so may loosen the screws, resulting in a poor contact.
- Use bar solderless terminals for the wiring to the terminal block. If inserted as is, a stripped cable cannot be clamped properly in a wire insertion opening.
- Use a crimping tool to connect a bar solderless terminal to a cable.
- Before inserting a bar solderless terminal, check the shapes of the wire insertion opening and bar solderless terminal. Then, insert the terminal in the correct orientation. A bar solderless terminal wider than the wire insertion opening may damage the terminal block. (☞ Page 32 Solderless terminal)
- Signal names are not printed on the transmission cable terminal block. To avoid incorrect wiring, wire cables to the terminal block attached to the RJ51AW12AL.
- Do not insert multiple bar solderless terminals into one wire insertion opening. Doing so may cause damage on the terminal block or cable, or malfunction.

6.3 Wiring Product

Applicable wires and cables

Use the following wires or cables connected to the transmission cable terminal block.

Classification	Name	Wire diameter	Type	Material	Temperature rating
Transmission cable (DP, DN) Power supply cable (24V, 0V)	UL-listed general-purpose 2-wire cable (VCTF, VCT)	0.75 to 1.25mm ²	Stranded wire	Copper wire	75°C or higher* ¹
	UL-listed general-purpose wire				
	Dedicated flat cable	1.25mm ²			
		0.75mm ²			

*1 When the operating ambient temperature is higher than 55°C, use cables with a temperature rating of 80°C or higher.

Solderless terminal

For safety reasons, it is recommended to connect bar solderless terminals.


Use UL-listed solderless terminals and, for processing, use a tool recommended by their manufacturer.

Type	Model	Application	Contact
Bar solderless terminal	AI 0,75-10 GY	Processing of a 0.75mm ² wire	PHOENIX CONTACT GmbH & Co. KG (www.phoenixcontact.com)
	AI 1,5-10	Processing of a 1.25mm ² wire	

6.4 Connecting Remote Module or Terminating Unit

Connection type

- The distance in an AnyWireASLINK stand-alone system is 200m, which is the total wiring length including the main line and branch line. (It varies depending on the wire diameter of the transmission cables (DP, DN) or the transmission cable supply current.)
- AnyWireASLINK systems support tree branch connection, T-branch connection, and multidrop connection.
- Up to 128 remote modules can be connected.



- (1) Tree branch connection
(2) T-branch connection



The total wiring length of the transmission distance for the AnyWireASLINK system can be calculated from $A + B + C$.

Note that the total length should not exceed the total wiring length set for the system to branch lines.

Terminating unit


To ensure more stable transmission quality, connect a terminating unit to the end of a transmission cable (DP, DN).

■Terminating unit connection

Connect at least one terminating unit for one AnyWireASLINK line. Connect it at the farthest end from the RJ51AW12AL. The maximum number of connectable modules differs depending on the terminating unit used. For details, refer to user's manuals for the terminating unit used.

■Branch of transmission cables (DP, DN)

Connect one terminating unit at the end of a branch line that exceeds 40m.



(1) Main line

(2) 40m or longer branch line

7 COMMUNICATION EXAMPLE

This chapter describes programming and start-up examples of the RJ51AW12AL.

7.1 Communication of RJ51AW12AL with Remote Module

The input signals of the input ASLINKER, stored in 'Bit input information area' (Un\G0 to Un\G15) of the RJ51AW12AL, are batch-transferred to the device data of the CPU module.


Moreover, the device data of the CPU module is batch-transferred to 'Bit output information area' (Un\G4096 to Un\G4111) of the RJ51AW12AL, and the output signals are transmitted to the output ASLINKER.

System configuration example

System configuration

The following system configuration is used to describe communication between the RJ51AW12AL and bit remote modules.


- Power supply module: R61P
- CPU module: R04CPU
- AnyWireASLINK master module: RJ51AW12AL (start I/O No.: 0000H to 001FH)



- (1) Link connector
- (2) Terminating unit
- (3) 2-point output ASLINKER
- (4) 2-point input ASLINKER
- (5) LED
- (6) Sensor switch

Correlations between devices

The following shows the correlations between devices.




- (1) CPU module
- (2) RJ51AW12AL
- (3) Input ASLINKER: Address 0
- (4) Output ASLINKER: Address 0
- (5) Buffer memory
- (6) Sensor switch
- (7) LED

RJ51AW12AL setting


Connect the engineering tool to the CPU module and set parameters.

1. Set the CPU module as follows.


 [Project] ⇒ [New]




2. Click the [Setting Change] button to use the module label.




3. Set the RJ51AW12AL as follows.

 [Navigation window] ⇒ [Parameter] ⇒ [Module Information] ⇒ Right-click ⇒ [Add New Module]



4. Click the [OK] button to add the module labels of the RJ51AW12AL.



5. Set the items in "Basic setting" as follows.

[Navigation window] ⇒ [Parameter] ⇒ [Module Information] ⇒ [RJ51AW12AL] ⇒ [Module Parameter] ⇒ [Basic Settings]

Item	Setting Value
<input checked="" type="checkbox"/> Transmission points	
<i>Transmission points setting</i>	3: 512 points(256 input points/256 output points) ▾
<input checked="" type="checkbox"/> Startup operating mode	
Startup operating mode setting	0: Without remote module information acquisition
<input checked="" type="checkbox"/> Double verification	
Double verification setting	0: All points,double verification of a bit
<input checked="" type="checkbox"/> Error status automatic recovery	
Error status automatic recovery mode setting	0: No error status automatic recovery
<input checked="" type="checkbox"/> Output data hold/clear setting when error occurs	
Output data hold/clear setting when error occurs	0: CLEAR
<input checked="" type="checkbox"/> Word input data hold/clear setting when error occurs	
Word input data hold/clear setting when error occurs	0: CLEAR
<input checked="" type="checkbox"/> Easy replacement enable/disable setting for one remote module	
Easy replacement enable/disable setting for one remote module	0: Enable
<input checked="" type="checkbox"/> Word data points setting	
To use or not to use word data setting	0: Not use
Word data points setting	0: word data (no word data)
Word data start address	0
Word data points setting per frame	0: word data (no word data)

6. Write the set parameters into the CPU module, and reset the CPU module or power off and on the system.

[Online] ⇒ [Write to PLC]

Point

In this example, default values were used for parameters that are not shown above. For the parameters, refer to the following.

MELSEC iQ-R AnyWireASLINK Master Module User's Manual (Application)

Settings of the remote module

Write addresses to remote modules to register the RJ51AW12AL.

Address setting

Write addresses to remote modules with an address writer.

- Output ASLINKER: Address 0 (ID: 0000H)
- Input ASLINKER: Address 0 (ID: 0200H)

Automatic address detection

Keep pressing the SET switch on the RJ51AW12AL until the SET LED turns on.

When the SET LED flashes and then turns off, it indicates that the registration of IDs (addresses) has been completed.

Checking the system status

Check whether the RJ51AW12AL can communicate with the remote modules normally.

The following LED statuses indicate that the communication is established normally.

- LED of the RJ51AW12AL

LED	Status
RUN LED	On
ERR LED	Off
LINK LED	Flashing
SET LED	Off
ALM LED	Off

- LED of the ASLINKER

LED	Status
LINK LED	Flashing
ALM LED	Off

Program example

Classification	Label name	Description	Device
Module label	RJ51AW12AL_1.bModuleREADY	Module READY	X0
	RJ51AW12AL_1.bDP_DNShortError	DP/DN short error	X1
	RJ51AW12AL_1.b24V_DPShortError	24V/DP short error	X2
	RJ51AW12AL_1.bTransmissionCableVoltageDdropError	Transmission cable voltage drop error	X3
	RJ51AW12AL_1.bDP_DNDisconnectionError	DP/DN disconnection error	X4
	RJ51AW12AL_1.uInputInformationArea0_15	Bit input information area	U0\G0
	RJ51AW12AL_1.uOutputInformationArea0_15	Bit output information area	U0\G4096

Label to be defined	Define the global label as follows.		
	Label Name	Data Type	Class
	TimerContact	Timer	VAR_GLOBAL
	ProgramStart	Bit	VAR_GLOBAL
	InputArea	Word [Signed]	VAR_GLOBAL

(0)	RJ51AW12AL_1.bModuleREADY X0	RJ51AW12AL_1.bDP_DNShortError X1	RJ51AW12AL_1.b24V_DPShortError X2	RJ51AW12AL_1.bTransmissionCableVoltageDdropError X3	RJ51AW12AL_1.bDP_DNDisconnectionError X4				OUT	TimerContact	K10
										T0	
(9)	TimerContact T0									SET	ProgramStart M1
(11)	RJ51AW12AL_1.bDP_DNShortError X1									RST	ProgramStart M1
	RJ51AW12AL_1.b24V_DPShortError X2										
	RJ51AW12AL_1.bTransmissionCableVoltageDdropError X3										
	RJ51AW12AL_1.bDP_DNDisconnectionError X4										
(16)	ProgramStart M1								BMOV	RJ51AW12AL_1.uInputInformationArea0_15 K4X100	K16
									BMOV	OutputArea K4Y100	RJ51AW12AL_1.uOutputInformationArea0_15 K16
(27)											{END }

- (16) When 'ProgramStart' (M1) is turned on, the values of 'Bit input information area' (U0\G0) are transferred to 'Input ASLINKER data storage area' (K4X100).
The values of 'Output ASLINKER data storage area' (K4Y100) are transferred to 'Bit output information area' (U0\G4096).




After 'Module READY' (X0) turns on, wait at least one second and start the program.

APPENDIX

Appendix 1 External Dimensions

This chapter describes the external dimensions of the RJ51AW12AL.



A

A

INDEX

A

Address	15
AnyWireASLINK	15

B

Bar solderless terminal	32
-----------------------------------	----

D

Device	15
------------------	----

E

Engineering tool	15
External dimensions	18
External power supply	18

I

ID	15
Intelligent function module	15
Internal current consumption (5VDC)	18

M

Module label	15
------------------------	----

P

Power supply cable (24V, 0V)	32
--	----

R

RAS	15
---------------	----

S

Solderless terminal	32
-------------------------------	----

T

T-branch	33
Terminating unit	15
Transmission cable (DP, DN)	32
Transmission cable terminal block	29
Tree branch	33

W

Weight	18
------------------	----

MEMO

REVISIONS

*The manual number is given on the bottom left of the back cover.

Revision date	*Manual number	Revision
June 2016	SH(NA)-081584ENG-A	First edition
November 2016	SH(NA)-081584ENG-B	■Added or modified parts SAFETY PRECAUTIONS, RELEVANT MANUALS, Chapter 3
April 2019	SH(NA)-081584ENG-C	■Added or modified parts RELEVANT MANUALS, TERMS, Chapter 1, 2, 3, Section 5.1, 5.2, 6.4
September 2020	SH(NA)-081584ENG-D	■Added or modified parts SAFETY PRECAUTIONS, RELEVANT MANUALS, TERMS, Section 2.1
March 2021	SH(NA)-081584ENG-E	■Added or modified part SAFETY PRECAUTIONS
November 2021	SH(NA)-081584ENG-F	■Added or modified parts PRECAUTIONS REGARDING WARRANTY AND SPECIFICATIONS, SAFETY PRECAUTIONS, Section 2.1, 6.3
March 2022	SH(NA)-081584ENG-G	■Added or modified parts Section 2.1, 6.3
June 2023	SH(NA)-081584ENG-H	■Added or modified parts SAFETY PRECAUTIONS, TERMS, GENERIC TERMS AND ABBREVIATIONS, Chapter 1, Section 2.1, Chapter 3, 4, Section 5.1, 5.2, 6.1, 6.2, 6.4, 7.1
May 2025	SH(NA)-081584ENG-I	■Added or modified parts Section 2.1, 6.3

Japanese manual number: SH-081582-I

This manual confers no industrial property rights or any rights of any other kind, nor does it confer any patent licenses. Mitsubishi Electric Corporation cannot be held responsible for any problems involving industrial property rights which may occur as a result of using the contents noted in this manual.

© 2016 MITSUBISHI ELECTRIC CORPORATION

WARRANTY

Please confirm the following product warranty details before using this product.

1. Gratis Warranty Term and Gratis Warranty Range

If any faults or defects (hereinafter "Failure") found to be the responsibility of Mitsubishi occurs during use of the product within the gratis warranty term, the product shall be repaired at no cost via the sales representative or Mitsubishi Service Company.

However, if repairs are required onsite at domestic or overseas location, expenses to send an engineer will be solely at the customer's discretion. Mitsubishi shall not be held responsible for any re-commissioning, maintenance, or testing on-site that involves replacement of the failed module.

[Gratis Warranty Term]

The gratis warranty term of the product shall be for one year after the date of purchase or delivery to a designated place. Note that after manufacture and shipment from Mitsubishi, the maximum distribution period shall be six (6) months, and the longest gratis warranty term after manufacturing shall be eighteen (18) months. The gratis warranty term of repair parts shall not exceed the gratis warranty term before repairs.

[Gratis Warranty Range]

- (1) The range shall be limited to normal use within the usage state, usage methods and usage environment, etc., which follow the conditions and precautions, etc., given in the instruction manual, user's manual and caution labels on the product.
- (2) Even within the gratis warranty term, repairs shall be charged for in the following cases.
 1. Failure occurring from inappropriate storage or handling, carelessness or negligence by the user. Failure caused by the user's hardware or software design.
 2. Failure caused by unapproved modifications, etc., to the product by the user.
 3. When the Mitsubishi product is assembled into a user's device, Failure that could have been avoided if functions or structures, judged as necessary in the legal safety measures the user's device is subject to or as necessary by industry standards, had been provided.
 4. Failure that could have been avoided if consumable parts (battery, backlight, fuse, etc.) designated in the instruction manual had been correctly serviced or replaced.
 5. Failure caused by external irresistible forces such as fires or abnormal voltages, and Failure caused by force majeure such as earthquakes, lightning, wind and water damage.
 6. Failure caused by reasons unpredictable by scientific technology standards at time of shipment from Mitsubishi.
 7. Any other failure found not to be the responsibility of Mitsubishi or that admitted not to be so by the user.

2. Onerous repair term after discontinuation of production

- (1) Mitsubishi shall accept onerous product repairs for one year after production of the product is discontinued. Discontinuation of production shall be notified with Mitsubishi Technical Bulletins, etc.
- (2) Product supply (including repair parts) is not available after production is discontinued.

3. Overseas service

Overseas, repairs shall be accepted by Mitsubishi's local overseas FA Center. Note that the repair conditions at each FA Center may differ.

4. Exclusion of loss in opportunity and secondary loss from warranty liability

Regardless of the gratis warranty term, Mitsubishi shall not be liable for compensation to:

- (1) Damages caused by any cause found not to be the responsibility of Mitsubishi.
- (2) Loss in opportunity, lost profits incurred to the user by Failures of Mitsubishi products.
- (3) Special damages and secondary damages whether foreseeable or not, compensation for accidents, and compensation for damages to products other than Mitsubishi products.
- (4) Replacement by the user, maintenance of on-site equipment, start-up test run and other tasks.

5. Changes in product specifications

The specifications given in the catalogs, manuals or technical documents are subject to change without prior notice.

INFORMATION AND SERVICES

For further information and services, please contact your local Mitsubishi Electric sales office or representative.
Visit our website to find our locations worldwide.

MITSUBISHI ELECTRIC Factory Automation Global Website

Locations Worldwide

www.MitsubishiElectric.com/fa/about-us/overseas/

TRADEMARKS

Anywire and AnyWireASLINK are either registered trademarks or trademarks of Anywire Corporation.

The company names, system names and product names mentioned in this manual are either registered trademarks or trademarks of their respective companies.

In some cases, trademark symbols such as '™' or '®' are not specified in this manual.

Anywire Anywire Corporation www.anywire.jp

SH(NA)-081584ENG-I(2505)MEE

MODEL: R-ANYWIRE-U-IN-E

mitsubishi electric corporation

HEAD OFFICE: TOKYO BLDG., 2-7-3, MARUNOUCHI, CHIYODA-KU, TOKYO 100-8310, JAPAN
NAGOYA WORKS: 1-14, YADA-MINAMI 5-CHOME, HIGASHI-KU, NAGOYA 461-8670, JAPAN

When exported from Japan, this manual does not require application to the
Ministry of Economy, Trade and Industry for service transaction permission.

Specifications subject to change without notice.