

MELSEC System Q

Programmable Logic Controllers

User's Manual

NAMUR Input Module ME1X16NA-Q



About this Manual

The texts, illustration, diagrams and examples in this manual are provided for information purposes only. They are intended as aids to help explain the installation, operation, programming and use of the programmable logic controllers of the MELSEC System Q

If you have any questions about the installation and operation of any of the products described in this manual please contact your local sales office or distributor (see back cover). You can find the latest information and answers to frequently asked questions on our website at www.mitsubishi-automation.com.

MITSUBISHI ELECTRIC EUROPE BV reserves the right to make changes to this manual or the technical specifications of its products at any time without notice.

© 2013

**NAMUR Input Module
ME1X16NA-Q
User's Manual
Art.-no.: 260166**

| Version | | | Changes / Additions / Corrections |
|----------------|---------|--------|--|
| A | 01/2013 | pdp-dk | First edition |
| | | | |

Contents

| | | |
|----------|---|------|
| 1 | Overview | |
| 1.1 | Introduction..... | 1-1 |
| 1.2 | Features of the ME1X16NA-Q | 1-2 |
| 2 | System Configuration | |
| 2.1 | Applicable Systems..... | 2-1 |
| 2.2 | How to Check the Function Version and Serial No. of the Modules | 2-4 |
| 3 | Detailed Description of the Module | |
| 3.1 | Part Names..... | 3-1 |
| 3.1.1 | Signal Layout of the Connector | 3-2 |
| 3.2 | Specifications | 3-3 |
| 3.2.1 | Input Filter | 3-4 |
| 3.2.2 | External Dimensions | 3-5 |
| 3.3 | Functions of the NAMUR Input Module..... | 3-6 |
| 3.3.1 | Short Pulse Discrimination (Filtering)..... | 3-6 |
| 3.3.2 | Pulse Stretching | 3-7 |
| 3.3.3 | Flutter Monitoring..... | 3-7 |
| 3.3.4 | Events..... | 3-8 |
| 3.4 | I/O Signals for the Programmable Controller CPU..... | 3-10 |
| 3.4.1 | List of I/O signals | 3-10 |
| 3.4.2 | Details of I/O signals | 3-11 |
| 3.5 | Buffer Memory | 3-15 |
| 3.5.1 | Buffer Memory Assignment | 3-16 |
| 3.5.2 | Filtered Input Values (Un\G0) | 3-18 |
| 3.5.3 | Latched Wire Break Flags (Un\G1) | 3-18 |
| 3.5.4 | Latched Short Circuit Flags (Un\G2) | 3-19 |
| 3.5.5 | Flutter Monitor Flags (Un\G3) | 3-20 |
| 3.5.6 | Error Detection Settings (Un\G4) | 3-21 |
| 3.5.7 | Wire Break Flags (Un\G5)..... | 3-22 |
| 3.5.8 | Short Circuit Flags (Un\G6) | 3-22 |

| | | |
|--------|--|------|
| 3.5.9 | Event Buffer Enable Settings (Positive Edge (Un\G8), negative Edge (Un\G9)) | 3-23 |
| 3.5.10 | Event Buffer Enable Settings (Errors) (Un\G10) | 3-24 |
| 3.5.11 | Event Buffer (Un\G11 to Un\G28) | 3-25 |
| 3.5.12 | Short Pulse Discrimination Time CH□ (Un\G30 to Un\G45) | 3-27 |
| 3.5.13 | Pulse Stretching Time CH□ (Un\G46 to Un\G61) | 3-28 |
| 3.5.14 | Flutter Monitoring Parameters CH□ (Un\G62 to Un\G77) | 3-28 |
| 3.5.15 | Real-Time Clock Setting (Un\G80 to Un\G87) | 3-29 |
| 3.5.16 | Error Code (Un\G90) | 3-30 |

4 Setup and Procedures before Operation

| | | |
|-------|---|-----|
| 4.1 | Handling Precautions | 4-1 |
| 4.2 | Setup and Procedures before Operation | 4-2 |
| 4.3 | Installation of the Module | 4-3 |
| 4.4 | Wiring | 4-4 |
| 4.4.1 | Wiring Precautions | 4-4 |
| 4.4.2 | External Wiring | 4-7 |
| 4.5 | PLC Parameter Setting | 4-8 |
| 4.5.1 | I/O Assignment | 4-8 |
| 4.5.2 | Intelligent Function Module Switch Settings | 4-9 |

5 Programming

| | | |
|-------|---|------|
| 5.1 | Programming Procedure | 5-1 |
| 5.2 | Example 1: Reading of Input Values and Error Handling | 5-3 |
| 5.2.1 | Before Creating a Program | 5-4 |
| 5.2.2 | Program | 5-5 |
| 5.3 | Example 2: Signal Conditioning | 5-9 |
| 5.3.1 | Before Creating a Program | 5-9 |
| 5.3.2 | Program | 5-10 |

| | | |
|----------|---|-----|
| 6 | Troubleshooting | |
| 6.1 | Error Code List | 6-1 |
| 6.2 | Troubleshooting by Symptom | 6-2 |
| 6.2.1 | When the LEDs of the ME1X16NA-Q are not turned ON | 6-2 |
| 6.2.2 | When the Input Values cannot be read | 6-2 |
| 6.2.3 | When Wire Breaks and Short Circuits are not detected | 6-3 |
| 6.2.4 | When there is always a Wire Break detected (XnD is ON) | 6-3 |
| 6.2.5 | When Flutter is not detected | 6-3 |
| 6.2.6 | When Events are not recorded | 6-3 |
| 6.2.7 | When the Short Pulse Discrimination Function is not working | 6-4 |
| 6.2.8 | When the Pulse Stretching Function is not working | 6-4 |
| 6.3 | Checking the Module Status | 6-5 |

INDEX

1 Overview

This User's Manual describes the specifications, handling and programming methods for the NAMUR Input Module ME1X16NA-Q (hereinafter referred to as the ME1X16NA-Q) which is used with the programmable controllers of the MELSEC System Q.

Before using the ME1X16NA-Q, please read this manual and the relevant manuals carefully and develop familiarity with the functions and performance of the MELSEC System Q series programmable controller to handle the product correctly.

1.1 Introduction

The ME1X16NA-Q is a digital input module for connection of up to 16 NAMUR sensors.

NAMUR is an international user association of automation technology in process industries. The principle of operation of a NAMUR sensor is based on the recommendations of this association.

In contrast to an ordinary binary sensor with only two states (ON and OFF), a NAMUR sensor can indicate four states: ON, OFF, wire break and short circuit.




Fig. 3-1: The sensor current is an indication of the four states of a NAMUR sensor

1.2 Features of the ME1X16NA-Q

Connection of up to 16 NAMUR sensors

Up to 16 NAMUR sensors can be connected to a single ME1X16NA-Q. The ME1X16NA-Q supplies the voltage for the sensors and measures the current in order to detect their individual states.

Wire breaks and short circuits are recognised for each input. The respective input is "0" within the wire break or short circuit condition.

As an alternative to NAMUR sensors, contacts with an external resistor network can be used.

Event monitoring

The ME1X16NA-Q can monitor the sensor status (switched ON, switched OFF, wire break, short circuit, fluttering signal), and store the historical data of occurred events into an internal buffer.

Time stamping

Events are marked with a time stamp from the internal clock of the ME1X16NA-Q.

Pulse conditioning

The ME1X16NA-Q can blank out short pulses as well as stretch pulses to an adjustable minimum length.

Flutter monitoring

Fluttering input signals can be detected. This can be a hint for a defective sensor or a poorly adjusted target.

For a detailed description of the functions of the ME1X16NA-Q, please refer to section 3.3.

2 System Configuration

2.1 Applicable Systems

Applicable modules, base units, and No. of modules

- When mounted with a CPU module

The table below shows the CPU modules and base units applicable to the NAMUR Input Module ME1X16NA-Q and quantities for each CPU model.

Depending on the combination with other modules or the number of mounted modules, the power supply capacity may be insufficient. Pay attention to the power supply capacity before mounting modules, and if the power supply capacity is insufficient, change the combination of the modules.

| Applicable CPU module | | No. of ME1X16NA-Q that can be installed*1 | Base unit*2 | | |
|-----------------------------|-----------------------------|---|----------------|---------------------|---|
| CPU type | CPU model | | Main base unit | Extension base unit | |
| Programmable controller CPU | Basic model QCPU | Q00JCPU | ● | ● | |
| | | Q00CPU | | | |
| | | Q01CPU | | | |
| | High performance model QCPU | Q02CPU | Up to 64 | ● | ● |
| | | Q02HCPU | | | |
| | | Q06HCPU | | | |
| | | Q12HCPU | | | |
| | | Q25HCPU | | | |
| | Process CPU | Q02PHCPU | Up to 64 | ● | ● |
| | | Q06PHCPU | | | |
| | | Q12PHCPU | | | |
| | | Q25PHCPU | | | |
| | Redundant CPU | Q12PRHCPU | Up to 53 | ○ | ● |
| | | Q25PRHCPU | | | |
| | Universal model QCPU | Q00UJCPU | Up to 16 | ● | ● |
| | | Q00UCPU | Up to 24 | | |
| | | Q01UCPU | | | |
| Q02UCPU | | Up to 36 | | | |
| Q□UD(E)CPU | | Up to 64 | | | |
| Q50UDEHCPU | | | | | |
| Q100UDEHCPU | | | | | |
| Safety CPU | QS001CPU | — | ○ | ○ | |
| C Controller module | Q06CCPU-V-H01 | Up to 64 | ● | ● | |
| | Q06CCPU-V | | | | |
| | Q06CCPU-V-B | | | | |
| | Q12DCCPU-V | | | | |

Tab. 2-1: Applicable base units and number of mountable modules

● : Applicable, ○ : Not applicable

*1 Limited within the range of I/O points for the CPU module.

*2 The ME1X16NA-Q can be installed to any I/O slot of a base unit.

- Mounting to a MELSECNET/H remote I/O station

The table below shows the network modules and base units applicable to the analog output module ME1X16NA-Q and quantities for each network module model.

Depending on the combination with other modules or the number of mounted modules, power supply capacity may be insufficient. Pay attention to the power supply capacity before mounting modules, and if the power supply capacity is insufficient, change the combination of the modules.

| Applicable network module | No. of ME1X16NA-Q that can be installed*1 | Base unit*2 | |
|---------------------------|---|--------------------------------------|---|
| | | Main base unit of remote I/O station | Extension base unit of remote I/O station |
| QJ72LP25-25 | Up to 64 | ● | ● |
| QJ72LP25G | | | |
| QJ72LP25GE | | | |
| QJ72BR15 | | | |

Tab. 2-2: Applicable base units and number of mountable modules in a MELSECNET/H remote I/O station

● : Applicable, ○ : Not applicable

*1 Limited within the range of I/O points for the network module.

*2 The ME1X16NA-Q can be installed to any I/O slot of a base unit.

NOTES

The Basic model QCPU or C Controller module cannot create the MELSECNET/H remote I/O network.

When using the time stamping function for a NAMUR input module mounted in a remote I/O station, please consider the delay of the I/O signals and the clock data sent to the module.

Support of the multiple CPU system

The function version of the NAMUR input module supports the multiple CPU system. When using the ME1X16NA-Q in a multiple CPU system, refer to the following manual first.

- QCPU User's Manual (Multiple CPU System)

- Intelligent function module parameters

Write intelligent function module parameters to only the control CPU of the ME1X16NA-Q.

Compatibility with online module change

An online module change is a function that allows the module of the MELSEC System Q mounted on the main base unit or extension base unit to be changed during system control executed by a Process CPU or a Redundant CPU.

NOTE

The Basic model QCPU, High Performance model QCPU and Universal model QCPU are not compatible with an online module change.

Using an online module change, the module that failed during control can be replaced with the module of the same model name.

The ME1X16NA-Q does support online module change. It can be replaced online (while power is on) on any MELSECNET/H remote I/O station or in the system where a CPU module supporting the online module change function is used.

For details, refer to the relevant sections in the QCPU User's Manual (Hardware Design, Maintenance and Inspection).

Supported software packages

For setting the PLC parameters for a system containing the ME1X16NA-Q and programming the software packages GX Developer, GX IEC Developer and GX Works2 can be used.

Depending on the CPU module used, a certain version of the software is needed since newly CPU modules are not supported by previous versions.

2.2 How to Check the Function Version and Serial No. of the Modules

Using the programming software GX Developer, GX IEC Developer or GX Works2, the serial No. and the function version can be checked while the PLC is operating.

From the **Diagnostics** menu select **System Monitor** and then select **Product Inf. List**.

| Slot | Type | Series | Model name | Points | I/O No. | Master PLC | Serial No | Ver. |
|------|----------|--------|---------------|--------|---------|------------|------------------|------|
| PLC | PLC | Q | Q02HCPU | - | - | - | 0212200000000000 | B |
| 0-0 | Intelli. | Q | 026ME1X16NA-Q | 32pt | 0000 | - | 1203100000000000 | B |

Fig. 2-1: Product Information List for a PLC with a ME1X16NA-Q

NOTE

The serial number displayed on the product information screen of GX Developer, GX IEC Developer or GX Works2 describes the function information of the product. The function information of the product is updated when a new function is added.

3 Detailed Description of the Module

3.1 Part Names

This section explains the names of the components for the ME1X16NA-Q.




Fig. 3-1:
Names of parts


| No. | Name | Description |
|-----|------------------|---|
| ① | Indicator LEDs | Used to indicate the status of each input. (0: Input CH0 to F: Input CHF) On: Input is ON Off: Input is OFF |
| ② | 40-pin connector | Used for connection of the NAMUR sensors and the external power supply. |

Tab. 3-1: Description of the LEDs and the connector of the ME1X16NA-Q

3.1.1 Signal Layout of the Connector

| Connector | Pin | Signal | Pin | Signal | Channel | Remark | |
|--------------------------|-----|--------|-----|--------|---------|---|---|
| <p>Module front view</p> | B20 | Vacant | A20 | Vacant | — | — | |
| | B19 | DI0 | A19 | VS0 | 0 | Digital inputs (DI) and voltage supply (VS) for the sensor. Connect the sensor to DI□ and VS□ (□ = 0 to F). | |
| | B18 | DI1 | A18 | VS1 | 1 | | |
| | B17 | DI2 | A17 | VS2 | 2 | | |
| | B16 | DI3 | A16 | VS3 | 3 | | |
| | B15 | DI4 | A15 | VS4 | 4 | | |
| | B14 | DI5 | A14 | VS5 | 5 | | |
| | B13 | DI6 | A13 | VS6 | 6 | | |
| | B12 | DI7 | A12 | VS7 | 7 | | |
| | B11 | DI8 | A11 | VS8 | 8 | | |
| | B10 | DI9 | A10 | VS9 | 9 | | |
| | B9 | DIA | A9 | VSA | A | | |
| | B8 | DIB | A8 | VS B | B | | |
| | B7 | DIC | A7 | VSC | C | | |
| | B6 | DID | A6 | VSD | D | | |
| | B5 | DIE | A5 | VSE | E | | |
| | B4 | DIF | A4 | VSF | F | | |
| | B3 | Vacant | A3 | Vacant | — | | — |
| | B2 | | A2 | | | | |
| | B1 | 24G | A1 | 24V | — | External power supply A1: +24 V DC B1: 0 V | |

Tab. 3-2: Signal layout for the 40-pin connector of the ME1X16NA-Q



WARNING:
Leave the "vacant" pins unconnected.

For the wiring of the NAMUR input module ME1X16NA-Q please refer to section 4.4.

3.2 Specifications

The specifications for the ME1X16NA-Q are shown in the following table. For general specifications, refer to the operation manual for the CPU module being used.

| Specification | | ME1X16NA-Q |
|---|--|--|
| Number of NAMUR inputs | | 16 channels |
| Sensor voltage (from internal power supply) | | 8.2 V DC |
| ON current | | >2.1 mA |
| OFF current | | <1.2 mA |
| Hysteresis | | 0.2 mA |
| Wire break detection current | | <0.2 mA |
| Short circuit detection current | | >7.5 mA |
| Maximum short circuit current | | 8.9 mA |
| Response time | OFF to ON | 3 ms/6 ms or less (configured in PLC parameter) ^① (Default: 6 ms) |
| | ON to OFF | |
| Time stamping | Resolution | 1 ms |
| Insulation method | Between the I/O terminals and PLC power supply | Digital isolator insulation |
| | Between I/O terminals and external power supply (24 V DC) | Photocoupler/transformer insulation |
| | Between channels | Non-insulated |
| Dielectric with-stand voltage | Between I/O terminals and programmable controller power supply | 500 V ACrms for 1 min |
| Insulation resistance | | 500 V DC 10 MΩ or higher |
| Number of occupied I/O points | | 32 points (I/O assignment: Intelligent 32 points) |
| External wiring connections | Connection system | 40-pin connector |
| | Applicable connectors | A6CON1, A6CON2, A6CON3, A6CON4 (optional) |
| | Cable specification | Shielded cable |
| | Applicable wire size | 0.3 mm ² (A6CON1 and A6CON4), 0.08–0.2 mm ² (A6CON2), 0.05 mm ² (A6CON3, single wire), 0.08 mm ² (A6CON3, stranded wire) |
| External supply power | Voltage | 24 V DC (+20%, -15%); ripple ratio within 5% |
| | Current | 0.15 A |
| | Inrush current | 5.0 A within 230 μs |
| Online module change | | Supported |
| Internal current consumption (5 VDC) | | 0.33 A |
| Weight | | 0.14 kg |

Tab. 3-3: Specifications of the ME1X16NA-Q

^① For the setting method, please refer to section 4.5.

3.2.1 Input Filter

The input signals are internally filtered to suppress any induced noise. The filter has an influence on the signal timing. This influence depends on the ON current and OFF current values of the connected NAMUR sensors.




Fig. 3-2: Distortion of input pulses

A positive pulse will be extended by the distortion time after the input filter and a negative pulse will be reduced by the distortion time. The worst case distortion time is:

Max. fall time – min. rise time = 2.5 ms

3.2.2 External Dimensions




Fig. 3-3: Dimensions of the ME1X16NA-Q

3.3 Functions of the NAMUR Input Module

| Function | Description | Reference section |
|--|--|-------------------|
| Short pulse discrimination (filtering) | Short pulses of the input signal can be eliminated. | 3.3.1 |
| Pulse stretching | Input signals can be extended to an adjustable minimum value. | 3.3.2 |
| Flutter monitoring | Fluttering input signals can be detected. | 3.3.3 |
| Events | Signal changes of an input signal or errors can be defined as an event. When an event occurs, the relevant data is stored in the ME1X16NA-Q. | 3.3.4 |

Tab. 3-4: Functions of the ME1X16NA-Q

Signal Flow




Fig. 3-4: Signal flow of the ME1X16NA-Q

3.3.1 Short Pulse Discrimination (Filtering)

The short pulse discrimination eliminates short pulses (positive or negative). The minimum allowed length for pulses is adjustable by the parameter T_0 in the range from 0 to 2 s in increments of 5 ms. If the parameter T_0 is set to 0, the function is disabled.




Fig. 3-5: Pulses shorter than the time T_0 are not recognized as changes of the input signal

The short pulse discrimination time can be set for each input in the buffer memory addresses $Un\G30$ to $Un\G45$ (refer to section 3.5.12).

3.3.2 Pulse Stretching

The pulse stretching function extends any filtered input signal pulse (positive or negative) to an adjustable minimum value (T_0). The parameter T_0 can be set in the range of 0 to 2 s in increments of 100 ms. If the parameter T_0 is set to 0, the function is disabled.




Fig. 3-6: Pulses shorter than the time T_0 are extended

The time for the minimum pulse length can be set for each input in the buffer memory addresses Un\G46 to Un\G61 (refer to section 3.5.13).

3.3.3 Flutter Monitoring

With flutter monitoring it is possible to detect fluttering signals which can be a hint for a defective sensor or a poorly adjusted target.

If a certain number of signal changes (Parameter n) or more are detected in a certain time (Parameter T_0), input signal Xn1 is turned ON, indicating a fault. Additionally a bit in the buffer memory is set which shows the faulty input. Both the input signal Xn1 and the buffer memory bit has to be reset by the application.

The parameter T_0 can be in the range from 0 to 60 s in increments of 500 ms. If the parameter T_0 is set to 0, the function is disabled.

The parameter n can be set in the range from 2 to 31.

NOTE

The parameter n stands for the number of signal changes and not for the number of pulses. One pulse of the input signal has two signal changes (OFF to ON and ON to OFF.)




Fig. 3-7: When n or more signal changes occur during the interval T_0 , flutter is recognized

The first interval T_0 is started when a slope is detected, the next interval T_0 is started with the next slope after the previous interval T_0 .

The parameters for flutter monitoring can be set for each input in the buffer memory addresses Un\G62 to Un\G77 (refer to section 3.5.14).

NOTE

If the input signal flutters for less than $2 \times T_0$ it may be not detected in some situation (refer to figure below). In order to detect short flutter signals reliably, T_0 should be as short as possible.




Fig. 3-8: Short flutter signals

3.3.4 Events

Signal changes of an input signal or errors (wire break, short circuit, flutter) can be defined as an event. In case of an event, the type of event, cause of the event etc. together with the date and time of the event is stored in an internal buffer in the ME1X16NA-Q. This buffer can store the data of up to 64 events.

The data of one event is also stored in the buffer memory of the ME1X16NA-Q, where it can be retrieved by the PLC CPU.

To indicate that there is event data in the buffer memory, a signal (Xn4) to the PLC CPU is switched ON. After reading the event data, the PLC CPU turns ON the signal "Event reset" (Yn4) to reset Xn4. If another event is pending, Xn4 turns ON again as soon as Yn4 has been turned OFF.

The internal buffer works "first in – first out". With an empty internal buffer and an empty event buffer in the buffer memory, the first event is shown in the buffer memory. Subsequent events are stored in the internal buffer. After a Xn4/Yn4 handshake, the data of the second event is moved to the buffer memory.

Please note that there is no indication of the number of events waiting in the internal buffer. In order to read the data of all events, the user has to execute the Xn4/Yn4 handshake as long as the signal Xn4 turns ON.

The events are counted in order to simplify the evaluation of their sequence.




Fig. 3-9: Example with two more events pending in the internal buffer

Time stamping

The event data also includes the date and time of the event (time stamp). This data is taken from the internal clock of the ME1X16NA-Q.

If the time stamp is not needed, setting of the internal clock is not required.

If the time stamp is evaluated, system wide consistent real-time clock (RTC) data is necessary. For this reason the PLC provides RTC data to the ME1X16NA-Q and the module continues its own time keeping with the internal clock.

To keep accuracy, the time shall be updated at least every minute. The procedure to set the clock of the ME1X16NA-Q is described in section 3.5.15.

There are several ways to acquire RTC data. The following should be seen as examples.

- Use of the internal clock of the PLC CPU

The internal clock of the PLC CPU can be set by a programming tool (GX Developer, GX IEC Developer, GX Works2) or the sequence program using a DATEWR or S(P).DATEWR instruction.

For reading the date and time out of the PLC CPU, a DATERD or S(P).DATERRD instruction can be used. The difference between these two instructions is that the S(P).DATERRD also reads the milliseconds from the clock. Since the milliseconds are required for the clock of the ME1X16NA-Q, a S(P).DATERRD should preferably be used. However, a S(P).DATERRD cannot be executed by MELSEC System Q Basic PLC CPU modules and for some of the other CPUs of the MELSEC System Q a certain function version is needed.

When the milliseconds of the time stamp are not evaluated, also a DATERD instruction can be used.

For a detailed description of these instructions, please refer to the programming manual for the MELSEC System Q and the L Series.

- Time synchronization via Ethernet

The real-time clock data is transmitted to the PLC CPU via Ethernet and then stored in the ME1X16NA-Q.

- Time synchronization using SNTP (Simple Network Time Protocol)

Using an QnUDECPU (with built-in Ethernet Port) or a MES interface module Q71MES96 the clock of the PLC CPU can be set through communications with an SNTP server computer. This enables to synchronize the time for the entire system. The clock data is then stored in the ME1X16NA-Q.

3.4 I/O Signals for the Programmable Controller CPU

3.4.1 List of I/O signals

Note that the I/O numbers (X/Y) shown in this section and thereafter depends on the mounting position resp. on the start I/O number or head address of the ME1X16NA-Q. This head address has to be added to the shown I/O numbers.

For example, if the ME1X16NA-Q occupies the range from X/Y040 to Y/X05F the head address is X/Y040. However the least significant digit is omitted and the head address "n" in this case reads as "4". The "module ready" input (Xn0) will be X40 and the "error flag" will be X4F.

NOTE

In this manual, the I/O signals of the ME1X16NA-Q for communication with the PLC CPU are designated Xn0 to Xn1F and Yn0 to Yn1F. The inputs from the NAMUR sensors are designated CH0 to CHF.

| Signal direction CPU Module ← ME1X16NA-Q | | Signal direction CPU Module → ME1X16NA-Q | |
|--|--------------------------------------|--|---------------------------------------|
| Device No. (Input) | Signal name | Device No. (Output) | Signal name |
| Xn0 | Module ready | Yn0 | Use prohibited |
| Xn1 | Flutter warning | Yn1 | Flutter warning clear request |
| Xn2 | Update real-time clock acknowledge | Yn2 | Update real-time clock |
| Xn3 | Use prohibited | Yn3 | Use prohibited |
| Xn4 | Event detection | Yn4 | Event reset |
| Xn5 | Event buffer full | Yn5 | Event buffer clear request |
| Xn6 | Use prohibited | Yn6 | Use prohibited |
| Xn7 | External 24 V ready | Yn7 | |
| Xn8 | Use prohibited | Yn8 | |
| Xn9 | Operating condition setting complete | Yn9 | Operating condition setting request |
| XnA | Use prohibited | YnA | Use prohibited |
| XnB | | YnB | |
| XnC | | YnC | |
| XnD | Wire break detection | YnD | Wire break detection clear request |
| XnE | Short circuit detection | YnE | Short circuit detection clear request |
| XnF | Error | YnF | Error clear request |
| Xn10 to Xn1F | Use prohibited | Yn10 to Yn1F | Use prohibited |

Tab. 3-5: I/O signals of the ME1X16NA-Q

NOTE



The "Use prohibited" signals cannot be used by the user since they are for system use only. If these are turned ON/OFF by the sequence program, the performance of the NAMUR input module cannot be guaranteed.

3.4.2 Details of I/O signals



Input signals

| Device No. | Signal Name | Description |
|------------|------------------------------------|---|
| Xn0 | Module ready | <ul style="list-style-type: none"> When the programmable controller CPU is powered on or reset, this signal turns on when the preparation for module operation has been completed. When the NAMUR input module has a watchdog timer error, "Module ready" (Xn0) turns OFF. |
| Xn1 | Flutter warning | <ul style="list-style-type: none"> The flutter warning turns ON when a flutter is detected on a least one input and therefore at least one bit of Un\G3 is set. To switch OFF the flutter warning (Xn1) and to clear the flutter monitor flags (Un\G3), switch the flutter warning clear request (Yn1) ON. When the flutter warning (Xn1) is OFF, switch the flutter warning clear request (Yn1) OFF. <p>Flutter monitor flags (Un\G3)</p> <p>Flutter warning (Xn1)</p> <p>Flutter warning clear request (Yn1)</p> <p>-----> Performed by the ME1X16NA-Q —————> Performed by the sequence program</p> |
| Xn2 | Update real-time clock acknowledge | <ul style="list-style-type: none"> This signal is switched ON when the signal Yn2 (update real-time clock) has been switched ON to adjust the real-time clock of the ME1X16NA-Q. Xn2 is switched OFF after Yn2 has been switched OFF (refer to section 3.5.15). |
| Xn4 | Event detection | <ul style="list-style-type: none"> The signal Xn4 is ON when an event is pending in the event buffer (Un\G11 to Un\G28, refer to section 3.5.11). To switch OFF Xn4, switch ON the signal Yn4 (Event reset). With the rising edge of Yn4, Xn4 turns OFF. After Xn4 has turned OFF, switch Yn4 OFF. If another event is pending, Xn4 turns ON again as soon as Yn4 has been turned OFF. This timing is shown in section 3.5.11. |
| Xn5 | Event buffer full | <ul style="list-style-type: none"> This signal turns ON if the internal event buffer is full. This signal turns OFF if at least one position in the internal event buffer is free. |
| Xn7 | External 24 V ready | <ul style="list-style-type: none"> This signal turns ON as soon as the external 24 V supply is available and the communication with the NAMUR input circuit is stable. This signal turns OFF when the external 24 V are not present or the communication with the NAMUR input circuit is disturbed. It is recommended to check this signal always before using any of the input values in the buffer memory addresses Un\G0 to Un\G3. |

Tab. 3-6: Detailed description of the input signals (Signal direction ME1X16NA-Q → CPU Module)

| Device No. | Signal Name | Description |
|------------|--|---|
| Xn9 | Operating condition setting completed flag | <ul style="list-style-type: none"> This signal is used as an interlock condition to turn ON/OFF the operating condition setting request (Yn9) when any of the following settings has been changed. <ul style="list-style-type: none"> Error detection settings (buffer memory address Un\G4) Event buffer enable settings (buffer memory addresses Un\G8 to Un\G10) Short pulse discrimination settings (buffer memory addresses Un\G30 to Un\G45) Pulse stretching settings (buffer memory addresses Un\G46 to Un\G61) Flutter monitoring parameters (buffer memory addresses Un\G62 to Un\G77) The operating condition setting completed flag (Xn9) turns OFF when the operating condition setting request (Yn9) is ON. To update settings, write new values into the buffer memory while Xn9 is ON, then switch Yn9 ON. <p>Xn9 will be ON until new settings are stored in the module. As soon as Xn9 is OFF, switch Yn9 OFF. After completion of the update, Xn9 will be ON again.</p>  <ul style="list-style-type: none"> Among module initialization, the parameter update procedure using the Yn9/Xn9 handshake must be performed at least once to avoid using undefined operation parameters. |
| XnD | Wire break detection | <ul style="list-style-type: none"> This signal turns ON if a wire break is detected on one or more input enabled for error detection (the according bit in Un\G4 is set, please refer to section 3.5.6). To switch OFF this signal, replace the faulty sensor(s) or deactivate the error detection for the faulty channel(s) and then switch the wire break detection clear request (YnD) ON. When XnD is OFF, switch YnD OFF.  <ul style="list-style-type: none"> Performed by the ME1X16NA-Q Performed by the sequence program |

Tab. 3-6: Detailed description of the input signals (Signal direction ME1X16NA-Q → CPU Module)

| Device No. | Signal Name | Description |
|------------|-------------------------|---|
| XnE | Short circuit detection | <ul style="list-style-type: none"> This signal turns ON if a short circuit is detected on one or more inputs enabled for error detection (the according bit in Un\G4 is set, please refer to section 3.5.6). To switch OFF this signal, replace the faulty sensor(s) or deactivate the error detection for the faulty channel(s) and then switch the short circuit detection clear request (YnE) ON. When XnE is OFF, switch YnE OFF.  <p>-----> Performed by the ME1X16NA-Q —————> Performed by the sequence program</p> |
| XnF | Error flag | <ul style="list-style-type: none"> The error flag turns ON when an error occurs. The error code is stored in buffer memory address Un\G90. To turn the error flag (XnF) OFF, remove the cause of the error and set the error clear request (YnF) to ON. When the error flag (XnF) is OFF, set the error clear request (YnF) to OFF.  <p>-----> Performed by the ME1X16NA-Q —————> Performed by the sequence program</p> |

Tab. 3-6: Detailed description of the input signals (Signal direction ME1X16NA-Q → CPU Module)

Output signals

| Device No. | Signal Name | Description |
|------------|---------------------------------------|---|
| Yn1 | Flutter warning clear request | <ul style="list-style-type: none"> • Turn ON this signal to clear a flutter warning. • For the ON/OFF timing, please refer to the entry for input Xn1 in table 3-6. |
| Yn2 | Update real-time clock | <ul style="list-style-type: none"> • Turn ON this signal after writing the clock data into the real-time clock setting register (Un\G80 to Un\G87). • Wait until Xn2 is switched ON. • Switch OFF Yn2. <p>Please refer to section 3.5.15 for a detailed description of the update sequence.</p> |
| Yn4 | Event reset | <ul style="list-style-type: none"> • This signal controls the reading process of the event buffer. • For the ON/OFF timing, please refer to the entry for input Xn4 in table 3-6. |
| Yn5 | Event buffer clear request | <ul style="list-style-type: none"> • Turn this signal ON while there are any recorded events pending (Xn4 (Event) is ON.) to clear the internal event buffer. • After the event buffer is cleared (Xn4 and in case of a full event buffer also Xn5 is switched OFF), switch this signal back to OFF. |
| Yn9 | Operating condition setting request | <ul style="list-style-type: none"> • Turn ON this signal when changing any of the following settings to make the settings valid. <ul style="list-style-type: none"> – Error detection settings (buffer memory address Un\G4) – Event buffer enable settings (buffer memory addresses Un\G8 to Un\G10) – Short pulse discrimination settings (buffer memory addresses Un\G30 to Un\G45) – Pulse stretching settings (buffer memory addresses Un\G46 to Un\G61) – Flutter monitoring parameters (buffer memory addresses Un\G62 to Un\G77) • For the ON/OFF timing, please refer to the entry for input Xn9 in table 3-6. |
| YnD | Wire break detection clear request | <ul style="list-style-type: none"> • Turn this signal ON to clear a wire break error. • For the ON/OFF timing, please refer to the entry for input XnD in table 3-6. |
| YnE | Short circuit detection clear request | <ul style="list-style-type: none"> • Turn this signal ON to clear a short circuit error. • For the ON/OFF timing, please refer to the entry for input XnE in table 3-6. |
| YnF | Error clear request | <ul style="list-style-type: none"> • Turn this signal ON to clear an error. • For the ON/OFF timing, please refer to the entry for input XnF in table 3-6. |

Tab. 3-7: Detailed description of the output signals (Signal direction CPU Module → ME1X16NA-Q)

3.5 Buffer Memory

The NAMUR input module has a memory range assigned as a buffer for temporary storage of data, such as input values or wire break flags. The PLC CPU can access this buffer and both read the stored values from it and write new values to it which the module can then process (settings for the module's functions such as short pulse discrimination times, flutter monitoring parameters, etc.).

Each buffer memory address consists of 16 bits.




Fig. 3-10: Assignments of bits to a buffer memory address

NOTE

Do not write data in the "system areas" of the buffer memory. If data is written to any of the system areas, the PLC system may not be operated properly. Some of the user areas contain partially system areas. Care must be taken when reading/writing to the buffer memory.

Also, do not write data (e.g. in a sequence program) to the buffer memory area where writing is disabled. Doing so may cause malfunction.

The "Default" value indicated in the following tables is the initial value set after the power is turned on or the PLC CPU is reset.

Instructions for data exchange with the buffer memory

Communication between the PLC CPU and the buffer memory of special function modules is performed with FROM and TO instructions.

The buffer memory of a special function module can also be accessed directly, e. g. with a MOV instruction. The special function module addressed in this way can be mounted on a base unit or an extension base unit but not in remote I/O stations.

Format of the device address: Un\Gn

- Un: Head address of the special function module
- Gn: Buffer memory address (decimal)

For example the device address U3\G11 designates the buffer memory address 11 in the special function module with the head address 3 (X/Y30 to X/Y3F).

In this User's Manual the latter form of addressing is used throughout.

For full documentation of all the instructions with examples please refer to the Programming Manual for the MELSEC System Q and the L series.

3.5.1 Buffer Memory Assignment

| Address | | Description | Default | R/W* | Reference (Section) | | |
|--------------|---------|---|---|-------|---------------------|--------|--|
| Hexa-decimal | Decimal | | | | | | |
| 0H | 0 | Filtered input values | 0000H | R | 3.5.2 | | |
| 1H | 1 | Wire break flags (Latched) | 0000H | R | 3.5.3 | | |
| 2H | 2 | Short circuit flags (Latched) | 0000H | R | 3.5.4 | | |
| 3H | 3 | Flutter monitor flags | 0000H | R | 3.5.5 | | |
| 4H | 4 | Error detection settings | 0000H | R/W | 3.5.6 | | |
| 5H | 5 | Wire break flags | 0000H | R | 3.5.7 | | |
| 6H | 6 | Short circuit flags | 0000H | R | 3.5.8 | | |
| 7H | 7 | System area | — | — | — | | |
| 8H | 8 | Event buffer enable flags | Positive edge (Input Un\G0) | 0000H | R/W | 3.5.9 | |
| 9H | 9 | | Negative edge (Input Un\G0) | 0000H | | | |
| AH | 10 | | Errors (Flutter monitor Un\G3, Wire break Un\G5, Short circuit Un\G6) | 0000H | | 3.5.10 | |
| BH | 11 | Event buffer | Status | 0000H | R | 3.5.11 | |
| CH | 12 | | Event ID (Free Running Event Counter) | | | | |
| DH | 13 | | Time-stamp | | | | Year |
| EH | 14 | | | | | | Month |
| FH | 15 | | | | | | Day |
| 10H | 16 | | | | | | Hour |
| 11H | 17 | | | | | | Minute |
| 12H | 18 | | | | | | Second |
| 13H | 19 | | | | | | Day of the week |
| 14H | 20 | | | | | | Milliseconds |
| 15H | 21 | | Event information | | | | Input number |
| 16H | 22 | | | | | | Event code |
| 17H | 23 | | Detailed buffer memory log | | | | Input trigger |
| 18H | 24 | | | | | | Filtered input values before trigger |
| 19H | 25 | | | | | | Filtered input values after trigger |
| 1AH | 26 | | | | | | Current wire break flags after trigger |
| 1BH | 27 | Current short circuit flags after trigger | | | | | |
| 1CH | 28 | Flutter monitor flags after trigger | | | | | |
| 1DH | 29 | System area | — | — | — | | |
| 1EH | 30 | Input 0 (CH0) | Short pulse discrimination time | 0000H | R/W | 3.5.12 | |
| 1FH | 31 | Input 1 (CH1) | | | | | |
| 20H | 32 | Input 2 (CH2) | | | | | |
| 21H | 33 | Input 3 (CH3) | | | | | |
| 22H | 34 | Input 4 (CH4) | | | | | |
| 23H | 35 | Input 5 (CH5) | | | | | |
| 24H | 36 | Input 6 (CH6) | | | | | |
| 25H | 37 | Input 7 (CH7) | | | | | |
| 26H | 38 | Input 8 (CH8) | | | | | |
| 27H | 39 | Input 9 (CH9) | | | | | |
| 28H | 40 | Input 10 (CHA) | | | | | |
| 29H | 41 | Input 11 (CHB) | | | | | |
| 2AH | 42 | Input 12 (CHC) | | | | | |
| 2BH | 43 | Input 13 (CHD) | | | | | |
| 2CH | 44 | Input 14 (CHE) | | | | | |
| 2DH | 45 | Input 15 (CHF) | | | | | |

Tab. 3-8: Buffer memory assignment of the ME1X16NA-Q

| Address | | Description | Default | R/W* | Reference (Section) | |
|-------------------|---------|-------------------------|-------------------|-------------------|---------------------|--------|
| Hexa-decimal | Decimal | | | | | |
| 2E _H | 46 | Input 0 (CH0) | 0000 _H | R/W | 3.5.13 | |
| 2F _H | 47 | Input 1 (CH1) | | | | |
| 30 _H | 48 | Input 2 (CH2) | | | | |
| 31 _H | 49 | Input 3 (CH3) | | | | |
| 32 _H | 50 | Input 4 (CH4) | | | | |
| 33 _H | 51 | Input 5 (CH5) | | | | |
| 34 _H | 52 | Input 6 (CH6) | | | | |
| 35 _H | 53 | Input 7 (CH7) | | | | |
| 36 _H | 54 | Input 8 (CH8) | | | | |
| 37 _H | 55 | Input 9 (CH9) | | | | |
| 38 _H | 56 | Input 10 (CHA) | | | | |
| 39 _H | 57 | Input 11 (CHB) | | | | |
| 3A _H | 58 | Input 12 (CHC) | | | | |
| 3B _H | 59 | Input 13 (CHD) | | | | |
| 3C _H | 60 | Input 14 (CHE) | | | | |
| 3D _H | 61 | Input 15 (CHF) | 0000 _H | R/W | 3.5.14 | |
| 3E _H | 62 | Input 0 (CH0) | | | | |
| 3F _H | 63 | Input 1 (CH1) | | | | |
| 40 _H | 64 | Input 2 (CH2) | | | | |
| 41 _H | 65 | Input 3 (CH3) | | | | |
| 42 _H | 66 | Input 4 (CH4) | | | | |
| 43 _H | 67 | Input 5 (CH5) | | | | |
| 44 _H | 68 | Input 6 (CH6) | | | | |
| 45 _H | 69 | Input 7 (CH7) | | | | |
| 46 _H | 70 | Input 8 (CH8) | | | | |
| 47 _H | 71 | Input 9 (CH9) | | | | |
| 48 _H | 72 | Input 10 (CHA) | | | | |
| 49 _H | 73 | Input 11 (CHB) | | | | |
| 4A _H | 74 | Input 12 (CHC) | | | | |
| 4B _H | 75 | Input 13 (CHD) | | | | |
| 4C _H | 76 | Input 14 (CHE) | | | | |
| 4D _H | 77 | Input 15 (CHF) | — | — | — | |
| 4E _H | 78 | System area | | | | |
| 4F _H | 79 | System area | | 0000 _H | R/W | 3.5.15 |
| 50 _H | 80 | Real-time clock setting | Year | | | |
| 51 _H | 81 | | Month | | | |
| 52 _H | 82 | | Day | | | |
| 53 _H | 83 | | Hour | | | |
| 54 _H | 84 | | Minute | | | |
| 55 _H | 85 | | Second | | | |
| 56 _H | 86 | | Day of the week | | | |
| 57 _H | 87 | Millisecond | | | | |
| 58 _H | 88 | System area | | — | — | — |
| 59 _H | 89 | System area | | | | |
| 5A _H | 90 | Error Code | | 0000 _H | R/W | 3.5.16 |
| 5B _H | 91 | System area | | | | |
| | to | System area | | | | |
| 7FFF _H | 32767 | System area | | — | — | — |

Tab. 3-8: Buffer memory assignment of the ME1X16NA-Q

* Indicates whether reading from and writing to a sequence program are enabled.
R : Read enabled
W : Write enabled

3.5.2 Filtered Input Values (Un\G0)

When after all filtering an input signal is "1", the respective bit in the buffer memory address Un\G0 is set to 1.




Fig. 3-11: Assignment of the bits in buffer memory address 0

Example ▾

When the inputs CHC, CH6, CH1 and CH0 have a "1"-input signal, 1043H (4163) is stored into buffer memory address 0 (Un\G0).




Fig. 3-12: In this example the inputs CHC, CH6, CH1 and CH0 are switched ON



3.5.3 Latched Wire Break Flags (Un\G1)

- When a wire break is detected for an input activated for error detection, the respective bit in the buffer memory address Un\G1 is set to 1.
- When the wire break condition is gone, the bit will remain set until completion of the wire break detection clear request process using XnD/YnD signals.
- The respective bit in Un\G0 (filtered input value) is set to 0 as long as the input is within wire break condition.




Fig. 3-13: Assignment of the bits in buffer memory address 1

Example ▾ When there is a wire break on CH8, 0100H (256) is stored into buffer memory address 1 (Un\G1).




Fig. 3-14: In this example a broken wire is detected for input CH8



3.5.4 Latched Short Circuit Flags (Un\G2)

- When a short circuit is detected for an input activated for error detection, the respective bit in the buffer memory address Un\G2 is set to 1.
- When the short circuit condition is gone, the bit will remain set until completion of the short circuit detection clear request process using XnE/YnE signals.
- The respective bit in Un\G0 (filtered input value) is set to 0 as long as the input is within short circuit condition.




Fig. 3-15: Assignment of the bits in buffer memory address 2

Example ▾ When there is a short circuit on CHA, 0400H (1024) is stored into buffer memory address 2 (Un\G2).




Fig. 3-16: In this example a short circuit is detected for input CHA



3.5.5 Flutter Monitor Flags (Un\G3)

- When fluttering is detected for an input with activated flutter monitoring function, the respective bit in the buffer memory address Un\G3 is set to 1.
- For information how to activate the flutter monitoring function for a certain input, please refer to section 3.3.3.
- When at least one flutter monitoring flag in Un\G3 is 1, the signal Xn1 is switched ON (section 3.4.)
- The flags are reset by the signal Yn1 (Flutter warning clear request) only.




Fig. 3-17: Assignment of the bits in buffer memory address 3

Example ▽

When input CH5 shows fluttering, 0020H (32) is stored into the buffer memory address 3 (Un\G3).




Fig. 3-18: In this example flutter is detected for input CH5



3.5.6 Error Detection Settings (Un\G4)

- To enable wire break and short circuit detection for a certain input, set the according bit in Un\G4 to 1.
- Any changes will not take effect until the new value is committed by using the Yn9/Xn9 handshake procedure (refer to section 3.4.2).
- An input not activated for error detection will not have its wire break or short circuit bit set in case of an error (but the respective input value bit will still be set to 0 during error condition) nor will it influence the Signals XnD and XnE.
- This is to avoid continuous error detection if not all 16 NAMUR channels are used. It is recommended to enable error detection for each used NAMUR channel.




Fig. 3-19: Assignment of the bits in buffer memory address 4

Example ▾

To enable error detection for NAMUR channels 0 to 5, store 003FH (63) in the buffer memory address 4 (Un\G4)




Fig. 3-20: In this example error detection is enabled for the inputs CH0 to CH5



3.5.7 Wire Break Flags (Un\G5)

- As long as an input enabled for error detection is in a wire break condition, the respective bit in the buffer memory address Un\G5 is set to 1.
- When the NAMUR input circuit detects that the wire break condition is gone, the respective bit will be reset to 0. No wire break detection clear request process using YnD/XnD signals is required.




Fig. 3-21: Assignment of the bits in buffer memory address 5

Example ▾

As long as the inputs CH0 to CH5 are enabled for error detection and when there is a wire break on the inputs CH1 and CH4, the value 0012H (18) is stored in the buffer memory address 5 (Un\G5).




Fig. 3-22: In this example a broken wire is detected for the inputs CH1 and CH4.



3.5.8 Short Circuit Flags (Un\G6)

- As long as an input enabled for error detection is in a short circuit condition, the respective bit in the buffer memory address Un\G6 is set to 1.
- When the NAMUR input circuit detects that the short circuit condition is gone, the respective flags will be reset to 0. No short circuit detection clear request process using XnE/YnE signals is required.




Fig. 3-23: Assignment of the bits in buffer memory address 6

Example ▾

As long as the inputs CH0 to CH5 are enabled for error detection and when there is a short circuit on input CH3, 0008H (8) is stored into buffer memory address 6 (Un\G6).




Fig. 3-24: In this example a short circuit is detected for input CH3



3.5.9

Event Buffer Enable Settings (Positive Edge (Un\G8), negative Edge (Un\G9))

- The inputs in Un\G0 can trigger an event in the moment they are switched ON or OFF. This is enabled in the buffer memory addresses 8 (Un\G8) and 9 (Un\G9).
- To trigger an event when the respective input is switched ON, enable the event in Un\G8 (positive edge).
- If you want to trigger an event when the respective input is switched OFF, enable the event in Un\G9 (negative edge).
- Any changes in Un\G8 and Un\G9 will not take effect until the new value is committed by using the Yn9/Xn9 handshake procedure (refer to section 3.4.2).




Fig. 3-25: Assignment of the bits in the buffer memory addresses 8 and 9

Example ▾

A positive edge on Input CH0 or CH5 (Un\G0.0 or Un\G0.5) triggers an event if 0021H (33) is stored into the buffer memory address 8 (Un\G8).




Fig. 3-26: An event is triggered when the input CH0 or the input CH5 is switched ON



Example ▾ If 0022H (34) is stored into the buffer memory address 9 (Un\G9), a negative edge on Input CH1 or CH5 triggers an event.




Fig. 3-27: An event is triggered when either of the inputs CH1 or CH5 is switched OFF



3.5.10 Event Buffer Enable Settings (Errors) (Un\G10)

- A wire break, short circuit or signal fluttering error (positive edge in Un\G5, Un\G6 or Un\G3) on the selected inputs in Un\G10 will trigger an event.

NOTE

Each signal flutter error will generate a new error event even if the Flutter Monitor Flags in Un\G3 are not cleared.

- Any changes in Un\G10 will not take effect until the new value is committed by using the Yn9/ Xn9 handshake procedure (refer to section 3.4.2).




Fig. 3-28: Assignment of the bits in the buffer memory address 10

Example ▾ An error on input CH0, CH1 or CH5 triggers an event if 0023H (35) is stored into the buffer memory address 10 (Un\G10).




Fig. 3-29: An event is triggered when an error is detected for one of the inputs CH0, CH1 or CH5



3.5.11 Event Buffer (Un\G11 to Un\G28)

The event buffer logs the changes of the inputs and respective errors. By evaluating the event buffer, it is possible to track sequences of switching events.

- Only those inputs enabled in the Event Buffer Enable Settings (Un\G8, Un\G9 and Un\G10) can trigger an event.
- The module has an internal buffer for 64 events. The sequence program has to read out the events to empty the internal buffer.
- If the internal event buffer is full, new events will not be recorded.
- The event buffer works "first in – first out".

Status (Un\G11)

In the buffer memory address Un\G11 the status of an event record is stored.

| Status | Meaning |
|--------|---|
| 0000H | Valid event |
| 0011H | First recorded event since the real-time clock was adjusted within the last second. |
| Other | Not used |

Tab. 3-9: Status codes in Un\G11

Event ID (Free Running Event Counter) (Un\G12)

The event counter is incremented with every event, even if the event buffer is full and the event can not be recorded. This allows to detect missed events in case the event buffer is full.

Time-stamp (Un\G13 to Un\G20)

The time-stamp indicates the date and time the event has happened. The clock data is read from the internal clock of the ME1X16NA-Q and stored in binary format in the buffer memory addresses listed below:

| | |
|-------------------------|--|
| Un\G13: Year | (1980 to 2079, The "Year" is stored as four-digit indication.) |
| Un\G14: Month | (1 to 12) |
| Un\G15: Day | (1 to 31) |
| Un\G16: Hour | (24-hour clock, 0 to 23) |
| Un\G17: Minute | (0 to 59) |
| Un\G18: Second | (0 to 59) |
| Un\G19: Day of the week | (0 to 6, 0: Sunday, 1: Monday, 2: Tuesday ... 6: Saturday) |
| Un\G20: Milliseconds | (0 to 999) |

The format, the order of data and the data ranges are identical to the S(P).DATERD instruction.

Example ▾

If an event was triggered on Monday, 24th December 2012 at 10:57:39 and 530 ms.




Fig. 3-30: Storage of date and time



Input number (Un\G21), input trigger (Un\G23)

The input trigger register shows which input triggered the event. When several inputs generate an event within 1 ms, a separate event is stored in the event buffer for each input, starting with input 0. Those events have the same time stamp.*

In addition, the input number register (Un\G21) shows the decimal number of the input that triggered the event.

* If for example both inputs CH5 and CH0 trigger an event within 1 ms, separate events are generated for CH0 first and then CH5 with the same time stamp.

Example ▾

If 0020H (32) is stored in the input trigger register (Un\G23), input CH5 has triggered the event.




Fig. 3-31: The contents of Un\G23 indicates that the event was triggered by input CH5

In addition, the decimal channel number 5 will be stored in the input number register (Un\G21).




Fig. 3-32: Un\G21 shows the number of the input



Event code (Un\G22)

The event code shows the type of event recorded for the input.

| Event code | Type of event |
|------------|---|
| F001H | Wire break |
| F002H | Short circuit |
| F004H | Signal flutter |
| F008H | Positive edge |
| F00CH | Combined positive edge and signal flutter |
| F010H | Negative edge |
| F011H | Combined negative edge and wire break |
| F012H | Combined negative edge and short circuit |
| F014H | Combined negative edge and signal flutter |
| Other | Not used |

Tab. 3-10: Event codes in buffer memory address Un\G22

Sequence to read out the event buffer

- ① Make sure the signal Yn4 (Reset event) is OFF and wait until the signal Xn4 (Event) is switched ON.
- ② Read out the event buffer (Un\G11 to Un\G28).
- ③ Switch Yn4 (Reset event) ON and wait until the signal Xn4 (Event) is switched OFF.
- ④ Switch Yn4 (Reset event) OFF.
- ⑤ Continue with Step ①.




Fig. 3-33: Reading of the event buffer

3.5.12 Short Pulse Discrimination Time CH□ (Un\G30 to Un\G45)

- For each input of the module a buffer memory address to adjust the short pulse discrimination time (section 3.3.1) is provided.
- The time can be adjusted from 0 to 2 s in 5 ms steps.
Set time = Set value × 5 ms (setting range 0 to 400)
For example, the set value 400 (190H) means 400 × 5 ms = 2000 ms = 2 s
- If the set value is outside the allowed range, an error will occur.
- If the time is set to 0, the function is disabled for the respective input.
- Any changes in the area Un\G30 to Un\G45 will not take effect until the new value is committed by using the Yn9/Xn9 handshake procedure (refer to section 3.4.2)

Example ▾

To set input CH3 to a short pulse discrimination time of 500 ms, 64H (100) is written into Un\G33.




Fig. 3-34: Setting of a short pulse discrimination time of 500 ms in Un\G33 for input CH3



3.5.13 Pulse Stretching Time CH□ (Un\G46 to Un\G61)

- The pulse stretching time (section 3.3.2) of each input can be adjusted in the buffer memory.
- The time can be adjusted from 0 to 2 s in 100 ms steps.
Set time = Set value × 100 ms (setting range 0 to 20)
For example, the set value 20 (14H) means 20 × 100 ms = 2000 ms = 2 s
- If the set value is outside the allowed range, an error will occur.
- If the time is set to 0, the function is disabled for the respective input.
- Any changes in the area Un\G46 to Un\G61 will not take effect until the new value is committed by using the Yn9/Xn9 handshake procedure (refer to section 3.4.2).

Example ▾

To set input CH3 to a pulse stretching time of 500 ms, 5H (5) is written into Un\G49.




Fig. 3-35: Setting of a pulse stretching time of 500 ms in Un\G49 for input CH3



3.5.14 Flutter Monitoring Parameters CH□ (Un\G62 to Un\G77)

- Using flutter monitoring it is possible to detect fluttering signals (refer to section 3.3.3).
- For each input of the module, the time of the flutter monitoring window and the maximum allowed number of signal changes can be set in the buffer memory.




Fig. 3-36: Assignment of the buffer memory addresses 62 to 77

- The window time can be adjusted from 0 to 60 s in 500 ms steps.
Set time = Set value × 500 ms (setting range 0 to 120)
For example, the set value 120 (79H) means 120 × 500 ms = 60000 ms = 60 s
- The setting range for the maximum allowed number of signal changes is 2 to 31.
- If any value outside the setting range is set, an error occurs and the corresponding error code is stored in buffer memory address Un\G90.
- If the window time is set 0, the function is disabled for the respective input.
- Any changes in the buffer memory addresses Un\G62 to Un\G77 will not take effect until the new value is committed by using the Yn9/Xn9 handshake procedure (refer to section 3.4.2).

Example ▾

To set input CH4 to a 10 s window and a maximum of 6 signal changes, 0614H (5126) is written into Un\G66. (The set value for a flutter monitoring window of 10 s is 20 (14H).)




Fig. 3-37: The flutter monitoring parameters for input CH4 are set in Un\G66



3.5.15 Real-Time Clock Setting (Un\G80 to Un\G87)

- Data for setting the internal clock of the ME1X16NA-Q is stored in the buffer memory addresses Un\G80 to Un\G87.
- To keep accuracy, the time shall be updated at least every minute.
- For best accuracy, make sure to run the following process as fast as possible with no additional delays (I/Os normally are refreshed by the execution of the END instruction. In order to avoid delays caused by the cycle time, specify direct access I/Os (DXn2, DYn2).)
- The procedure to set the RTC data of the module is as follows:

- ① Make sure the signal Yn2 (Update real-time clock) is OFF.
- ② Get the clock data.

When using the internal clock of the PLC CPU, execute a S(P).DATERD instruction to read the clock data out of the PLC CPU (Please note that the S(P).DATERD instruction reads the data including the milliseconds whereas the DATERD instruction does not read the milliseconds.)

- ③ Move the clock data into Un\G80 to Un\G87 (Copy the result of the S(P).DATERD instruction into these buffer memory addresses.)
- ④ Switch the signal Yn2 (Update real-time clock) ON.
- ⑤ Wait Xn2 (Update real-time clock acknowledge) to become ON.
- ⑥ Switch the signal Yn2 (Update real-time clock) OFF.




Fig. 3-38: Updating of the real time clock

- After the RTC has been updated, the first event within one second after the update will have its event status set to 0011H to indicate that the RTC has been adjusted.
- The data in the buffer memory addresses Un\G80 to Un\G87 has the same format as delivered by the S(P).DATERD instruction:

Un\G80: Year (1980 to 2079)
 Un\G81: Month (1 to 12)
 Un\G82: Day (1 to 31)
 Un\G83: Hour (24-hour clock, 0 to 23)
 Un\G84: Minute (0 to 59)
 Un\G85: Second (0 to 59)
 Un\G86: Day of the week (0 to 6, 0: Sunday, 1: Monday, 2: Tuesday ... 6: Saturday)
 Un\G87: Milliseconds (0 to 999)

Example ▽

The clock is set to Friday, 19th October 2012; 09:48:14 and 257 ms.




Fig. 3-39: Storage of date and time



3.5.16 Error Code (Un\G90)

- If an error occurs (In this case the signal XnF is ON), the error code is stored in the buffer memory address Un\G90.
- For more details of the error codes, please refer to section 6.1. Errors can be caused e.g. by the values in Un\G30 to Un\G77.
- If two or more errors have occurred, the latest error found by the module is stored.
- The error code can be cleared by turning ON the error clear request (YnF).

Example ▽

If the value in Un\G33 is set to 401 (allowed is a maximum of 400) and the Yn9/Xn9 handshake is performed, an error will occur. The error code 33 (21H) is stored in Un\G90.




Fig. 3-40: The error code 33 means that the setting in the buffer memory address Un\G33 is not correct



4 Setup and Procedures before Operation

4.1 Handling Precautions

- Do not drop the module or subject it to heavy impact.
- Do not remove the PCB of the module from its case. Doing so may cause the module to fail.
- Prevent foreign matter such as dust or wire chips from entering the module. Such foreign matter can cause a fire, failure, or malfunction.
- Before handling the module, touch a grounded metal object to discharge the static electricity from the human body.

Failure to do so may cause the module to fail or malfunction.

- Tighten the module fixing screw within the following range. A loose screw may cause short circuits, failures, or malfunctions.

| Screw location | Tightening torque range |
|--|-------------------------|
| Module fixing screw (M3 screw, optional) | 0.36 to 0.48 Nm |

Tab. 4-1: Tightening torque

- To mount the module on the base unit, fully insert the module fixing latch into the fixing hole in the base unit and press the module using the hole as a fulcrum.

Improper installation may result in a module malfunction, or may cause the module to fall off.

4.2 Setup and Procedures before Operation




Fig. 4-1: Function chart for the setup of the NAMUR input module

4.3 Installation of the Module

The ME1X16NA-Q can be combined with a CPU module or, when mounted to a remote I/O station, with a master module for MELSECNET/H (refer to section 2.1).



CAUTION:

- **Cut off all phases of the power source externally before starting the installation or wiring work.**
- **Always insert the module fixing latch of the module into the module fixing hole of the base unit. Forcing the hook into the hole will damage the module connector and module.**
- **Do not touch the conductive parts of the module directly.**

- ① After switching of the power supply, insert the module fixing latch into the module fixing hole of the base unit.
- ② Push the module in the direction of the arrow to load it into the base unit.




Fig. 4-2: Module installation

- ③ Secure the module with an additional screw (M3 × 12) to the base unit if large vibration is expected. This screw is not supplied with the module.

4.4 Wiring

4.4.1 Wiring Precautions

Please observe the following precautions for external wiring:

- Always confirm the terminal layout before connecting the wires to the ME1X16NA-Q.
(For the signal layout of the connector please refer to section 3.1.1)
- Correctly solder the external wiring connector. An incomplete soldering could lead to malfunctioning.
- Make sure that foreign matter such as cutting chips and wire scraps does not enter the ME1X16NA-Q. Failure to observe this could lead to fires, faults or malfunctioning.
- A protective label is attached on the top of the ME1X16NA-Q to avoid foreign matter such as wire scraps from entering inside during wiring process. Do not remove the label until the wiring is completed. Before starting the system, however, be sure to remove the label to ensure heat radiation.
- Securely mount the external device connector to the connector on the ME1X16NA-Q with two screws.
- Do not disconnect the external wiring cable connected to the ME1X16NA-Q by pulling the cable section. When the cable has a connector, be sure to hold the connector connected to the ME1X16NA-Q. Pulling the cable while it is connected to the ME1X16NA-Q may lead to malfunctioning or damage of the ME1X16NA-Q or cable.
- Do not bundle or adjacently lay the connection cable connected to the ME1X16NA-Q external I/O signals with the main circuit line, power line, or the load line other than that for the PLC. Separate these by 100 mm as a guide. Failure to observe this could lead to malfunctioning caused by noise, surge, or induction.
- If the shielded cable is not secure, unevenness or movement of the shielded cable or careless pulling on it could result in damage to the ME1X16NA-Q or shielded cable or defective cable connections could cause misoperation of the unit.
- If the cable connected to the ME1X16NA-Q and the power line must be adjacently laid (less than 100 mm), use a shielded cable. Ground the shield of the cable securely to the control panel on the ME1X16NA-Q side. (A wiring example is given below.)
 - Wiring example of shielded cable.




Fig. 4-3: Wiring example for noise reduction (in this case a connector A6CON1 is used)

Preparation of the connector




Fig. 4-4: Connection of a FG wire to each shielded cable

Assembling of the connector




Fig. 4-5: Assembling of the connector (A6CON1)

- To make this product conform to the EMC and Low Voltage Directive, be sure to use a AD75CK type cable clamp (manufactured by Mitsubishi Electric) for grounding to the control box.




Fig. 4-6: Grounding of a shielded cable using a AD75CK cable clamp




Fig. 4-7: Mounting of a AD75CK cable clamp

Using the AD75CK, you can tie four cables of about 7 mm outside diameter together for grounding.

- The influence of noise may be reduced by installing ferrite cores to the cable connected to the ME1X16NA-Q as a noise reduction technique.
- Even if compliance with the EMC directive is not required, the influence of external noise may be reduced by making the configuration compliant with the EMC directive.

4.4.2 External Wiring

Up to 16 NAMUR sensors can be connected to one ME1X16NA-Q. For connection, a 40-pin connector is used (refer to section 3.1.1).

Applicable cables


For best noise immunity, use shielded cable for the sensors. Ground the shield as described in the previous section 4.4.1.

External power supply

For operation of the ME1X16NA-Q, an external power supply of 24 V DC (+20%, -15%, which gives a voltage range of 20.4 to 28.8 V DC), is required.

Connect the external 24 V power to the pins 24V and 24G of the connector. One pole of the external power may be connected to earth.

Connection of the external wiring



WARNING:

- Leave the "vacant" pins unconnected.
- Do not connect any voltage to a DI□ or VS□ pin.




Fig. 4-8: External wiring of the ME1X16NA-Q

4.5 PLC Parameter Setting

In the PLC parameters the I/O assignment for the ME1X16NA-Q, the HOLD/CLEAR function and the fast conversion function are set.

4.5.1 I/O Assignment

Start GX Developer, GX IEC Developer or GX Works2 and open up the project with the ME1X16NA-Q. After the selection of **Parameter** in the Project Navigator Window, double click on **PLC parameter**. The Q parameter setting window will appear. Click on the **I/O assignment** tab.




Fig. 4-9: I/O assignment setting screen

Set the following for the slot in which the ME1X16NA-Q is mounted:

Type: Select "Intelli."

Model name: ME1X16NA-Q (Entering of the module model name is optional. The entry is used for documentation only and has no effect on the function of the module.)

Points: Select 32 points.

StartXY: Start I/O number for the ME1X16NA-Q. (Assigning of the I/O address is not necessary as the address is automatically assigned by the PLC CPU.)

4.5.2 Intelligent Function Module Switch Settings

The HOLD/CLEAR setting and the Fast conversion mode for each input of the ME1X16NA-Q is selected by "switches" in the PLC parameters. There are no switches at the module itself.

HOLD/CLEAR function

When the internal communication is not stable or when there is no communication (e.g. the external 24 V are not present and the NAMUR circuit is not supplied), depending on the switch 3 settings the filtered input values in Un\G0 are reset to 0 (CLEAR) or latched (HOLD) until the communication is restored.

The wire break and short circuit flags in Un\G1 and Un\G2 are latched in any case until they are reset by error clear request using XnD/YnD and XnE/YnE signals.

Fast conversion mode

Since the NAMUR input circuit uses an analog low-pass filter with a time constant of 0.6 ms to improve signal quality, any change of the analog input value takes some time to load the filter capacitor. This leads to transient states when switching immediately from one state to another. For example, changing directly from wire break to short circuit will pass through 0-state and 1-state even though those states are not signalled by the sensor. To avoid this, all input values are delayed for 3 milliseconds to perform a consistency check.

This delay can be skipped by using fast conversion mode to reduce the time between an input signal change and the new module output by 3 ms, but in that case an output of the transient states described above may occur.

Switch 5 is used to enable or disable the fast conversion mode.

Setting the switches

The intelligent function module switches are set using 16 bit data (4 hexadecimal digits).




Fig. 4-10: Bit assignment for one switch

In the I/O assignment setting screen (section 4.5.1) click on **Switch setting** to display the screen shown below, then set the switches as required. The switches can easily be set if values are entered in hexadecimal. Change the entry format to hexadecimal and then enter the values.






Fig. 4-11: Switch setting for intelligent function module screen

When the intelligent function module switches are not set, the default value for switches 1 to 5 is 0000H.

| Switch | Setting item | |
|----------|--|---|
| Switch 1 | Reserved | Fixed to 0H |
| Switch 2 | Reserved | |
| Switch 3 | HOLD/CLEAR function setting (CH0 to CHF) b15 b6 b5 b4 b3 b2 b1 b0  CHF CH6 CH5 CH4 CH3 CH2 CH1 CH0 | |
| Switch 4 | Reserved | Fixed to 0H |
| Switch 5 | Fast conversion mode (CH0 to CHF) b15 b6 b5 b4 b3 b2 b1 b0  CHF CH6 CH5 CH4 CH3 CH2 CH1 CH0 | |
| | | Fast conversion for inputs CH0 to CHF 0: Fast conversion mode for according NAMUR input disabled (default setting); additional output delay of 3 ms. 1: Fast conversion mode for according NAMUR input enabled; no additional output delay. |

Tab. 4-2: Switch settings for the ME1X16NA-Q

● Setting example:

The configuration shown below is used for the setting example.

| Function | | Input | | | | | | | | | | | | | | | | | |
|-----------------------------|--------------|-------|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|
| | | CHF | CH6 | CH5 | CH4 | CH3 | CH2 | CH1 | CH0 | CH9 | CH8 | CH7 | CH6 | CH5 | CH4 | CH3 | CH2 | CH1 | CH0 |
| HOLD/CLEAR function setting | CLEAR (0) | ● | ● | ● | | ● | ● | ● | | ● | ● | | | | | ● | ● | ● | |
| | HOLD (1) | | | | ● | | | | ● | | | ● | ● | ● | ● | | | | |
| Fast conversion mode | Disabled (0) | | | | | ● | ● | ● | | ● | ● | ● | ● | ● | ● | ● | ● | | |
| | Enabled (1) | ● | ● | ● | ● | | | | ● | | | | | | | | | ● | ● |

Tab. 4-3: HOLD/CLEAR settings and Fast conversion mode for this example

- Setting value for switch 1: 0000H (fixed)
- Setting value for switch 2: 0000H (fixed)
- Setting value for switch 3 (HOLD/CLEAR): 0001 0001 0011 1000 = 1138H
- Setting value for switch 4: 0000H (fixed)
- Setting value for switch 5 (Fast conversion): 1111 0001 0000 0011 = F103H

5 Programming

This chapter describes the programming of the NAMUR input module ME1X16NA-Q.

NOTE When applying any of the program examples introduced in this chapter to the actual system, verify the applicability and confirm that no problems will occur in the system control.

5.1 Programming Procedure

Create a program that will execute the initial setting of the ME1X16NA-Q, the reading of input values and the error handling in the following procedure.




Fig. 5-1: Programming procedure for the ME1X16NA-Q (1)




Fig. 5-2: Programming procedure for the ME1X16NA-Q (2)

5.2 Example 1: Reading of Input Values and Error Handling

This program example reads the input values from the ME1X16NA-Q and responds to sensor errors as well as module errors.

The following figure shows the system configuration used for this example. Eight NAMUR sensors are connected to a ME1X16NA-Q.




Fig. 5-3: In this example eight NAMUR sensors are connected to the ME1X16NA-Q

| Input | HOLD/CLEAR function setting | Fast conversion mode |
|------------|-----------------------------|----------------------|
| CH0 to CH7 | CLEAR | Disabled |
| CH8 to CHF | — | — |

Tab. 5-1: Conditions for the intelligent function module switch setting

Program conditions

- The input values from the NAMUR sensors are stored in the internal relays M100 to M115.
- Error detection is enabled for all connected sensors.
 - In case of a wire break or short circuit processing for the error is performed.
- In case of a module error the error code is read and stored in the PLC CPU.

5.2.1 Before Creating a Program

Wiring of external devices

Mount the ME1X16NA-Q on the base unit and connect the external power supply and the NAMUR sensors. For details, refer to section 4.4.

Intelligent function module switch setting

Based on the setting conditions given on the previous page, perform the switch settings for the intelligent function module in the PLC parameters.

Since by default the HOLD/CLEAR setting is set to CLEAR and the fast conversion mode is disabled, no setting is necessary when a brand-new module is used. For a module used before in an other application, checking and setting of the switches is required.

Based on the setting conditions given previously, perform the intelligent function module switch settings.




Fig. 5-4: Setting of the switches 1 to 5 for this example

On the **Parameter setting** screen of GX Developer, GX IEC Developer or GX Works2, select the **I/O assignment** tab, click **Switch setting**, and make settings of the switches 1 to 5 as on the screen shown below (for details about the setting, refer to section 4.5.2).




Fig. 5-5: Switch setting for this example

5.2.2 Program

For a full documentation of the instructions used with the examples please refer to the Programming Manual for the MELSEC System Q and the MELSEC-L series.

● Used Devices

| Device | Function | Remark | |
|-----------------|--------------|---------------------------------------|---|
| Inputs | X0 | Module ready | ME1X16NA-Q (X0 to X1F) |
| | X7 | External 24 V ready | |
| | X9 | Operating condition setting complete | |
| | XD | Wire break detection | |
| | XE | Short circuit detection | |
| | XF | Error flag | |
| Outputs | Y9 | Operating condition setting request | ME1X16NA-Q (Y0 to Y1F) |
| | YD | Wire break detection clear request | |
| | YE | Short circuit detection clear request | |
| | YF | Error clear request | |
| Internal relays | M10 | Wire break reset signal | --- |
| | M11 | Short circuit reset signal | --- |
| | M12 | Module error reset signal | --- |
| | M100 to M115 | Input value CH0 to CHF | Input values of all sensors are stored in M110 (CH0) to M115 (CHF). |
| | M120 to M135 | Wire break NAMUR sensor CH0 to CHF | The wire break detection flags for all sensors are stored in M120 (CH0) to M135 (CHF). |
| | M140 to M155 | Short circuit NAMUR sensor CH0 to CHF | The short circuit detection flags for all sensors are stored in M140 (CH0) to M155 (CHF). |
| Register | D100 | Error code | Error code of the ME1X16NA-Q. |

Tab. 5-2: List of used devices

● Initial settings




Fig. 5-6: The initial settings are performed once when X0 (Module ready) turns on

| Number | Description |
|--------|--|
| ① | Error (wire break and short circuit) detection enable/disable setting (CH0 to CH7: enable) |
| ② | The operation condition setting request (Y9) is turned ON. |
| ③ | When the setting is completed, the operation condition setting request is turned OFF. |

Tab. 5-3: Description of the program for the initial settings

● Reading of the input values, wire break detection flags and short circuit detection flags




Fig. 5-7: The input values are copied into internal relays

| Number | Description |
|--------|---|
| ① | The input values are moved to the internal relays M100 to M115 for further processing in the program. |
| ② | The wire breaks flags are moved to the internal relays M120 to M135. |
| ③ | The short circuit flags are moved to the internal relays M140 to M155. |

Tab. 5-4: Description of the program shown on the previous page

● Processing at wire break detection and wire break detection clear request




Fig. 5-8: Program part for wire break processing

| Number | Description | |
|--------|--|--------------------------|
| ① | Processing for input CH0 | |
| ② | Processing for input CH1 | |
| ③ | When the module detects a wire break on at least one input, XD is switched ON. In case of a wire break, separate processing is performed for each input (e.g. issue of an alarm message, locking of the input in the program because the input value is set to "0" in this case, etc.). | |
| ④ | | Processing for input CH2 |
| ⑤ | | Processing for input CH3 |
| ⑥ | | Processing for input CH4 |
| ⑦ | | Processing for input CH5 |
| ⑧ | | Processing for input CH6 |
| ⑨ | | Processing for input CH7 |

Tab. 5-5: Description of the program shown above

| Number | Description |
|--------|--|
| ⑨ | When M10 (Wire break reset signal) is set while the wire break detection signal is ON, the wire break detection clear request (YD) is turned ON. |
| ⑩ | When there is no wire break indicated, the wire break detection clear request (YD) is turned OFF. |

Tab. 5-5: Description of the program shown above

● Processing at short circuit detection and short circuit detection clear request




Fig. 5-9: Program part for short circuit processing

| Number | Description | |
|--------|--|--------------------------|
| ① | When the module detects a short circuit on at least one input, XE is switched ON. In case of a short circuit, separate processing is performed for each input (e.g. issue of an alarm message, locking of the input in the program because the input value is set to "0" in this case, etc.). | Processing for input CH0 |
| ② | | Processing for input CH1 |
| ③ | | Processing for input CH2 |
| ④ | | Processing for input CH3 |
| ⑤ | | Processing for input CH4 |
| ⑥ | | Processing for input CH5 |
| ⑦ | | Processing for input CH6 |
| ⑧ | | Processing for input CH7 |
| ⑨ | When M11 (Short circuit reset signal) is set while the short circuit detection signal is ON, the short circuit detection clear request (YE) is turned ON. | |
| ⑩ | When there is no short circuit indicated, the short circuit detection clear request (YE) is turned OFF. | |

Tab. 5-6: Description of the program shown above

● Module error detection




Fig. 5-10: Module error detection and handling

| Number | Description |
|--------|--|
| ① | In case of an error the error code is stored in D100. |
| ② | When an error has been detected and the reset signal (M12) is set to "1", the error clear request (YF) is set. |
| ③ | When there is no error indicated, the error clear request (YF) is turned OFF. |

Tab. 5-7: Description of the program shown above

5.3 Example 2: Signal Conditioning

In addition to the program shown in the previous section, in this program example some of the input signals are conditioned (elimination of short pulses, pulse stretching) and for one input the flutter monitoring function is used.

System configuration

In this example eight sensors are connected to a ME1X16NA-Q. The same system configuration as for example 1 is used (refer to section 5.2).

Program conditions

- The input values from the NAMUR sensors are stored in the internal relays M100 to M115.
- Error detection is enabled for all connected sensors.
 - In case of a wire break or short circuit processing for the error is performed.
- In case of a module error the error code is read and stored in the PLC CPU.
- Short pulses on the inputs CH0 and CH2 are eliminated.
 - The minimum allowed pulse length for CH0 is 1.4 seconds.
 - The minimum allowed pulse length for CH2 is 0.8 seconds.
- Pulses on the input CH5 are extended to a minimum length of 1.5 seconds.
- For input CH6 the flutter monitoring function is activated. Eight or more signal changes in 2 seconds are recognized as flutter.

5.3.1 Before Creating a Program

Before creating the program, perform the steps described in section 5.3.1.

| Number | Description | |
|--------|--|---|
| ① | Error (wire break and short circuit) detection enable/disable setting (CH0 to CH7: enable) | |
| ② | Short pulse discrimination time setting | Input CH0: 1.4 s = 1400 ms = 280 × 5 ms → The value 280 is stored in Un\G30. |
| ③ | | Input CH2: 0.8 s = 800 ms = 160 × 5 ms → The value 160 is stored in Un\G32. |
| ④ | Pulse stretching time setting for input CH5: 1.5 s = 1500 ms = 15 × 100 ms → The value 15 is stored in Un\G51. | |
| ⑤ | Setting of flutter monitoring parameters for input CH6 (n = 8, t = 2 s = 4 × 500 ms → The value 0804H is stored in Un\G68.) | |
| ⑥ | The operation condition setting request (Y9) is turned ON. | |
| ⑦ | When the setting is completed, the operation condition setting request is turned OFF. | |

Tab. 5-9: Description of the program for the initial settings

- Reading of input values, wire break detection flags, short circuit detection flags and error processing

The processing is the same as performed for example 1. (Please refer to section 5.2.2.)

- Flutter monitoring




Fig. 5-12: Flutter detection and handling

| Number | Description |
|--------|--|
| ① | When flutter is detected for input CH6, bit 6 is set in Un\G3. |
| ② | M13 is used to switch the flutter warning clear request (Y1) ON. |
| ③ | When there is no more flutter warning, the flutter warning clear request (Y1) is turned OFF. |

Tab. 5-10: Description of the program shown above

6 Troubleshooting

The following section explains the types of errors that may occur when the NAMUR input module ME1X16NA-Q is used, and how to troubleshoot such errors.

6.1 Error Code List

If an error occurs in the ME1X16NA-Q while writing to or reading data from the programmable controller CPU, an error code is written to buffer memory address 90 (Un\G90).

| Error code (decimal) | Error description | Corrective action |
|----------------------|---|---|
| 30 to 45 | The setting for the short pulse discrimination time for an input is outside the range of 0 to 400. | The error code shows the buffer memory address containing the incorrect value (30 = Un\G30 for input CH0 to 45 = Un\G45 for input CHF). Set a value within 0 to 400. |
| 46 to 61 | The setting for the pulse stretching time for an input is outside the range of 0 to 20. | The error code shows the buffer memory address containing the incorrect value (46 = Un\G46 for input CH0 to 61 = Un\G61 for input CHF). Set a value within 0 to 20. |
| 62 to 77 | At least one of the flutter monitoring parameters is out of range. | The error code shows the buffer memory address containing the incorrect value (62 = Un\G62 for input CH0 to 77 = Un\G77 for input CHF). Set the flutter monitoring parameters to within its valid ranges: <ul style="list-style-type: none"> Flutter monitoring window: 0 to 120 Maximum no. of allowed signal changes: 2 to 31 |
| 80 to 87 | While updating the real-time clock (Yn2), the real-time clock setting value (Un\G80 to Un\G87) is out of range. | Make sure the clock data is written in the correct format into Un\G80 to Un\G87 before switching the signal Yn2 ON. |
| 100 | External 24 V not connected or hardware error of the NAMUR input circuit. | Connect the external 24 V or turn the 24 V OFF and ON again. If the error occurs again, the module may be malfunctioning. Please consult your local Mitsubishi representative, explaining the detailed description of the problem. |
| 111 | Hardware error of the module. | Turn the power OFF and ON again. If the error occurs again, the module may be malfunctioning. Please consult your local Mitsubishi representative, explaining the detailed description of the problem. |

Tab. 6-1: Error code list

NOTE

When two or more errors have occurred, the latest error found by the ME1X16NA-Q is stored.

6.2 Troubleshooting by Symptom

6.2.1 When the LEDs of the ME1X16NA-Q are not turned ON

| Check item | Corrective action |
|---|---|
| Is the power being supplied to the PLC? | Confirm that the supply voltage for the power supply module is within the rated range. |
| Is the capacity of the power supply module adequate? | Calculate the current consumption of the CPU module, I/O modules and intelligent function modules mounted on the base unit to see if the power supply capacity is adequate. |
| Has a watchdog timer error occurred? | Reset the programmable controller CPU and verify that it is lit. If the RUN LED does not light even after doing this, the module may be malfunctioning. Please consult your local Mitsubishi representative, explaining the detailed description of the problem. |
| Is the ME1X16NA-Q correctly mounted on the base unit? | Check the mounting condition of the module. |
| Has an error occurred in the ME1X16NA-Q? | <ul style="list-style-type: none"> • Check that the input signal Xn0 (Module ready) is ON (refer to section 3.4.2). • Check whether the input signal XnF (Error) is ON (refer to section 3.4.2). • Check the buffer memory address 90 (Un\G90) for an error code and take corrective action as described in section 6.1. |
| Is 24 V DC external supply power being supplied to the ME1X16NA-Q? | <ul style="list-style-type: none"> • Check that the external supply power terminals (terminals No. A1 and B1) are supplied with a 24 V DC voltage. • Check that the input signal Xn7 (External 24V ready) is ON. • Check the buffer memory address 90 (Un\G90) for an error code and take corrective action as described in section 6.1. |
| Is the NAMUR sensor correctly connected to the ME1X16NA-Q? | Check the connection status of the sensor (section 4.4). |
| Is the connected NAMUR sensor working correctly? | Check the device connected to the input. |
| Is there any fault with the signal lines such as disconnection or wire break? | Check for faulty condition of the signal lines by a visual check and a continuity check. |

Tab. 6-2: When the LEDs are not turned ON

6.2.2 When the Input Values cannot be read

| Check item | Corrective action |
|---|--|
| Is an error being generated? | Check the buffer memory address 90 (Un\G90) for an error code and take corrective action as described in section 6.1. |
| Are the input values being written to the buffer memory? | <ul style="list-style-type: none"> • Verify the contents of the buffer memory address Un\G0 in the monitor of GX (IEC) Developer or GX Works2. • Check the sensor connected to the input. |
| Are the input values moved from the buffer memory of the ME1X16NA-Q to the PLC CPU correctly? | <ul style="list-style-type: none"> • Check the sequence program. Make sure that the input values are taken out of the correct buffer memory address (Un\G0). • Check that data is not moved from different sources into the same storage destination in the PLC CPU. |

Tab. 6-3: When the input values cannot be read

6.2.3 When Wire Breaks and Short Circuits are not detected

| Check item | Corrective action |
|--|---|
| Is the detection of wire breaks and short circuits enabled in the buffer memory address Un\G4? | Enable the detection of wire breaks and short circuits for the respective input in Un\G4. |
| Has the operating condition setting request (Yn9) been executed? | After a change in the buffer memory address Un\G4 the operating condition setting request (Yn9) must be switched ON to make the setting valid. Review the initial setting in the sequence program. |

Tab. 6-4: When wire breaks and short circuits are not detected

6.2.4 When there is always a Wire Break detected (XnD is ON)

| Check item | Corrective action |
|---|--|
| Is the detection of wire break and short circuit enabled for an unused input? | Disable the detection of wire breaks and short circuits for unused inputs in Un\G4 (refer to section 3.5.6). |

Tab. 6-5: When a wire break for an unused input is detected

6.2.5 When Flutter is not detected

| Check item | Corrective action |
|--|--|
| Is the flutter monitoring enabled for the input? | The flutter monitoring parameters are set in the buffer memory addresses Un\G62 to Un\G77 (section 3.5.14). <ul style="list-style-type: none"> • When the window time is set to 0, the flutter monitoring function is disabled for the respective input. • When a value outside the allowed range is entered for the parameters, an error is detected and an error code is stored in the buffer memory address 90 (Un\G90). Review the settings of the parameters. |
| Are the flutter monitoring parameters set correctly? | |
| Has the operating condition setting request (Yn9) been executed? | After changing the flutter monitoring parameters in one of the buffer memory addresses Un\G62 to Un\G77, the operating condition setting request (Yn9) must be switched ON to make the settings valid. Review the sequence program. |

Tab. 6-6: When flutter is not detected

6.2.6 When Events are not recorded

| Check item | Corrective action |
|--|---|
| Is the specific event enabled? | Enable the event for the respective input in one of the following buffer memory addresses: <ul style="list-style-type: none"> – Un\G8 (positive edge of input) (section 3.5.9) – Un\G9 (negative edge pf input) (section 3.5.9) – Un\G10 (wire break, short circuit, flutter) (section 3.5.10) |
| Has the operating condition setting request (Yn9) been executed? | After changing the event buffer enable settings in one of the buffer memory addresses Un\G8 to Un\G10, the operating condition setting request (Yn9) must be switched ON to make the settings valid. Review the sequence program. |
| Is the event buffer full? | Check the status of the signal Xn5 (event buffer full). If this signal is ON, use the Yn4/Xn4 handshake to read out the events (refer to section 3.3.4). Or use the signal Yn5 to clear the event buffer. |

Tab. 6-7: When events are not detected

6.2.7 When the Short Pulse Discrimination Function is not working

| Check item | Corrective action |
|--|--|
| Is the short pulse discrimination time set correctly? | <p>The short pulse discrimination time is set in the buffer memory addresses Un\G30 to Un\G45 (refer to section 3.5.12).</p> <ul style="list-style-type: none"> When the time is set to 0, the short pulse discrimination is disabled for the respective input. When a value outside the allowed range is entered for the time, an error is detected and an error code is stored in the buffer memory address 90 (Un\G90). <p>Check the buffer memory address Un\G90 for an error code and take corrective action as described in section 6.1. Review the setting of the parameters.</p> |
| Has the operating condition setting request (Yn9) been executed? | <p>After changing the short pulse discrimination time in one of the buffer memory addresses Un\G30 to Un\G45, the operating condition setting request (Yn9) must be switched ON to make the settings valid. Review the sequence program.</p> |

Tab. 6-8: When short pulses are not eliminated

6.2.8 When the Pulse Stretching Function is not working

| Check item | Corrective action |
|--|--|
| Is the pulse stretching time set correctly? | <p>The pulse stretching time is set in the buffer memory addresses Un\G46 to Un\G61 (refer to section 3.5.13).</p> <ul style="list-style-type: none"> When the time is set to 0, the pulse stretching is disabled for the respective input. When a value outside the allowed range is entered for the time, an error is detected and an error code is stored in the buffer memory address 90 (Un\G90). <p>Check the buffer memory address Un\G90 for an error code and take corrective action as described in section 6.1. Review the setting of the parameters.</p> |
| Has the operating condition setting request (Yn9) been executed? | <p>After changing the short pulse discrimination time in one of the buffer memory addresses Un\G46 to Un\G61, the operating condition setting request (Yn9) must be switched ON to make the settings valid. Review the sequence program.</p> |

Tab. 6-9: When pulse stretching is not working

6.3 Checking the Module Status

When the analog output module detail information is selected in GX Developer, GX IEC Developer or GX Works2 system monitor, an error code and the status of the intelligent function module switch setting can be checked.

- Operating GX Developer
In the **Diagnostics** menu select **System monitor**.
- Operating GX IEC Developer
In the **Debug** menu select **System monitor**.
- Operating GX Works2
In the **Diagnostics** menu select **System Monitor**.




Fig. 6-1: The System Monitor displays comprehensive information of the connected PLC

For further information about a module, click on the module and then click **Module Detailed Information**.




Fig. 6-2: Detailed information on the selected module allow an easy and quick troubleshooting

Contents of Module's Detailed Information

- Module
 - Module Name: Shows the designation of the module, e.g. ME1X16NA-Q
 - I/O Address: Head address of the module
 - Implementation Position: Shows whether the module is mounted to the main base or to an extension base and the position of the module.
 - Product information: Serial No. of the module. The letter shows the function version.
- Module Information
 - Module access: Shows whether the module is ready or not.
 - Fuse status: Not relevant for the ME1X16NA-Q.
 - Status of I/O Address Verify: Indicates whether the parameter set module and the installed module are identical.
 - I/O Clear / Hold Settings, Noise Filter Setting, etc.: Not relevant for the ME1X16NA-Q.
- Error Display
 - Checking the error code
The error code stored in buffer memory address 90 (Un\G90) of the ME1X16NA-Q is displayed in the **Present Error** field.
 - When the **Error History** button is pressed, the contents displayed in the **Present Error** field is displayed in the No. 1 field.

Index

B

| | |
|---------------|------|
| Buffer memory | |
| Overview | 3-16 |
| Structure | 3-15 |

E

| | |
|--|------|
| Error (input signal) | 3-13 |
| Error clear request (output signal) | 3-14 |
| Error code | |
| List | 6-1 |
| storage in buffer memory | 3-30 |
| Event buffer clear request (output signal) | 3-14 |
| Event buffer full (input signal) | 3-11 |
| Event detection (input signal) | 3-11 |
| Event reset (output signal) | 3-14 |
| Events | |
| Enable setting | 3-23 |
| Overview | 3-8 |
| storage in buffer memory | 3-25 |
| Troubleshooting | 6-3 |
| External 24 V ready (input signal) | 3-11 |
| External power supply | |
| Specifications | 3-3 |
| Wiring | 4-7 |

F

| | |
|---|------|
| Fast conversion mode | 4-9 |
| Flutter monitoring | |
| Overview | 3-7 |
| Parameters | 3-28 |
| Program example | 5-9 |
| Troubleshooting | 6-3 |
| Flutter warning (input signal) | 3-11 |
| Flutter warning clear request (output signal) | 3-14 |
| Function version | 2-4 |

G

| | |
|-----------|-----|
| Grounding | 4-6 |
|-----------|-----|

H

| | |
|---|------|
| HOLD/CLEAR | |
| Overview | 4-9 |
| Setting with intelligent function module switches | 4-10 |

I

| | |
|---------------------------------------|------|
| Input signal | |
| Error | 3-13 |
| Event buffer full | 3-11 |
| Event detection | 3-11 |
| External 24 V ready | 3-11 |
| Flutter warning | 3-11 |
| Module ready | 3-11 |
| Operating condition setting completed | 3-12 |
| Update real-time clock acknowledge | 3-11 |
| Wire break detection | 3-12 |
| Input values | |
| in buffer memory | 3-18 |
| Troubleshooting | 6-2 |
| Intelligent function module | |
| Parameter setting | 4-8 |
| Switch setting | 4-9 |

L

| | |
|-----------------|-----|
| LEDs | |
| Overview | 3-1 |
| Troubleshooting | 6-2 |

M

| | |
|---|------|
| ME1X16NA-Q | |
| Dimensions | 3-5 |
| I/O assignment | 4-8 |
| Installation | 4-3 |
| Intelligent function module switch settings | 4-9 |
| LEDs | 3-1 |
| Parameter setting | 4-8 |
| Specifications | 3-3 |
| MELSEC System Q CPU modules | 2-1 |
| MELSECNET/H remote I/O station | 2-2 |
| Module ready (input signal) | 3-11 |
| Multiple CPU system | 2-2 |

N

| | |
|--------------------------|-----|
| NAMUR sensor | |
| connection to ME1X16NA-Q | 4-7 |
| Principle of operation | 1-1 |

| O | |
|---|------|
| Online module change | 2-2 |
| Operating condition | |
| Setting completed (input signal) | 3-12 |
| Setting request (output signal) | 3-14 |
| Output signal | |
| Error clear request | 3-14 |
| Event buffer clear request | 3-14 |
| Event reset | 3-14 |
| Flutter warning clear request | 3-14 |
| Operating condition setting request | 3-14 |
| Short circuit detection clear request | 3-14 |
| Update real-time clock | 3-14 |
| Wire break detection clear request | 3-14 |

| P | |
|---------------------------|-----|
| Pulse stretching | |
| Overview | 3-7 |
| Program example | 5-9 |
| Troubleshooting | 6-4 |

| R | |
|---|------|
| Real-time clock | |
| Setting data in buffer memory | 3-29 |
| Update (output signal) | 3-14 |
| Update acknowledge (input signal) | 3-11 |

| S | |
|---|------|
| Short circuit detection | |
| clear request (output signal) | 3-14 |
| Flags in buffer memory | 3-19 |
| Input signal | 3-13 |
| Troubleshooting | 6-3 |
| Short pulse discrimination | |
| Overview | 3-6 |
| Program example | 5-9 |
| Troubleshooting | 6-4 |
| Switch settings for intelligent function module . . . | 4-9 |
| System monitor | 6-5 |

| T | |
|---------------------------|-----|
| Time stamping | 3-9 |
| Troubleshooting | 6-2 |

| U | |
|---|------|
| Update real-time clock (output signal) | 3-14 |
| Update real-time clock acknowledge (input signal) | 3-11 |

| W | |
|---|------|
| Wire break detection | |
| clear request (output signal) | 3-14 |
| input signal | 3-12 |
| Troubleshooting | 6-3 |
| Wiring | |
| Connection of NAMUR sensors | 4-7 |
| Example for shielded cable | 4-4 |
| External power supply | 4-7 |
| Grounding of shielded cable | 4-6 |

| HEADQUARTERS | | EUROPEAN REPRESENTATIVES | | EUROPEAN REPRESENTATIVES | | EUROPEAN REPRESENTATIVES | |
|--|-------------------|--|-------------------------------|--|--------------------|---|-------------------|
| MITSUBISHI ELECTRIC EUROPE B.V. German Branch Gothaer Straße 8 D-40880 Ratingen Phone: +49 (0)2102 / 486-0 Fax: +49 (0)2102 / 486-1120 | EUROPE | GEVA Wiener Straße 89 AT-2500 Baden Phone: +43 (0)2252 / 85 55 20 Fax: +43 (0)2252 / 488 60 | AUSTRIA | ALFATRADE Ltd. 99, Paola Hill Malta- Paola PLA 1702 Phone: +356 (0)21 / 697 816 Fax: +356 (0)21 / 697 817 | MALTA | TOO Kazpromavtomatika Ul. Zhambyla 28 KAZ-100017 Karaganda Phone: +7 7212 / 50 10 00 Fax: +7 7212 / 50 11 50 | KAZAKHSTAN |
| MITSUBISHI ELECTRIC EUROPE B.V.-org.sl. Czech Branch Avenir Business Park, Radlická 714/113a CZ-158 00 Praha 5 Phone: +420 - 251 551 470 Fax: +420 - 251-551-471 | CZECH REP. | TECHNIKON Oktyabrskaya 19, Off. 705 BY-220030 Minsk Phone: +375 (0)17 / 210 46 26 Fax: +375 (0)17 / 210 46 26 | BELARUS | INTEHSIS srl bld. Traian 23/1 MD-2060 Kishinev Phone: +373 (0)22 / 66 4242 Fax: +373 (0)22 / 66 4280 | MOLDOVA | MIDDLE EAST REPRESENTATIVES | |
| MITSUBISHI ELECTRIC EUROPE B.V. French Branch 25, Boulevard des Bouvets F-92741 Nanterre Cedex Phone: +33 (0)1 / 55 68 55 68 Fax: +33 (0)1 / 55 68 57 57 | FRANCE | ESCO DRIVES & AUTOMATION Culliganlaan 3 BE-1831 Diegem Phone: +32 (0)2 / 717 64 30 Fax: +32 (0)2 / 717 64 31 | BELGIUM | HIFLEX AUTOM.TECHNIEK B.V. Wolweverstraat 22 NL-2984 CD Ridderkerk Phone: +31 (0)180 - 46 60 04 Fax: +31 (0)180 - 44 23 55 | NETHERLANDS | EGYPT | |
| MITSUBISHI ELECTRIC EUROPE B.V. Irish Branch Westgate Business Park, Ballymount IRL-Dublin 24 Phone: +353 (0)1 4198800 Fax: +353 (0)1 4198890 | IRELAND | Koning & Hartman b.v. Woluwelaan 31 BE-1800 Vilvoorde Phone: +32 (0)2 / 257 02 40 Fax: +32 (0)2 / 257 02 49 | BELGIUM | Koning & Hartman b.v. Haarlerbergweg 21-23 NL-1101 CH Amsterdam Phone: +31 (0)20 / 587 76 00 Fax: +31 (0)20 / 587 76 05 | NETHERLANDS | ISRAEL | |
| MITSUBISHI ELECTRIC EUROPE B.V. Italian Branch Viale Colleoni 7 I-20041 Agrate Brianza (MB) Phone: +39 039 / 60 53 1 Fax: +39 039 / 60 53 312 | ITALY | INEA RBT d.o.o. Aleja Lipa 56 BA-71000 Sarajevo Phone: +387 (0)33 / 921 164 Fax: +387 (0)33 / 524 539 | BOSNIA AND HERZEGOVINA | Beijer Electronics AS Postboks 487 NO-3002 Drammen Phone: +47 (0)32 / 24 30 00 Fax: +47 (0)32 / 84 85 77 | NORWAY | ISRAEL | |
| MITSUBISHI ELECTRIC EUROPE B.V. Poland Branch Krakowska 50 PL-32-083 Balice Phone: +48 (0)12 / 630 47 00 Fax: +48 (0)12 / 630 47 01 | POLAND | AKHNATON 4, Andrej Ljapchev Blvd., PO Box 21 BG-1756 Sofia Phone: +359 (0)2 / 817 6000 Fax: +359 (0)2 / 97 44 06 1 | BULGARIA | Fonseca S.A. R. João Francisco do Casal 87/89 PT - 3801-997 Aveiro, Esgueira Phone: +351 (0)234 / 303 900 Fax: +351 (0)234 / 303 910 | PORTUGAL | LEBANON | |
| MITSUBISHI ELECTRIC EUROPE B.V. Russian Branch 52, bld. 3 Kosmodamienskaya nab 8 floor RU-115054 Moscow Phone: +7 495 721-2070 Fax: +7 495 721-2071 | RUSSIA | INEA RBT d.o.o. Losinjska 4 a HR-10000 Zagreb Phone: +385 (0)1 / 36 940 -01 / -02 / -03 Fax: +385 (0)1 / 36 940 -03 | CROATIA | Sirius Trading & Services srl Aleea Lacul Morii Nr. 3 RO-060841 Bucuresti, Sector 6 Phone: +40 (0)21 / 430 40 06 Fax: +40 (0)21 / 430 40 02 | ROMANIA | LEBANON | |
| MITSUBISHI ELECTRIC EUROPE B.V. Spanish Branch Carretera de Rubí 76-80 E-08190 Sant Cugat del Vallés (Barcelona) Phone: 902 131121 // +34 935653131 Fax: +34 935891579 | SPAIN | AutoCont C.S. s.r.o. Technologická 374/6 CZ-708 00 Ostrava-Pustkovec Phone: +420 595 691 150 Fax: +420 595 691 199 | CZECH REPUBLIC | INEA RBT d.o.o. Izletnička 10 SER-113000 Smederevo Phone: +381 (0)26 / 615 401 Fax: +381 (0)26 / 615 401 | SERBIA | AFRICAN REPRESENTATIVE | |
| MITSUBISHI ELECTRIC EUROPE B.V. UK Branch Travellers Lane UK-Hatfield, Herts. AL10 8XB Phone: +44 (0)1707 / 27 61 00 Fax: +44 (0)1707 / 27 86 95 | UK | Beijer Electronics A/S Lykkegårdsvej 17 DK-4000 Roskilde Phone: +45 (0)46 / 75 76 66 Fax: +45 (0)46 / 75 56 26 | DENMARK | SIMAP s.r.o. Jána Derku 1671 SK-911 01 Trenčín Phone: +421 (0)32 743 04 72 Fax: +421 (0)32 743 75 20 | SLOVAKIA | SOUTH AFRICA | |
| MITSUBISHI ELECTRIC EUROPE B.V. Japan Office Tower "Z" 14 F 8-12,1 chome, Harumi Chuo-Ku Tokyo 104-6212 Phone: +81 3 622 160 60 Fax: +81 3 622 160 75 | JAPAN | Beijer Electronics Eesti OÜ Pärnu mnt.160i EE-11317 Tallinn Phone: +372 (0)6 / 51 81 40 Fax: +372 (0)6 / 51 81 49 | ESTONIA | PROCONT, spol. s r.o. Prešov Kúpeľná 1/A SK-080 01 Prešov Phone: +421 (0)51 7580 611 Fax: +421 (0)51 7580 650 | SLOVAKIA | SOUTH AFRICA | |
| MITSUBISHI ELECTRIC AUTOMATION, Inc. 500 Corporate Woods Parkway Vernon Hills, IL 60061 Phone: +1 847 478 21 00 Fax: +1 847 478 22 53 | USA | Beijer Electronics OY Peltoie 37 FIN-28400 Ulvila Phone: +358 (0)207 / 463 540 Fax: +358 (0)207 / 463 541 | FINLAND | INEA RBT d.o.o. Stegne 11 SI-1000 Ljubljana Phone: +386 (0)1 / 513 8116 Fax: +386 (0)1 / 513 8170 | SLOVENIA | SOUTH AFRICA | |
| | | UTEKO 5, Mavrogenous Str. GR-18542 Piraeus Phone: +30 211 / 1206 900 Fax: +30 211 / 1206 999 | GREECE | Beijer Electronics AB Box 426 SE-20124 Malmö Phone: +46 (0)40 / 35 86 00 Fax: +46 (0)40 / 93 23 01 | SWEDEN | SOUTH AFRICA | |
| | | MELTRADE Kft. Fertő utca 14. HU-1107 Budapest Phone: +36 (0)1 / 431-9726 Fax: +36 (0)1 / 431-9727 | HUNGARY | Omni Ray AG Im Schörl 5 CH-8600 Dübendorf Phone: +41 (0)44 / 802 28 80 Fax: +41 (0)44 / 802 28 28 | SWITZERLAND | SOUTH AFRICA | |
| | | Beijer Electronics SIA Ritausmas iela 23 LV-1058 Riga Phone: +371 (0)784 / 2280 Fax: +371 (0)784 / 2281 | LATVIA | GTS Bayraktar Bulvari Nutuk Sok. No:5 TR-34775 Yukarı Dudullu-Ümraniye-İSTANBUL Phone: +90 (0)216 526 39 90 Fax: +90 (0)216 526 3995 | TURKEY | SOUTH AFRICA | |
| | | Beijer Electronics UAB Savanoriu Pr. 187 LT-02300 Vilnius Phone: +370 (0)5 / 232 3101 Fax: +370 (0)5 / 232 2980 | LITHUANIA | CSC Automation Ltd. 4-B, M. Raskovoyi St. UA-02660 Kiev Phone: +380 (0)44 / 494 33 55 Fax: +380 (0)44 / 494-33-66 | UKRAINE | SOUTH AFRICA | |
| | | | | Systemgroup 2 M. Krivonosy St. UA-03680 Kiev Phone: +380 (0)44 / 490 92 29 Fax: +380 (0)44 / 248 88 68 | UKRAINE | SOUTH AFRICA | |