


mitsubishi

A870/A850/A851GOT Graphic Operation Terminal

Operating Manual (Expanded Functions Manual)




GRAPHIC OPERATION TERMINAL

800

Series



Mitsubishi Graphic Operation Terminal



● Precautions Regarding Safety ●

(Please read carefully before using your equipment)

When using the Graphic Operation Terminal, please read the manuals that are supplied with each of the products, as well as any related manuals available as supplementary manuals. Make sure careful attention is paid to safety, and that the equipment is handled correctly.

These precautions apply to the Graphic Operation Terminal. Refer to the CPU module user's manual for a description of the PC system safety precautions.

In this manual, safety precautions concerning more hazardous items are labeled "DANGER", and those concerning more general safety items are labeled "CAUTION".



DANGER

Improper handling could cause hazardous conditions resulting in severe injury or death.



CAUTION

Improper handling could cause hazardous conditions resulting in moderate or light injury, or in physical damage.

Items marked with an exclamation point in a triangle  could also cause severe consequences, depending on the circumstances, if not handled properly. They indicate information that should be taken seriously and observed conscientiously.

Manuals supplied with the products should be stored carefully where they can be accessed whenever necessary, and should always be passed on to the end user along with the equipment.

[Precautions Regarding Startup and Maintenance]

CAUTION

- For a test operation during a run (forced output, data change), read the manual thoroughly and check the safety conditions carefully.

The machine can be damaged or accidents can occur due to operation error.

Introduction

Thank you for purchasing the Mitsubishi Graphic Operation Terminal.

Before using the equipment, please read this manual carefully to develop full familiarity with the functions and performance of the graphic operation terminal you have purchased, so as to ensure correct use.

Please forward a copy of this manual to the end user.

Contents

Precautions Regarding Safety

Configuration of the Manual

About the Manuals

Common Edition

1. Overview

1-1~1-11

- 1.1 Preparation Prior to Using Expanded Functions 1-1
- 1.2 Precautions Concerning Usage 1-1
- 1.3 Features 1-4
 - 1.3.1 Features of the Circuit Monitor Function 1-4
 - 1.3.2 Features of the System Monitor Function 1-6
 - 1.3.3 Features of the Special Unit Monitor 1-8
- 1.4 Names, Abbreviations, and Terminology Used in This Manual 1-10

2. Before Beginning Operation

2-1

- 2.1 Required Equipment 2-1

3. Specifications

3-1~3-29

- 3.1 Circuit Monitor Function Specifications 3-1
 - 3.1.1 PC CPUs which can be monitored 3-1
 - 3.1.2 Access ranges which can be monitored 3-1
- 3.2 System Monitor Function Specifications 3-9
 - 3.2.1 PC CPUs which can be monitored 3-9
 - 3.2.2 Access ranges which can be monitored 3-9
 - 3.2.3 Names of devices which can be monitored 3-22
 - 3.2.4 Precautions When Using the System Monitor Function 3-24
- 3.3 Special Unit Monitor Function Specifications 3-25
 - 3.3.1 Access ranges which can be monitored 3-25
 - 3.3.2 Special Function Units That Can Be Monitored 3-26
 - 3.3.3 Memory Capacity Required for Using the Special Unit Monitor Function 3-26
 - 3.3.4 Precautions When Using the Special Unit Monitor Function 3-28

Circuit Monitor Function Operation Manual

4. Operating Procedures for the Circuit Monitor Function **4-1~4-2**

- 4.1 Operating Procedures Before Starting Circuit Monitoring 4-1
- 4.2 Operating Procedure from Display of User-Created Monitor Screen to Start of Circuit Monitoring 4-2

5. Operating the Various Circuit Monitor Screens **5-1~5-7**

- 5.1 Screen Operation and Screen Changes When Monitoring 5-1
 - 5.1.1 Reading Data From the PC 5-1
 - 5.1.2 Circuit Read Operation 5-3
 - 5.1.3 Changing From One Screen to Another 5-5
- 5.2 Circuit Monitor 5-6
 - 5.2.1 Circuit Monitor Screen Display and Key Functions 5-6
 - 5.2.2 Switching the Display Form (Decimal/Hexadecimal) and Turning the Comment Display On/Off 5-7

6. Error Display and Handling With Circuit Monitoring **6-1**

System Monitor Function Operation Manual

7. Operation Procedure for the System Monitor Function

7-1~7-2

- 7.1 Operation Procedure Before Starting System Monitoring 7-1
- 7.2 Operation Procedure from User-Created Monitor Screen Display to Start of System Monitoring ... 7-2

8. Operation of the Various System Monitor Screens

8-1~8-17

- 8.1 Screen Configuration, Common Operations and Changing Screens When Monitoring 8-1
 - 8.1.1 Basic Screen Configuration and Key Functions (Menu) 8-1
 - 8.1.2 Switching the Display Form (Decimal/Hexadecimal)
and Turning the Comment Display On/Off (FORM) 8-2
 - 8.1.3 Specifying the Monitor Station and Device (SET) 8-4
 - 8.1.4 Changing Screens 8-6
- 8.2. Entry Monitor 8-7
 - 8.2.1 Basic Operation 8-7
 - 8.2.2 Entry Monitor Screen Display and Key Functions 8-8
 - 8.2.3 Deleting a Registered Device 8-9
- 8.3 Batch Monitor 8-10
 - 8.3.1 Basic Operation 8-10
 - 8.3.2 Batch Monitor Screen Display and Key Functions 8-11
- 8.4 TC Monitor 8-12
 - 8.4.1 Basic Operation 8-12
 - 8.4.2 TC Monitor Screen Display and Key Functions 8-13
- 8.5 BM Monitor 8-14
 - 8.5.1 Basic Operation 8-14
 - 8.5.2 BM Monitor Screen Display and Key Functions 8-15
- 8.6 Test 8-16
 - 8.6.1 Basic Operation 8-16

9. Error Display and Handling with System Monitoring

9-1

Special Unit Monitor Function Operation Manual

10. Operating Procedure for Special Unit Monitor Function 10-1~10-2

- 10.1 Operating Procedure Before Starting Special Unit Monitor 10-1
- 10.2 Operating Procedure From User-Created Monitor Screen Display
to Start of Special Unit Monitor 10-2

11. Operation of Each Special Unit Monitor Screen 11-1~11-109

- 11.1 Screen Configuration, Common Operation and Changing Screens When Monitoring 11-1
 - 11.1.1 Composition of System Configuration Screen and Key Functions 11-1
 - 11.1.2 Monitor Screen Configuration and Key Functions 11-2
 - 11.1.3 Specifying Monitor Unit and Selecting Monitor Menu 11-3
 - 11.1.4 Test for Special Function Unit 11-4
 - 11.1.5 Changing the Screen 11-6
- 11.2 A61LS Unit Monitor 11-7
 - 11.2.1 Operation Monitor 11-7
 - 11.2.2 I/O Monitor 11-8
- 11.3 AD61 Unit Monitor 11-9
 - 11.3.1 Operation Monitor 11-9
- 11.4 A1SD61 Unit Monitor 11-10
 - 11.4.1 Operation Monitor 11-10
 - 11.4.2 I/O Monitor 11-11
- 11.5 A62DA-S1 Unit Monitor 11-12
 - 11.5.1 Operation Monitor 11-12
 - 11.5.2 Graph Monitor 11-13
- 11.6 A1S62DA Unit Monitor 11-14
 - 11.6.1 Operation Monitor 11-14
- 11.7 A62LS Unit Monitor 11-15
 - 11.7.1 Operation Monitor 11-15
 - 11.7.2 I/O Monitor 11-16
- 11.8 A1S62RD Unit Monitor 11-17
 - 11.8.1 Operation Monitor 11-17
 - 11.8.2 I/O Monitor 11-18
 - 11.8.3 Graph Monitor 11-19
- 11.9 A1S63DA Unit Monitor 11-20
 - 11.9.1 Operation Monitor 11-20
 - 11.9.2 Simple Loop Monitor 11-21
 - 11.9.3 I/O Monitor 11-22
- 11.10 A1S64DA Unit Monitor 11-23
 - 11.10.1 Operation Monitor 11-23
 - 11.10.2 I/O Monitor 11-24
 - 11.10.3 Graph Monitor 11-25
- 11.11 A68AD Unit Monitor 11-26
 - 11.11.1 Operation Monitor 11-26
 - 11.11.2 I/O Monitor 11-27
 - 11.11.3 Graph Monitor 11-28
- 11.12 A1S68AD Unit Monitor 11-29
 - 11.12.1 Operation Monitor 11-29

11.12.2	I/O Monitor	11-30
11.12.3	Graph Monitor	11-31
11.13	A68ADN Unit Monitor	11-32
11.13.1	Operation Monitor	11-32
11.13.2	I/O Monitor	11-33
11.13.3	Graph Monitor	11-34
11.14	A68RD Unit Monitor	11-35
11.14.1	Operation Monitor	11-35
11.14.2	I/O Monitor	11-36
11.14.3	Graph Monitor	11-37
11.15	A1S68DAI, A1S68DAV Unit Monitor	11-38
11.15.1	Operation Monitor	11-38
11.15.2	I/O Monitor	11-39
11.15.3	Graph Monitor	11-40
11.16	A616AD Unit Monitor	11-41
11.16.1	Operation Monitor	11-41
11.16.2	Operation Monitor (Connect No. 0 - Connect No. 7 When Multiplex Unit is Used)	11-42
11.16.3	I/O Monitor	11-43
11.16.4	Graph Monitor	11-44
11.16.5	Graph Monitor (Connect No. 0 - Connect No. 7 When Multiplex Unit is Used)	11-45
11.17	A616DAI, A616DAV Unit Monitor	11-46
11.17.1	Operation Monitor	11-46
11.17.2	I/O Monitor	11-47
11.17.3	Graph Monitor	11-48
11.18	A616TD Unit Monitor	11-49
11.18.1	Operation Monitor (INPUT 0-F)	11-49
11.18.2	Operation Monitor (Connect No. 0 - Connect No. 7 When Multiplex Unit is Used)	11-50
11.18.3	I/O Monitor	11-51
11.18.4	Setting Monitor (When A60MXT is used)	11-52
11.18.5	Temperature Monitor (Connect No. 0 - Connect No. 7 when A60MXT is used)	11-53
11.18.6	Graph Monitor (INPUT 0-F)	11-54
11.18.7	Graph Monitor (Connect No. 0 - Connect No. 7 When Multiplex Unit is Used)	11-55
11.19	AD70, A1SD70 Unit Monitor	11-56
11.19.1	Positioning and Parameter Data Monitor	11-56
11.19.2	Zero Return Monitor	11-58
11.19.3	I/O Monitor	11-59
11.20	A70D Unit Monitor	11-60
11.20.1	Positioning Monitor	11-60
11.20.2	Zero Return Monitor	11-62
11.20.3	Parameter Data Monitor	11-64
11.20.4	I/O Monitor	11-66
11.21	AD71 Unit Monitor	11-67
11.21.1	Positioning Monitor	11-67
11.21.2	Zero Return Monitor	11-68
11.21.3	Parameter Data Monitor	11-69
11.21.4	M Code Comment Monitor	11-70
11.21.5	I/O Monitor	11-71
11.21.6	Positioning Data Monitor	11-72
11.22	AD72, A1SD71 Unit Monitor	11-73

11.22.1	Positioning Monitor	11-73
11.22.2	Zero Return Monitor	11-74
11.22.3	Parameter Data Monitor	11-75
11.22.4	M Code Comment Monitor	11-76
11.22.5	I/O Monitor	11-77
11.22.6	Positioning Data Monitor	11-78
11.23	AD75, A1SD75 Unit Monitor	11-79
11.23.1	I/O Monitor	11-79
11.23.2	Operation Monitor	11-80
11.23.3	Basic Parameter Monitor	11-81
11.23.4	Extended Parameter Monitor	11-83
11.23.5	Zero Return Parameter Monitor	11-85
11.23.6	Monitoring the Error History and Warning History	11-87
11.23.7	Monitoring the Error Temporary Startup History and Startup History	11-88
11.23.8	Monitoring Speed/Position Control	11-90
11.23.9	Monitoring Special Startup, Jogging, and Manual Pulser Operation	11-91
11.23.10	Monitoring an Origin Point Return	11-92
11.23.11	Monitoring Axis Control Data	11-93
11.23.12	Monitoring the Output Speed	11-94
11.23.13	Monitoring the Target values and Machine Values	11-95
11.23.14	Monitoring External I/O Signals and Status Signals (Flags)	11-96
11.23.15	Monitoring Positioning Information	11-97
11.24	Monitoring the AJ71PT32-S3 and A1SJ71PT32-S3 Units	11-98
11.24.1	I/O Monitor (I/O Mode)	11-98
11.24.2	Monitoring the Link Status	11-99
11.24.3	Monitoring Batch Refreshing	11-100
11.24.4	Monitoring Separate Refreshing	11-101
11.24.5	Monitoring Input and Output (Expansion Mode)	11-102
11.25	Monitoring the AJ71ID1 (ID2)-R4 and A1SK71ID1 (ID2)-R4 Units	11-103
11.25.1	Action Monitor (CH 1 and CH 2)	11-103
11.25.2	I/O Monitor	11-104
11.25.3	Monitoring Set Information	11-105
11.26	Monitoring the A84AD Unit	11-106
11.26.1	Action Monitor	11-106
11.26.2	Setting Monitor	11-107
11.26.3	I/O Monitor	11-108
11.26.4	Monitoring Graphs	11-109

12. Operating I/O Unit Monitor Screens

12-1~12-2

12.1	Specifying the Unit to be Monitored	12-1
12.2	Configuration and Key Functions on Monitor Screens	12-2

13. Error Displays and Countermeasures When Monitoring Special Units

13-1

Appendices

A-1~A-3

Index	A-1
-------------	-----

Configuration of the Manual

This manual covers the circuit monitor functions, system monitor functions, and special unit monitor functions that are possible with the GOT Graphic Operation Terminal, and presents an overview, the specifications, and the functions.

[Common Edition]

Chapter 1

This describes the various monitor functions and their features.

Chapter 2

This describes the equipment required in order to use the various monitor functions, and precautions regarding use of these functions.

Chapter 3

This describes the specifications for the various monitor functions.

[Circuit Monitor Functions Operation]

Chapters 4 ~ 6

These present an overview of the operation procedures for the circuit monitor function, as well as the operation procedures for system monitoring of the PC CPU, input and output units, and special function units.

[System Monitor Functions Operation]

Chapters 7 ~ 9

These present an overview of the operation procedures for the system monitor function, as well as operation procedures for system monitoring of the PC CPU, input and output units, and special function units.

[Special Unit Monitor Functions Operation]

Chapters 10 ~ 13

These present an overview of the operation procedures for the special unit monitor function, as well as operation procedures for monitoring special units using the dedicated screens provided for each unit.

POINT

- (1) When using the circuit monitor function, read Chapters 1 ~ 3 to confirm the overview, required equipment, and precautions, and then begin operation by referring to Chapters 4 ~ 6.
- (2) When using the system monitor function, read Chapters 1 ~ 3 to confirm the overview, required equipment, and precautions, and then begin operation by referring to Chapters 7 ~ 9.
- (3) When using the special unit monitor function, read Chapters 1 ~ 3 to confirm the overview, required equipment, and precautions, and then begin operation by referring to Chapters 10 ~ 13.


About the Manuals

The following product manuals are available. Please use this table as a reference to request the appropriate manual as necessary.

Related Manuals


Manual Name	Manual No. (Model Code)
<p>A870GOT Graphic Operation Terminal User's Manual This describes the specifications and performance of the A870GOT main unit, as well as the hardware configuration, procedures for installing optional units, operation in on-line mode, error codes, and troubleshooting guidelines. (Sold separately)</p>	<p>IB-66628 (13J830)</p>
<p>A850GOT Graphic Operation Terminal User's Manual This describes the specifications and performance of the A850GOT main unit, as well as the hardware configuration, procedures for installing optional units, operation in on-line mode, error codes, and troubleshooting guidelines. (Sold separately)</p>	<p>IB-66659 (13JH33)</p>
<p>SW2NIW-A8GOTP Graphic Settings Software Package Operating Manual (Introductory Manual) This manual is designed for the first-time user of the GOT. It describes how to create monitor screens with the A8GOTP, how to send monitor data to the GOT, and what the various screen displays mean. (Sold separately)</p>	<p>IB-66679-A (13J900)</p>
<p>SW2NIW-A8GOTP Graphic Settings Software Package Operating Manual (Startup Manual) This describes the configuration of the A8GOTP system, precautions regarding the configuration, and the specifications of the various functions, as well as the installation procedures, startup procedures, screen configurations, and basic operation procedures. (Sold separately)</p>	<p>IB-66680-A (13J901)</p>
<p>SW2NIW-A8GOTP Graphic Settings Software Package Operating Manual (Monitor Screen Creation Manual) This describes procedures for creating monitor screens, monitor functions that can be used with the GOT, procedures for setting the monitor functions, precautions to be observed when creating monitor screens, and precautions to be observed when appropriating conventional GOT monitor data for use with the GOT. (Sold separately)</p>	<p>IB-66681-A (13J902)</p>
<p>SW2NIW-A8GOTP Graphic Settings Software Package Operating Manual (Data Transmission/Debugging/Document Creation Manual) This manual describes the following items. (1) Procedures for downloading project data to the GOT and uploading data from the GOT (2) Procedures for installing the operating system in the GOT (3) Procedures for using the A8GOTP as a virtual sequencer and for debugging the A870GOT (4) Procedures for outputting created monitor data as a completed document (Sold separately)</p>	<p>IB-66682-A (13J903)</p>
<p>A8GT-MCAM Memory Cassette with Built-in Circuit Monitoring Function User's Manual This manual explains how to install the circuit monitor cassette in the A870GOT. (Sold separately)</p>	<p>IB-66634 (13J831)</p>
<p>A8GT-RS4 RS-422 Serial Communication Unit User's Manual (Hardware Manual) This manual describes the names and settings for the various parts of the interface unit, and how to install it in the A870GOT. (Sold separately)</p>	<p>IB-66635 (13J832)</p>

Manual Name	Manual No. (Model Code)
<p>A7GT-BUS Bus Connection Interface Unit User's Manual (Hardware Manual) This describes the specifications of the bus connection unit, the names of parts, and how to enter settings. (Sold separately)</p>	<p>IB-66556 (13JE92)</p>
<p>A7GT-BUS2 Multi-Drop Bus Connection Interface Unit User's Manual (Hardware Manual) This describes the specifications, names of parts, and settings for the multi-drop bus connection unit. (Sold separately)</p>	<p>IB-66672 (13J849)</p>
<p>A7GT-CNB Bus Connector Conversion Box Instruction Manual This describes the specifications of the bus connector conversion box, and how connections are made. (Sold separately)</p>	<p>BCN-P5138</p>
<p>A7GT-J71AP23/R23 Data Link User's Manual This manual contains the specifications for the MELSECNET (II) Optical Data Link Unit/MELSECNET (II) Coaxial Data Link Unit, as well as the names and settings for the various parts.(Supplied with the pertinent data link unit) (Sold separately)</p>	<p>IB-66438 (13JE26)</p>
<p>A7GT-J71AP23B Data Link Unit User's Manual This contains the specifications for the MELSECNET/B Data Link Unit, as well as the names and settings for the various parts. (Sold separately)</p>	<p>IB-66439 (13JE27)</p>
<p>A7GT-J71LP23/BR13 Network Unit User's Manual This manual contains the specifications for the MELSECNET/10 Optical Loop Network Unit/MELSECNET/10 Coaxial Bus Network Unit, as well as the names and settings for the various parts. (Sold separately)</p>	<p>IB-66558 (13JE94)</p>
<p>MELSECNET, MELSECNET/B Data Link System Reference Manual This manual contains an overview of the MELSECNET (II) and MELSECNET/B, as well as the specifications, names of parts, and the various settings. (Sold separately)</p>	<p>IB-66350 (13JF70)</p>
<p>MELSECNET/10 Network System Reference Manual (For PC Networks) This manual contains an overview of the MELSECNET/10, along with the specifications, names of parts, and the settings. (Sold separately)</p>	<p>IB-66440 (13JE33)</p>
<p>Computer Link/Unit User's Manual (Computer Link Functions/Printer Functions Manual) This manual describes the unit settings, wiring, programming, troubleshooting procedures, and other information concerning communication with peripheral equipment using the dedicated protocol, the no-protocol mode and the bi-directional mode for the computer link unit, as well as printer functions. This manual can be used with the following computer link units: A1SJ71UC24-R2, A1SJ71UC24-R4, A1SJ71UC24-PRF, AJ71UC24, A2CCPUC24, A2CCPUC24-PRF, and A1SCPUC24-R2 (Sold separately)</p>	<p>SH-3511 (13JE77)</p>
<p>AJ71UC24 Computer Link/Unit User's Manual (Hardware Manual) This manual explains the system configuration when using the unit, the unit specifications, and the names of parts and the settings, and contains diagrams of the external dimensions. (Sold separately)</p>	<p>IB-66559 (13JE95)</p>
<p>A1SJ71UC24-R4 Computer Link/Unit User's Manual (Hardware Manual) This manual explains the system configuration when using the unit, the unit specifications, and the names of parts and the settings, and contains diagrams of the external dimensions. (Sold separately)</p>	<p>IB-66582 (13J805)</p>



Common Edition

The Common Edition section of this manual describes an overview of the circuit monitor function, the system monitor function, and the special unit monitor function, along with the features of each, the required equipment, precautions concerning the functions, and specifications.



1. Overview

This manual describes the circuit monitor function, system monitor function, and special unit monitor function (hereafter referred to as "expanded functions") which can be used with a GOT in which the SW2NIW-A8SYSP has been installed.

1.1 Preparation Prior to Using Expanded Functions

In order to use the circuit monitor function, system monitor function, and special unit monitor function described in this manual, the graphic settings software must be used to install the operating systems for the various functions in the GOT.

Referring to the manuals noted below, make sure the operating system of the expanded function to be used has been installed in the GOT before attempting to use the function.

SW2NIW-A8GOTP Graphic Settings Software Package Operating Manual (Data Transmission/Debugging/Document Creation Manual)

1.2 Precautions Concerning Usage

The user should be aware of the following precautions before using the expanded functions.

- (1) It may not be possible to use some of the expanded functions, depending on the type of GOT being used.**

Expanded functions which can be used with the A870GOT

Circuit monitor function, system monitor function, special unit monitor functionIf using the function that allows screens displayed on the GOT to be printed out (the Hard Copy function), please be aware that not all of the expanded functions noted above can be used. Only two functions from among those noted above can be used when the Hard Copy function is used.

Expanded functions which can be used with the A85_GOT

System monitor function (circuit monitor function and special unit monitor function cannot be used)

(2) There are some functions which cannot be used, depending on the CPU to which the GOT is connected and the connection format.

Functions			Ref. Page	MELSEC -QnACPU				MELSEC -ACPU				MELSEC -FXCPU	OMRON PLC
				Bus connection	CPU direct connection	MELSECNET connection	Calculator link connection	Bus connection	CPU direct connection	MELSECNET connection	Calculator link connection	CPU direct connection	Host link connection
Circuit monitor function	Circuit monitoring	Sequence program monitoring using circuit signals	Page 5.2.1										
	Display switching	Decimal and hexadecimal display of word device values	Page 5.2.2			×		○		×		×	
		Device comment display											
System monitor function	Entry monitoring	Monitoring of current values by pre-registering monitor devices	Page 8.2										
	Batch monitoring	Monitoring of n points of current values subsequent to specified device	Page 8.3			○			○		○		
	T/C monitoring	Monitoring of m points of current values, set values, contact points, and coils subsequent to specified device	Page 8.4		○		△ Can't monitor T/C set values		○		△ Can't monitor T/C set values		○
	BM monitoring	Monitoring of x points of current values subsequent to specified buffer memory of specified special unit	Page 8.5			○			○			×	
	Data editing using test operation	Setting/resetting of bit device		Page 8.6			○			○			○
		Changing of current value for buffer memory of word device				○		△ Can't change V or Z current values		○		△ Can't change V or Z current values	
		Changing of current value and set value for T/C (can be used while monitoring T/C)				△ Can't change set values			○		△ Can't change set values		△ Can't change set values
Display switching	Device comment display		Page 8.1.2			×			○			×	
	Decimal and hexadecimal display of word device values and buffer memory values						○			○			○
Special unit monitor function	Monitor test of special function unit	Monitor testing of buffer memory using special screen	Page 11.2			○		△ (Monitoring possible when connected to QC24)		○		×	
	I/O unit monitoring	Monitoring of I/O signal statuses using special screen	Ch. 12									×	

*1 PC CPU models listed below can do monitoring, (Equal to monitor function)

<Large-sized QnACPU>

AnACPU, Q4ARCPU, AnUCPU, AnACPU, AnNCPU

(Version L or subsequent version with AnN link; Version H or subsequent versions without link)

<Small-sized AnQCPU>

Q2ASCPU, Q2ASHCPU, AnUSCPU, AnSCPU (Version C or subsequent version for A2SCPU), A1SJCPU, A0J2HCPU (Version E or subsequent version), A2CCPU (Version H or subsequent version), A2CJCPU

<Multi-axis controller>

A273UCPU, A273UHCPU, A373UCPU, A373CPU (SW0SRX-SV12H (I, J, K) or subsequent), A171CPU

. The circuit monitor function cannot be used with the QnACPU, Q4ARCPU, Q2ASCPU, and Q2ASHCPU.

*2 For access ranges for the circuit monitor function, please see page 3.1.2.

*3 For access ranges and devices which can be monitored with the system monitor function, please see pages 3.2.2 and 3.2.3.

*4 For access ranges and special function units which can be monitored with the special unit monitor function, please see pages 3.3.1 and 3.3.2.

(3) The capacities of the GOT internal memory when the operating systems of the expanded functions have been installed are as noted below.

(a) With the A870GOT

① When an option driver (Hard Copy function) has been installed in the GOT:

If the expanded function operating systems are not installed 768 KB

If any one expanded function operating system is installed 512 KB

If any two expanded function operating systems are installed 512 KB

② If no option driver (Hard Copy function) has been installed in the GOT:

If any one expanded function operating system is installed 768 KB

If any two expanded function operating systems are installed 512 KB

If three expanded function operating systems are installed 384 KB

POINT

If the special unit monitor function is being used, enough memory space must be reserved in the internal memory to accommodate the special unit monitoring data (see page 3.3.3).

(b) With the A85_GOT

If no expanded function operating systems have been installed 768 KB

(If the system monitor function operating system has been installed 768 KB

(The circuit monitor function, special unit monitor function, and Hard Copy function cannot be used.)

1.3 Features

The monitor functions described in this manual are intended to improve the efficiency of troubleshooting and maintenance operations for the PC system.

The features of each monitor function are explained in the following sections.


1.3.1 Features of the Circuit Monitor Function

Installing the circuit monitor function operating system into the A870GOT built-in memory using the graphics software enables circuit monitoring of the PC CPU program. The features of the circuit monitor function are shown below.

(1) Monitoring based on circuit symbols (For details, see Section 5.2.)

(Sample display)

Circuit monitor screen



① Circuit monitor screen


A maximum of 8 lines (max. 11 contact points per line; with 12 contact points or more, the line returns) of a sequence program are displayed on one screen.

Also, for the current values and other settings of word devices, a maximum of 8 devices are displayed. (With 9 devices or more, use the arrow keys to switch displays.)

- (2) The display format can be changed to show comments for devices. (For details, see Section 5.2.2.)

(Sample display)

Circuit monitor screen



① Switching the display format

The current values monitor of the word devices at the bottom of the screen are executed in decimal or hexadecimal format.

② Displaying device comments

Comments for the device used in the sequencer program (comments that are written into the PC CPU) are displayed.

When comments are displayed, 3 lines of the program are shown.

(3) Monitoring other stations

Other stations in data link systems or network systems, including the A870GOT (or stations connected to the A870GOT), can be monitored.

1.3.2 Features of the System Monitor Function

Installing the screen monitor function operating system into the A870GOT built-in memory using the graphics software enables monitoring and testing of the buffer memory for the sequencer CPU program and the special functions unit. The features of the system monitor function are shown below.

(1) Any desired device can be monitored, using 4 dedicated screens

The system monitor function provides an entry monitor, a batch monitor, and a buffer memory monitor, enabling monitoring of any device, for complete flexibility in any application.

Entry monitor

ENTRY MONITOR MENU FORM SET			
NETWK No. [0]	STATION [FF]		
D 15	-2147483648	DW	
D 10	-32767		
X 001	●		
M 25	○		
Y 70	○		
W 200	43		
R 50	68378428	DW	
D 0	3		

Batch monitor

BATCH MONITOR MENU FORM SET			
NETWK No. [0]	STATION [FF]		
D 10	32767	D 18	-500
D 11	0	D 19	3234
D 12	0	D 20	0
D 13	-1	D 21	0
D 14	0	D 22	0
D 15	3	D 23	-32768
D 16	0	D 24	0
D 17	0	D 25	0

Up to 8 points for a PC CPU device registered by the user can be monitored in one window. (See Section 8.2.)

Up to 16 points subsequent to a PC CPU device specified by the user can be monitored in one window. (See Section 8.3.)

T/C monitor

TC MONITOR MENU FORM SET			
NETWK No. [0]	STATION [FF]		
T 0	PV 0 SV	0 ↑ ○	▲
[Production line A]			
T 1	PV 0 SV	0 ↑ ○	
[Production line B]			
T 2	PV 150 SV	150 → ●	
[Production line C]			
T 3	PV 0 SV	0 ↑ ○	▼
[Production line D]			

Buffer memory monitor

BM MONITOR MENU FORM SET			
NETWK No. [0]	STATION [FF]		
I/O NO [1]			
BM 1110	-32768	BM 1118	0
BM 1111	64	BM 1119	0
BM 1112	149	BM 1120	150
BM 1113	-1111	BM 1121	131
BM 1114	126	BM 1122	-32768
BM 1115	160	BM 1123	555
BM 1116	255	BM 1124	2368
BM 1117	1200	BM 1125	11000



Up to 8 points, including the current value, set value, contact point, and coil can be monitored in a window subsequent to a PC CPU timer (T)/counter (C) specified by the user. (See Section 8.4.)

Up to 16 points subsequent to the buffer memory of a special function unit specified by the user can be monitored in one window. (See Section 8.5.)

With the A870GOT, the full screen can be divided into four windows and separate monitoring carried out in all four windows simultaneously.

A870GOT

A85□GOT




(2) Data can be changed by test operation. (See Section 8.6 for details.)

(Test sample)

When M0 is on

When changing D0 present value



① Test for bit device

Device specified by user is turned on or off.

② Test for word device

Writes designated value into device specified by user.

③ Test for timer/counter

Writes in designated value as current value or set value of device specified by user.

④ Test for buffer memory



Writes designated value into buffer memory specified by user.

(3) Display format can be changed and device comments can be displayed. (See Section 8.1.2 for details.)

(Sample display)

For entry monitor
(comment display)

For batch monitor
(hexadecimal display)



① Changing display format

The word device values for the entry monitor, batch monitor, T/C monitor, and buffer memory monitor are monitored in decimal or hexadecimal format.

② Device comment display

When the PC CPU device is monitored, the comments written into the PC CPU are displayed.


(4) Other stations can be monitored.

Other stations in data link systems or network systems, including the GOT (or stations connected to the GOT), can be monitored.

(2) Data can be changed by writing (See Section 11.1.4 for details.)

(Writing example) Monitor screen

When changing channel which can be changed



- ① The designated values are written into the user-specified buffer memory by writing the values from the monitor.
- ② When changing the buffer memory data, input the numeric value using the auto display key window and write it into the buffer memory.

(3) Special unit monitor data can be allocated as user monitor screen data.

The special unit monitor data installed in the computer can be allocated to serve as user monitor screen data. To do this, the steps below are required.

- ① Using the Copy function, allocate special unit monitor data from another project as user monitor screen data.
- ② Correct the data to match the system used for the initial buffer memory number of the sprite function which has been set.

1.4 Names, Abbreviations, and Terminology Used in This Manual

- (1) Circuit monitor cassette This refers to the A8GT-MCAM circuit monitor cassette (memory cassette)
- (2) Graphics software (A8GOTP) This refers to the SW2NIW-A8GOTP Graphic Operation Terminal Software Packages.
- (3) System FD This refers to the following floppy disks, which contain the graphics software, the operating system (see below) for monitors covered by this manual, and the data for monitoring special units.
 - SW2NIW-A8GOTP : This contains the graphics software. It is installed and run on personal computers which are supported by the software package.
 - SW2NIW-A8GMDP : This contains the data for special unit monitoring functions. It is downloaded to the A870GOT and stored in the built-in memory.
 - SW2NIW-A8SYSP : This contains the operating system for monitor screen displays created by the user, the operating system for circuit monitor functions, and various other operating system data. It is installed in the built-in memory of the GOT.
- (4) Data link system This refers to the MELSECNET (II) and MELSECNET/B data link systems.
- (5) Special unit monitor data This is the data for all monitor screens used for the special unit monitor functions displayed on the A870GOT screen.
- (6) Built-in memory This is the internal memory (flash ROM) built into the GOT.
- (7) Network system This is the MELSECNET/10 network system.
- (8) PC This refers to a personal computer which runs Windows and which can run the graphics software described (2).

Windows is a trademark of the U.S. firm Microsoft Corporation.
- (9) A870GOT This refers to the A870GOT Graphic Operation Terminal.

- (10) A850GOT This refers to the A850GOT Graphic Operation Terminal.
- (11) A851GOT This refers to the A851GOT Graphic Operation Terminal.
- (12) A85□ This refers to the A850GOT/A851GOT.
- (13) GOT This refers to the A870GOT/A850GOT/A851GOT.
- (14) FD This is the abbreviation for a floppy disk.
- (15) FDD This is the abbreviation for a floppy disk drive (the drive into which the floppy disk is inserted).
- (16) OS (program) This is the abbreviation for an operating system. In this manual, it indicates the system software programs for the various applicable monitor functions. The types of floppy disks stored in the OS are those indicated above as the system FD.

2. Before Beginning Operation

The required equipment and precautions for using the monitor functions in this manual are described in this section.

2.1 Required Equipment

The chart below shows the equipment required for using the monitor functions.

Required equipment	Application	System monitor	Special function unit monitor (Not supported by A85□GOT)	Circuit monitor (Not supported by A850GOT)
Circuit monitor cassette *1	<ul style="list-style-type: none"> Required for executing circuit monitor function installed in the A870GOT. (Circuit monitor dedicated cassette) 	—	—	○
PC graphics software *2	<ul style="list-style-type: none"> Required for installing the applicable monitor function OS into the GOT and downloading the special unit monitor data. It is necessary to install the graphics software for the applicable PC into the PC. 		○	
Connecting cables *3	<ul style="list-style-type: none"> Required for connecting the above PC and the GOT when installing the applicable monitor function OS into the GOT and downloading the special unit monitor data. 		○	

○ : Required — : Not required

*1 The table below shows the types of circuit monitor cassettes available for circuit monitoring.

Name	Model	Contents
Circuit monitor cassette	A8GT-MCAM	For circuit monitor function
Expanded memory cassette	A8GT-MCA1MFDW	1 MB expansion of internal memory + circuit monitor function
	A8GT-MCA2MFDW	2 MB expansion of internal memory + circuit monitor function
	A8GT-MCA3MFDW	3 MB expansion of internal memory + circuit monitor function

*2 Information concerning the PC for installing and using the graphics software is found in the A8GOTP Operating Manual (Startup Manual).

*3 For information on the cable used to connect the personal computer and the GOT, please refer to the A8GOTP Operating Manual (Data Transmission/Debugging/Document Creation Manual).

3. Specifications

In this chapter, the specifications of the circuit monitor function, system monitor function, and special unit monitor function are discussed separately.

3.1 Circuit Monitor Function Specifications

This section includes the function charts for the circuit monitor function, the PC CPUs and ranges that can be monitored, and the memory capacity required to use the circuit monitor function.

POINT

When using the circuit monitor function, a circuit monitor cassette must be used.

3.1.1 PC CPUs which can be monitored

For PC CPUs which can be monitored, please see page 1.2.

3.1.2 Access ranges which can be monitored

(1) Data link system access ranges which can be monitored

(a) Bus connection/CPU direct connection

- ① If the connected station is the master station (the connected station can be monitored)
 - Local stations cannot be monitored.
- ② If the connected station is a local station (the connected station can be monitored)
 - Only the master station can be monitored.
 - Other local stations cannot be monitored.
- ③ If the connected station is a tri-layer master station (the connected station can be monitored)
 - Dual-layer master stations and tri-layer local stations can be monitored.
 - Dual-layer local stations cannot be monitored.

(b) With a MELSECNET/B or MELSECNET (II) connection

- Only master stations can be monitored.
- Local stations cannot be monitored.

POINT

Even with those stations for which monitoring is listed as possible, it cannot be done if the CPU being monitored is a QnACPU.

(2) Access Ranges for Network Systems That Can be Monitored

(a) For a bus connection (when the A7GT-BUS Version B, the A7GT-BUS2 Version A or each later version is being used)

① When the connected station is a QnACPU or AnUCPU (The connected station can be monitored.)

- The control station and all ordinary stations on the network can be monitored.
- The control station and all ordinary stations on another network can be monitored. (When monitoring another network, always set the routine parameters.)
- If the connected station is an intermediate station and is mixed with a data link system, the master station and local stations can be monitored.
- When circuit monitoring is being carried out with other stations, please be aware that there may be times when monitoring cannot be done, depending on the PC CPU to which the GOT is connected.

 See (Example 1), (Example 2).

② When the connected station is an AnA, or AnNCP (The connected station can be monitored.)

- The control station on the network can be monitored.
- Ordinary stations on the network cannot be monitored.
- Other networks cannot be monitored.

(b) For a bus connection (when the A7GT-BUS Version A is being used)

① When the connected station is an AnUCPU (The connected station can be monitored.)

- The control station and all ordinary stations on the network can be monitored.
- If the connected station is an intermediate station, the unit number to which the network number being monitored is connected should be set using the data link parameter called "Unit No. Effective When Accessing Other Stations".
- Other networks cannot be monitored.

② When the connected station is an AnA or AnNCP (The connected station can be monitored.)

- The control station on the network can be monitored.
- Ordinary stations on the network cannot be monitored.
- Other networks cannot be monitored.

(c) For CPU direct connections

- ① When the connected station is a QnACPU
 - The access range described in (a) ① applies.
- ② When the connected station is an AnUCPU
 - The access range described in (b) ① applies.
- ③ When the connected station is an AnA or AnNCPU
 - The access range described in (b) ② applies.


(d) For MELSECNET/10 connections

- The control station and all ordinary stations on the network can be monitored.
- Other networks cannot be monitored.

POINT

Even with access ranges for which monitoring is possible, it cannot be done if the CPU being monitored is a QnACPU.


(Example 1) For bus connections (A7GT-BUS Version B, A7GT-BUS 2 Version A or all subsequent versions)



Station being accessed Station connected to GOT	Network No. 1				Network No. 2			
	AnU (1-1)	QnA (1-2)	AnA (1-3)	AnU (1-4)	QnA (2-1)	AnU (2-2)	AnN (2-3)	AnU (2-4)
AnU (1-1)	○ Host station	X	○	○	X	○	X	○
QnA (1-2)	○	X Host station	X	○	X	○	X	○
AnA (1-3)	○	X	○ Host station	X	X	X	X	X
AnU (1-4) (2-2)	○	X	X	○ Host station	X	○ Host station	X	○
QnA (2-1)	○	X	X	○	X Host station	○	○	○
AnN (2-3)	X	X	X	X	X	X	○ Host station	X
AnU (2-4)	○	X	X	○	X	○	X	○ Host station

○ : Can be accessed
 X : Can't be accessed


(Example 2) For bus connections (A7GT-BUS Version B, A7GT-BUS 2 Version A or all subsequent versions)



Station being accessed Station connected to GOT	Network No. 1			Network No. 2				Data link system		
	QnA (1-1)	AnA (1-2)	QnA (1-3)	AnU (2-1)	QnA (2-2)	GOT (2-3)	AnU (2-4)	QnA (M)	QnA (L1)	AnA (L2)
QnA (1-1)	X Host station	O	X	O	X	—	O	X	X	X
AnA (1-2)	X	O Host station	X	X	X	—	X	X	X	X
QnA (1-3) QnA (2-2) (M)	X	X	X Host station	O	X Host station	—	O	X Host station	X	O
AnU (2-1)	X	X	X	O Host station	X	—	O	X	X	X
GOT (2-3)	X	X	X	O	X	—	O	X	X	X
AnU (2-4)	X	X	X	O	X	—	O Host station	X	X	X
QnA (L1)	X	X	X	X	X	—	X	X	X Host station	X
AnA (L2)	X	X	X	X	X	—	X	X	X	O Host station

O : Can be accessed
X : Can't be accessed

(Example 3) For bus connections (when using a QnACPU with A7GT-BUS Version B, A7GT-BUS 2 Version A or each later version, or when using an AnUAnA or AnNCPU with A7GT-BUS Version A)




*1. The data link parameter called "Unit No. Effective When Accessing Other Station" should be set to the unit number connected to Network No. 1

Station being accessed Station connected to GOT	Network No. 1				Network No. 2			
	AnU (1-1)	QnA (1-2)	AnA (1-3)	AnU (1-4)	QnA (2-1)	AnU (2-2)	AnN (2-3)	AnU (2-4)
AnU (1-1)	○ Host station	X	○	○	X	X	X	X
QnA (1-2)	○	X Host station	X	○	X	○	X	○
AnA (1-3)	○	X	○ Host station	X	X	X	X	X
AnU (1-4) (2-2)	○	X	X	○ Host station	X	○ Host station	X	X
QnA (2-1)	○	X	X	○	X Host station	○	○	○
AnN (2-3)	X	X	X	X	X	X	○ Host station	X
AnU (2-4)	X	X	X	X	X	○	X	○ Host station

○ : Can be accessed
X : Can't be accessed

(Example 4) For bus connections (when using a QnACPU with A7GT-BUS Version B, A7GT-BUS 2 Version A or each later version, or when using an AnUAnA or AnNCPU with A7GT-BUS Version A)



- Monitoring access ranges of devices of other networks (other than B and W) and other networks


Station being accessed Station connected to GOT	Network No. 1			Network No. 2				Data link system		
	QnA (1-1)	AnA (1-2)	QnA (1-3)	AnU (2-1)	QnA (2-2)	GOT (2-3)	AnU (2-4)	QnA (M)	QnA (L1)	AnA (L2)
QnA (1-1)	X Host station	○	X	○	X	—	○	X	X	X
AnA (1-2)	X	○ Host station	X	X	X	—	X	X	X	X
QnA (1-3) (2-2) (M)	X	X	X Host station	○	X Host station	—	○	X Host station	X	○
AnU (2-1)	X	X	X	○ Host station	X	—	○	X	X	X
GOT (2-3)	X	X	X	○	X	—	○	X	X	X
AnU (2-4)	X	X	X	○	X	—	○ Host station	X	X	X
QnA (L1)	X	X	X	X	X	—	X	X	X Host station	X
AnA (L2)	X	X	X	X	X	—	X	X	X	○ Host station

○ : Can be accessed
X : Can't be accessed

(Example 5) For CPU direct connection and calculator link connection

- The monitoring access range is the same as that listed in Example 3 and Example 4.

(Example 6) For MELSECNET/10 connections



Station being accessed / Station connected to GOT	QnA (1-1)	QnA (1-2)	GOT (1-3)	AnU (1-4)
GOT (1-3)	X	X	—	O

O : Can be accessed
 X : Can't be accessed

3.2 System Monitor Function Specifications

3.2.1 PC CPUs which can be monitored

For PC CPUs which can be monitored, please refer to page 1.2.


3.2.2 Access ranges which can be monitored

(1) Access Ranges for Data Link Systems That Can be Monitored

(a) With bus connections, CPU direct connections, and calculator link connections


① When the connected station is the master station (The connected station can be monitored.)

- Local stations can be monitored.
If the PC CPU of the local station is the QnACPU, however, the only devices which can be monitored are the B and W devices assigned with the link parameter.




② When the connected station is a local station (The connected station can be monitored.)

- The master station can be monitored.
If the PC CPU of the master station is the QnACPU, however, the only devices which can be monitored are the B and W devices assigned with the link parameter.
- Other local stations cannot be monitored.




③ If the connected station is a tri-layer master station (The connected station can be monitored.)

- Dual-layer master stations and tri-layer local stations can be monitored.
If the PC CPU of the station being monitored is the QnACPU, however, the only devices which can be monitored are the B and W devices assigned with the link parameter.
- Dual-layer local stations cannot be monitored.



(b) With MELSECNET (II) connections and MELSECNET/B connections

- The GOT acts as a local station, and only the master station can be monitored. If the PC CPU of the master station is the QnACPU, however, the only devices which can be monitored are the B and W devices assigned with the link parameter.



- Local stations cannot be monitored.

When settings are entered for the monitor device, the settings for the NW number and station number should be entered as shown below.

When monitoring the B and W devices assigned with the link parameter:


Set NW number to 0 and local station to host station

When monitoring any device other than the B and W devices assigned with the link parameter:

Set NW number to 0 and station number to other station (station number: 0)

(c) Setting the monitor device

The following illustration shows an example of how the NW number and station numbers are set when setting a monitor device.



- ① When monitoring a connected station (host station) and the B and W devices assigned with the link parameter

Set NW number to 0 and local station to host station

- ② When monitoring devices of another station

Set NW number to 0 and local station to (see table below).

Station being accessed / Station connected to GOT	M	L1	L2 m	L3	l1	l2	l3
M	Host station	Other station 1	Other station 2	Other station 3	—	—	—
L1	Other station 0	Host station	—	—	—	—	—
L2 m	Other station 0	—	Host station	—	Other station 1	Other station 2	—
L3	Other station 0	—	—	Host station	—	—	—
l1	—	—	Other station 0	—	Host station	—	—
l2	—	—	Other station 0	—	—	Host station	—
l3 (GOT)	—	—	Other station 0	—	—	—	—

(2) Access Ranges for Network Systems That Can be Monitored

(a) For a bus connection (when the A7GT-BUS Version B, the A7GT-BUS2 Version A or each later version is being used)

- ① When the connected station is a QnACPU or AnUCPU (The connected station can be monitored.)
- The control station and all ordinary stations on the network can be monitored.
 - The control station and all ordinary stations on another network can be monitored. (When monitoring another network, always set the routine parameters.)
 - If the connected station is an intermediate station and is mixed with a data link system, the master station and local stations can be monitored.
 - If the connected station is an intermediate station, the data link parameters for the "Unit No. Effective When Accessing Other Stations" (other than the B and W devices assigned with the network parameter) do not need to be set in the PC CPU of the connected station. (If set, the settings will be ignored.)
 - When the devices of another station (other than the B and W devices assigned with the network parameter) are being monitored, there may be times when monitoring cannot be done, depending on the PC CPU of the station being monitored.

 See (Example 1), (Example 2).

② When the connected station is an AnA, or AnNCP (The connected station can be monitored.)

- The control station on the network can be monitored.
If the PC CPU of the control station is a QnACPU, however, the only devices which can be monitored are the B and W devices assigned with the network parameter.
- Ordinary stations on the network cannot be monitored.
- Other networks cannot be monitored.

(b) For a bus connection (when the A7GT-BUS Version A is being used)

When using the A850GOT, the A7GT-BUS Version A cannot be used.

When using the A870GOT and the connected station is a QnACPU, the A7GT-BUS Version A cannot be used.

- ① When the connected station is an AnUCPU (The connected station can be monitored.)
- The control station and all ordinary stations on the network can be monitored. When the devices of another station (other than the B and W devices assigned with the network parameter) are being monitored, however, monitoring cannot be done if the PC CPU of the station being monitored is a QnACPU.
 - If the connected station is an intermediate station, the unit number to which the network number being monitored is connected should be set using the data link parameter called "Unit No. Effective When Accessing Other Stations".

② When the connected station is an AnA or AnNCPU (The connected station can be monitored.)

- The control station on the network can be monitored.

If the PC CPU of the control station is a QnACPU, however, the only devices which can be monitored are the B and W devices assigned with the network parameter.

- Ordinary stations on the network cannot be monitored.
- Other networks cannot be monitored.

(c) For CPU direct connections or calculator link connections

① When the connected station is a QnACPU

- The access range described in (a) 1 applies.

② When the connected station is an AnUCPU

- The access range described in (b) 1 applies.

③ When the connected station is an AnA or AnNCPU

- The access range described in (b) 2 applies.

(d) For MELSECNET/10 connections


- The GOT acts as an ordinary station, and the control station and all ordinary stations on the network can be monitored.

However, if the PC CPU being monitored is a QnACPU, monitoring can be done within the AnA device range.

- Other networks cannot be monitored.
- When monitoring devices of other stations (other than the B and W devices assigned with the network parameter), there may be times when monitoring cannot be done, depending on the PC CPU of the station being monitored.

 See (Example 6).

(Example 1) For bus connections (A7GT-BUS Version B, A7GT-BUS 2 Version A or all subsequent versions)



- Monitoring access ranges of devices of other networks (other than B and W) and other networks

Station being accessed Station connected to GOT	Network No. 1				Network No. 2			
	AnU (1-1)	QnA (1-2)	AnA (1-3)	AnU (1-4)	QnA (2-1)	AnU (2-2)	AnN (2-3)	AnU (2-4)
AnU (1-1)	○ Host station	X	○	○	X	○	X	○
QnA (1-2)	○	○ Host station	X	○	○	○	X	○
AnA (1-3)	○	X	○ Host station	X	X	X	X	X
AnU (1-4) (2-2)	○	X	X	○ Host station	X	○ Host station	X	○
QnA (2-1)	○	○	X	○	○ Host station	○	○	○
AnN (2-3)	X	X	X	X	X	X	○ Host station	X
AnU (2-4)	○	X	X	○	X	○	X	○ Host station

○ : Can be accessed
X : Can't be accessed

- Setting NW numbers and station numbers when setting monitor devices
 - (1) When monitoring the B and W devices of the connected station (host station) assigned with the network parameter


Set the NW number to 0 and the station number to the host station.

- (2) When monitoring another station (other than B and W) or another network

Station being accessed Station connected to GOT	Network No. 1				Network No. 2			
	AnU (1-1)	QnA (1-2)	AnA (1-3)	AnU (1-4)	QnA (2-1)	AnU (2-2)	AnN (2-3)	AnU (2-4)
AnU (1-1)	0, host station	—	1, other station (3)	1, other station (4)	—	2, other station (2)	—	2, other station (4)
QnA (1-2)	1, other station (1)	0, host station	—	1, other station (4)	2, other station (1)	2, other station (2)	—	2, other station (4)
AnA (1-3)	0, other station (0)	—	0, host station	—	—	—	—	—
AnU (1-4) (2-2)	1, other station (1)	—	—	0, host station	—	0, host station	—	2, other station (4)
QnA (2-1)	1, other station (1)	1, other station (2)	—	1, other station (4)	0, host station	2, other station (2)	2, other station (3)	2, other station (4)
AnN (2-3)	—	—	—	—	—	—	0, host station	—
AnU (2-4)	1, other station (1)	—	—	1, other station (4)	—	2, other station (2)	—	0, host station

How to read the table: $\frac{2}{\uparrow}$, $\frac{\text{other station (2)}}{\uparrow}$
 NW no. setting Station no. setting

(Example 2) For bus connections (A7GT-BUS Version B, A7GT-BUS 2 Version A or all subsequent versions)



- Monitoring access ranges of devices of other networks (other than B and W) and other networks

Station being accessed Station connected to GOT	Network No. 1			Network No. 2				Data link system		
	QnA (1-1)	AnA (1-2)	QnA (1-3)	AnU (2-1)	QnA (2-2)	GOT (2-3)	AnU (2-4)	QnA (M)	QnA (L1)	AnA (L2)
QnA (1-1)	○ Host station	○	○	○	○	—	○	○	×	×
AnA (1-2)	×	○ Host station	×	×	×	—	×	×	×	×
QnA (1-3) QnA (2-2) (M)	○	×	○ Host station	○	○ Host station	—	○	○ Host station	×	○
AnU (2-1)	×	×	×	○ Host station	×	—	○	×	×	×
GOT (2-3)	×	×	×	○	△	—	○	△	×	×
AnU (2-4)	×	×	×	○	×	—	○ Host station	×	×	×
QnA (L1)	×	×	×	×	×	—	×	×	○ Host station	×
AnA (L2)	×	×	×	×	×	—	×	×	×	○ Host station

○: Can be accessed
 △: Access possible within AnA range (for T/C, the range is 0 ~ 255)
 ×: Can't be accessed


- Setting NW numbers and station numbers when setting monitor devices
 - (1) When monitoring the B and W devices of the connected station (host station) assigned with the network parameter
Set the NW number to 0 and the station number to the host station.
 - (2) When monitoring another station (other than B and W) or another network

Station being accessed Station connected to GOT	Network No. 1			Network No. 2				Data link system		
	QnA (1-1)	AnA (1-2)	QnA (1-3)	AnU (2-1)	QnA (2-2)	GOT (2-3)	AnU (2-4)	QnA (M)	QnA (L1)	AnA (L2)
QnA (1-1)	0, host station	1, other station (2)	1, other station (3)	2, other station (1)	2, other station (2)	—	2, other station (4)	1, other station (3) or 2, other station (2)	—	—
AnA (1-2)	—	0, host station	—	—	0, host station	—	—	—	—	—
(1-3) QnA (2-2) (M)	1, other station (1)	—	0, host station	2, other station (2)	0, host station	—	2, other station (4)	0, host station	—	0, other station (2) *1
AnU (2-1)	—	—	—	0, host station	—	—	2, other station (4)	—	—	—
GOT (2-3)	—	—	—	0, other station (1)	0, other station (2)	—	0, other station (4)	0, other station (2)	—	—
AnU (2-4)	—	—	—	2, other station (1)	—	—	0, host station	—	—	—
QnA (L1)	—	—	—	—	—	—	—	—	0, host station	—
AnA (L2)	—	—	—	—	—	—	—	—	—	0, host station

*1 When monitoring a data link system, set the NW No. to 0.

How to read the table: $\frac{2}{\uparrow}$, $\frac{\text{other station (2)}}{\uparrow}$
 NW no. setting Station no. setting

(Example 3) For bus connections (when using a QnACPU with A7GT-BUS Version B, A7GT-BUS 2 Version A or each later version, or when using an AnUAnA or AnNCPU with A7GT-BUS Version A)



*1. The data link parameter called "Unit No. Effective When Accessing Other Station" should be set to the unit number connected to Network No. 1.

- Monitoring access ranges of devices of other networks (other than B and W) and other networks

Station being accessed Station connected to GOT	Network No. 1				Network No. 2			
	AnU (1-1)	QnA (1-2)	AnA (1-3)	AnU (1-4)	QnA (2-1)	AnU (2-2)	AnN (2-3)	AnU (2-4)
AnU (1-1)	○ Host station	X	○	○	X	X	X	X
QnA (1-2)	○	○ Host station	X	○	○	○	X	○
AnA (1-3)	○	X	○ Host station	X	X	X	X	X
AnU (1-4) (2-2)	○	X	X	○ Host station	X	○ Host station	X	X
QnA (2-1)	○	○	X	○	○ Host station	○	○	○
AnN (2-3)	X	X	X	X	X	X	○ Host station	X
AnU (2-4)	X	X	X	X	X	○	X	○ Host station

○ : Can be accessed
X : Can't be accessed

- Setting NW numbers and station numbers when setting monitor devices
 - (1) When monitoring the B and W devices of the connected station (host station) assigned with the network parameter


Set the NW number to 0 and the station number to the host station.

- (2) When monitoring another station (other than B and W) or another network

Station being accessed Station connected to GOT	Network No. 1				Network No. 2			
	AnU (1-1)	QnA (1-2)	AnA (1-3)	AnU (1-4)	QnA (2-1)	AnU (2-2)	AnN (2-3)	AnU (2-4)
AnU (1-1)	0, host station	—	0, other station (3)	0, other station (4)	—	0, other station (4)	—	—
QnA (1-2)	1, other station (1)	0, host station	—	1, other station (4)	2, other station (1)	2, other station (2)	—	2, other station (4)
AnA (1-3)	0, other station (0)	—	0, host station	—	—	—	—	—
AnU (1-4) (2-2)	0, other station (1)	—	—	0, host station	—	0, host station	—	—
QnA (2-1)	1, other station (1)	1, other station (2)	—	1, other station (4)	0, host station	2, other station (2)	2, other station (3)	2, other station (4)
AnN (2-3)	—	—	—	—	—	—	0, host station	—
AnU (2-4)	—	—	—	—	—	0, other station (2)	—	0, host station

How to read the table: $\frac{2}{\uparrow}$, $\frac{\text{other station (2)}}{\uparrow}$
 NW no. setting Station no. setting

(Example 4) For bus connections (when using a QnACPU with A7GT-BUS Version B, A7GT-BUS 2 Version A or each later version, or when using an AnUAnA or AnNCPU with A7GT-BUS Version A)



- Monitoring access ranges of devices of other networks (other than B and W) and other networks

Station being accessed Station connected to GOT	Network No. 1			Network No. 2				Data link system		
	QnA (1-1)	AnA (1-2)	QnA (1-3)	AnU (2-1)	QnA (2-2)	GOT (2-3)	AnU (2-4)	QnA (M)	QnA (L1)	AnA (L2)
QnA (1-1)	○ Host station	○	○	○	○	—	○	○	×	×
AnA (1-2)	×	○ Host station	×	×	×	—	×	×	×	×
QnA (1-3) QnA (2-2) (M)	○	×	○ Host station	○	○ Host station	—	○	○ Host station	×	○
AnU (2-1)	×	×	×	○ Host station	×	—	○	×	×	×
GOT (2-3)	×	×	×	○	△	—	○	△	×	×
AnU (2-4)	×	×	×	○	×	—	○ Host station	×	×	×
QnA (L1)	×	×	×	×	×	—	×	×	○ Host station	×
AnA (L2)	×	×	×	×	×	—	×	×	×	○ Host station

○ : Can be accessed
 △ : Access possible within AnA range (for T/C, the range is 0 ~ 255)
 × : Can't be accessed

- Setting NW numbers and station numbers when setting monitor devices
 - (1) When monitoring the B and W devices of the connected station (host station) assigned with the network parameter

Set the NW number to 0 and the station number to the host station.

- (2) When monitoring another station (other than B and W) or another network

Station being accessed Station connected to GOT	Network No. 1			Network No. 2				Data link system		
	QnA (1-1)	AnA (1-2)	QnA (1-3)	AnU (2-1)	QnA (2-2)	GOT (2-3)	AnU (2-4)	QnA (M)	QnA (L1)	AnA (L2)
QnA (1-1)	0, host station	1, other station (2)	1, other station (3)	2, other station (1)	2, other station (2)	—	2, other station (4)	1, other station (3) 2, other station (2)	—	—
AnA (1-2)	—	0, host station	—	—	—	—	—	—	—	—
(1-3) QnA (2-2) (M)	1, other station (1)	—	0, host station	2, other station (1)	0, host station	—	2, other station (4)	0, host station	—	0, other station (2) *1
AnU (2-1)	—	—	—	0, host station	—	—	2, other station (4)	—	—	—
GOT (2-3)	—	—	—	0, other station (1)	0, other station (2)	—	0, other station (4)	0, other station (2)	—	—
AnU (2-4)	—	—	—	2, other station (1)	—	—	0, host station	—	—	—
QnA (L1)	—	—	—	—	—	—	—	—	0, host station	—
AnA (L2)	—	—	—	—	—	—	—	—	—	0, host station

*1 When monitoring a data link system, set the NW No. to 0.


How to read the table: $\underset{\uparrow}{2}$, $\underset{\uparrow}{\text{other station (2)}}$
 NW no. setting Station no. setting

(Example 5) For CPU direct connection and calculator link connection

- The monitoring access range for devices of other stations (other than B and W) and other networks is the same as that listed in Example 3 and Example 4.
- Setting the NW number and station number for monitor devices

The settings for the NW number and station number for monitor devices are the same as those listed in Example 3 and Example 4.

(Example 6) For MELSECNET/10 connections



- Monitoring access ranges for devices of other stations (other than B and W)

Station being accessed / Station connected to GOT	QnA (1-1)	QnA (1-2)	GOT (1-3)	AnU (1-4)
GOT (1-3)	△	△	—	○

○ : Can be accessed
 △ : Access possible within AnA range (for T/C, the range is 0 ~ 255)
 x : Can't be accessed

- Setting NW numbers and station numbers when setting monitor devices

(1) When monitoring the B and W devices of the connected station (host station) assigned with the network parameter

Set the NW number to 0 and the station number to the host station.

(2) When monitoring another station (other than B and W)

Station being accessed / Station connected to GOT	QnA (1-1)	QnA (1-2)	GOT (1-3)	AnU (1-4)
GOT (1-3)	0, other station (1)	0, other station (2)	—	0, other station (4)

How to read the table: $\underset{\uparrow}{0}$, $\underset{\uparrow}{\text{other station (2)}}$
 NW no. setting Station no. setting

3.2.3 Names of devices which can be monitored

(1) With a MELSEC-ACPU

Bit devices which can be monitored

Device name	Range of monitors which can be set
Input (X)	X0 ~ X1FFF
Output (Y)	Y0 ~ Y1FFF
Internal relay (M)	M0 ~ M8191
Annunciator (F)	F0 ~ F2047
Link relay (B)	B0 ~ B1FFF
Special internal relay (M)	M9000 ~ M9255
Timer	T0 ~ T2047
Counter	C0 ~ C1023
Word device bit	Specified bit of word device noted above (except for index register and buffer memories)
GOT bit register (GB)	GB0 ~ 1023

Word devices which can be monitored

Device name	Range of monitors which can be set	
Data register (D)	D0 ~ D8191	
Special data register (D)	D9000 ~ D9255	
Link register (W)	W0 ~ W1FFF	
Timer (current value) (T)	T0 ~ T2047	
Counter (current value) (C)	C0 ~ C1023	
File register (R)	R0 ~ R8191	
Expanded file register (ER)	Block	1 ~ 255
	Device	R0 ~ R8191
Index register (Z)	(Z)	Z0 ~ Z6 (Z0 = Z)
	(V)	V0 ~ V6 (V0 = V)
Accumulator (A)	A0 ~ A1	
Buffer memory (special function unit) (BM)	BM0 ~ BMn (*1)	
GOT data register (GD)	GD0 ~ GD1023	

*1. This can be specified only for the special function unit of a station connected to the A870GOT.

It should be specified as a value within the address range of the buffer memory existing in the applicable special function unit.

(2) With a MELSEC-QnACPU

Bit devices which can be monitored

Device name	Range of monitors which can be set
Input (X)	X0 ~ X1FFF
Output (Y)	Y0 ~ Y1FFF
Internal relay (M)	M0 ~ M32767
Annunciator (F)	F0 ~ F32767
Link relay (B)	B0 ~ B7FFF
Timer	T0 ~ T32767
Counter	C0 ~ C32767
Special relay (SM)	SM0 ~ SM2047
Word device bit	Specified bit of word device noted above (except for index register and buffer memories)
GOT bit register (GB)	GB0 ~ 1023

Word devices which can be monitored

Device name	Range of monitors which can be set	
Data register (D)	D0 ~ D32767	
Special register (SD)	SD0 ~ SD2047	
Link register (W)	W0 ~ W7FFF	
Timer (current value) (T)	T0 ~ T32767	
Counter (current value) (C)	C0 ~ C32767	
File register (R)	R0 ~ R32767 (*1)	
Expanded file register (ER)	Block	0 ~ 31
	Device	R0 ~ 32767
Expanded file register (ZR)	ZR0 ~ ZR1042431 (*2)	
Index register (Z)	Z0 ~ Z15	
Buffer memory (special function unit) (BM)	BM0 ~ BMn (*3)	
GOT data register (GD)	GD0 ~ GD1023	

*1. This applies to the file registers of blocks switched using the RSET instruction.

*2. This applies to the file registers of blocks switched using the QFRSET instruction.

*3. This can be specified only for the special function unit of a station connected to the A879GOT.

It should be specified as a value within the address range of the buffer memory existing in the applicable special function unit.

3.2.4 Precautions When Using the System Monitor Function

The precautions to follow when using the system monitor function are shown below.

(1) Monitor and test of real number data

Real number data cannot be monitored or tested.


Monitoring of word devices that save real number data is all done by integer data (binary data).

(2) Monitoring in 32-bit units

When monitoring word devices (such as T, C, D, W) in 32-bit (2-word) units, monitor up to the point where 32 bits remain in the monitor processing. A location where 16 bits (1 word) remain cannot be monitored.

This situation occurs when an odd number has been specified as the initial number in the monitor device.

(Example) When monitoring the A2NCPU data register in 32-bit units beginning with an odd number (D1, D3...):



3.3 Special Unit Monitor Function Specifications

3.3.1 Access ranges which can be monitored

(1) With a bus connection, CPU direct connection, or calculator link connection

- A special function unit on the base of a connected station can be monitored.
- Special function units on the bases of other stations cannot be monitored.

(2) With a MELSECNET (II) connection or MELSECNET/B connection

- A special function unit on the base of a master station can be monitored.
- Special function units on the bases of local stations cannot be monitored.

(3) With a MELSECNET/10 connection

- A special function unit on the base of a control station can be monitored.
- Special function units on the bases of ordinary stations cannot be monitored.

3.3.2 Special Function Units That Can Be Monitored

The units for which special function monitoring can be done are only those types shown in Section 3.3.3.

Monitoring of special function units other than those can be done with the system monitor function "BM Monitor".

3.3.3 Memory Capacity Required for Using the Special Unit Monitor Function

The memory capacity required when saving special unit monitor data to the A870GOT built-in memory and the memory capacity required when saving to a PC hard disk are shown below.

(Unit: kilobytes)

Software to be saved	Memory capacity required when saving to A870GOT built-in memory	Memory capacity required when saving to PC hard disk	Remarks
Special unit monitor data		---	
A61LS		20.0	
AD61		11.0	
A62DA-S1		8.1	
S62LS		95.0	
A68AD (S2)		12.0	
A68ADN		19.0	
A68RD3		22.0	
A68RD4			
A616AD		140.0	
A616DAI		20.0	
A616DAV		20.0	By merely downloading either, both sides can be monitored.
A616TD		260.0	
AD70		28.0	
AD70D		40.0	
AD71 (S1/S2/S7)		740.0	
AD72		750.0	
A1SD71-S2 (S7)			
AD75P1 (P2/P3)		470.0	
AJ71PT32-S3		63.0	
AJ71ID1 (ID2)-R4		43.0	
A84AD		26.0	
A1SD61		51.0	
S1S62DA		4.1	
A1S62RD		16.0	
A1S63ADA		22.0	
A1S64AD		15.0	
A1S68AD		12.0	

Software to be saved	Memory capacity required when saving to A870GOT built-in memory	Memory capacity required when saving to PC hard disk	Remarks
Special unit monitor data	—	—	—
A1S68DAI	16.0		By merely downloading either, both sides can be monitored.
A1S68DAV	16.0		
A1SD70	28.0		—
A1SJ71JPT32-S3	63.0		
A1SJ71 (ID1)(ID2)-R4	43.0		
A1SD75P1 (P2/P3)	470.0		
Input unit	0.0		
Output unit	0.0		

3.3.4 Precautions When Using the Special Unit Monitor Function

The precautions to follow when using the special unit monitor function are discussed below.

(1) Special function units that cannot be monitored

Units displayed as "special" on the system configuration screen cannot be monitored using the special unit monitor function.

To monitor these units, use the system monitor function "BM Monitor".

(2) Display when connecting the small building-block type PC CPU

This precaution pertains to a situation where an expansion base unit for a building block type of setup is connected to a small building-block type CPU (such as the A1SCPU) in a station connected to the A870GOT.

In such a case, the special function unit on the expansion base unit is displayed on the system configuration screen with the same model name as that of the small building-block type special function unit.

If there is no small building-block type special function unit, "special" is displayed and the applicable unit cannot be monitored.

(Example)

With the AD70, "A1SD70" is displayed on the system configuration screen.

(3) Monitoring restricted special function units

(a) When monitoring the AD71 (S1, S2, S7)

When the slot on front of the AD71 unit is an empty slot, monitoring is done in the following way.

- ① The AD71 is treated as the AD72, and "AD72" is displayed on the system configuration screen.

In this case, when monitoring the AD71, select the AD72 in the applicable display position.

- ② The monitor screen that is displayed by 1) above is for the AD72.

The number obtained by subtracting 10H from the I/O signal number on the display is the number to be used when installing the AD71 in the 0 slot.

- * If you do not want the AD71 to be treated as the AD72, execute "Shift the installation position of AD71 forward" or "In the I/O assignments, assign the empty slot in front of AD71 to the 16 X-Y points."

(b) When monitoring the AD61 installed in the small building-block type PC CPU

With the A870GOT, the AD61 that is installed in the expansion base unit for the building-block type setup connected to the small building-block type CPU (such as the A1SCPU) is recognized as the A1SD61 and monitored as such.

Since the buffer memory composition of the AD61 and the A1SD61 is not the same, different data is displayed on the screen when monitoring the AD61.

- * An AD61 that is installed in the base unit of the building-block type PC CPU (such as the AnUCPU) can be monitored normally.

(c) When monitoring the A81CPU

The A81CPU is monitored in the following way.

	64 points in first half	64 points in last half
Treatment of A81CPU	Change to unit that cannot be monitored.	Change to input unit.
System configuration screen	Display "X, Y <input]"<="" td="" type="checkbox"/> <td>Display "Input 64 X <input]"<="" td="" type="checkbox"/> </td>	Display "Input 64 X <input]"<="" td="" type="checkbox"/>
Possibility of monitoring	Not possible	Can be monitored as input.

(d) When monitoring an I/O composite unit

- 1) With an I/O composite unit for which "Output


For the input signal, monitor X of the PC CPU device with the system monitor function.

(4) Editing and allocating of special unit monitor data.

Monitor screen data for the special unit monitor function cannot be edited and cannot be allocated to monitor screens created by the user. Monitoring should be done using the various monitor functions as they are set when the unit is shipped.

Circuit Monitor Function Operation Manual

The Circuit Monitor Function Operation Manual gives a summary of the procedures for using the circuit monitor function and describes the method of operating the circuit monitor function.




4. Operating Procedures for the Circuit Monitor Function

The operating procedures to follow when using the circuit monitor function are explained in the following sections.

4.1 Operating Procedures Before Starting Circuit Monitoring


This section contains a summary of the procedures for transmitting the system program (OS) for the circuit monitor function from the PC to the A870GOT until it is installed in the built-in memory.

For details, please refer to the A8GOTP Operating Manual (Data Transmission, Debugging, Document Creation Manual). Details of the screen display and key operation are shown below.



4.2 Operating Procedure from Display of User-Created Monitor Screen to Start of Circuit Monitoring

This section shows the operating procedures for the A870GOT when starting each operation of the circuit monitor function after the circuit monitor function system program (OS) has been installed in the A870GOT built-in memory.



*1 With the graphics software, touch the key where the touch switch (expanded) function is set, and start the circuit monitor function.

When the Utility Menu screen is displayed, start the circuit monitor function by touching **LADDER MON.**

5. Operating the Various Circuit Monitor Screens

The following sections describe each screen operation when using the circuit monitor function.

5.1 Screen Operation and Screen Changes When Monitoring

This section includes an explanation of the PC read operation that reads out the sequence program from the PC CPU when executing the circuit monitor, the circuit read operation that specifies the sequence program to be displayed on the circuit monitor screen, and the screen movement when executing the circuit monitor.

5.1.1 Reading Data From the PC


The operation of reading the sequence program for the circuit monitor from the PC CPU is described below.

All of the keys used with the operation are touch keys displayed on the screen. Touch the position where the applicable key is displayed and enter the data.


POINT

If circuit readout has been specified with the graphic settings software, this step does not need to be carried out. When circuit readout has been specified, touch the icon for the circuit monitor on the Utility screen, or touch the key specifying the touch key (expanded) function. If key words have been specified in the PC CPU, however, please be aware that the circuit monitor screen will not be displayed even if circuit readout is specified; instead, the PC readout screen will be displayed.

[Operation procedure]



PCRD. (Touch)



* When there is a at the upper left of the screen, touch it to return to the original screen.


When the circuit monitor function starts up, execution begins from the specified operation with the network no. and PC no. of the applicable PC CPU noted below.

When the screen below is currently displayed, it is not necessary to touch this.

(1) Specify the network no. and PC no. for the applicable PC CPU. (*1)

(For data link system)

- Network no. : 0
- PC no. : FF (Host station)
- 0 (Master station)
- 1-64 (Local stations)




POINT

Once this data has been read from the PC, it does not need to be read again. If data for screens created by the user is downloaded from the computer after this data has been read, however, the data will have to be read again.

5.1.2 Circuit Read Operation

This section describes the applicable sequence program of the circuit monitor that is read from the PC CPU, for the operation displayed on the circuit monitor screen.


[Operation procedure]



* When there is a at the upper left of the screen, touch it to return to the original screen.

Menu (Touch)


When the screen below is currently displayed it is not necessary to touch this.



The circuit read operation is executed.



When specifying and reading the device, contact point or coil used in the program

(Touch any of these.)




(When entering device name)

(When entering device no.)



: Select input area.
Character : Enter network no. and PC no. (*1)

(Touch: Input confirmation) → Move to circuit monitor screen (*2)



*1 Data being entered can be cleared by the following keys.

AC : Clears all data being entered to the target area.

DEL : Clears one character at the cursor position.


*2 When specifying and reading a device, contact point or coil used in the program, the search targets all programs starting from the step number displayed on the previous circuit monitor screen, to the program immediately previous to the one displayed.

After moving to the screen monitor screen, continuous reading by the same device is enabled by touching **↵** on the screen.

If you touch any other key but **↵**, the continuous read function is cancelled.

5.1.3 Changing From One Screen to Another

This section describes the screen movements when executing the circuit monitor from the status where the user-created monitor screen is displayed.



*1 Touch the key where the touch switch (expanded) function was set with the graphics software, and start the system monitor function.

When the Utility Menu screen is displayed, touch **LADDER MON.** to start the system monitor function.


The system monitor function and special unit monitor function can also be started from the Utility Menu screen.

5.2 Circuit Monitor

The circuit monitor screen display and the keys that are shown at the top of the screen are explained in this section.

5.2.1 Circuit Monitor Screen Display and Key Functions

(1) Display



When comment is not displayed: maximum 8 lines
 When comment is displayed : maximum 3 lines

ON/OFF status display for circuit monitor

- ON status :
- OFF status :

* The MCR command is normally displayed as

①	Sequence program is displayed. A maximum of 11 contact points is displayed in one line of a circuit; for 12 contact points or more, move to the next line. When a comment display is specified, a comment is also displayed; expanded comments are given priority. (For the method of displaying comments, see Sec. 5.2.2.)
②	A maximum of eight devices is displayed for the word device current value, timer and counter current value (upper row), and set value (lower row). When the set value is an indirect specification, the value of the indirectly specified device is displayed. (To switch between decimal and hexadecimal for the displayed value, see Sec. 5.2.2.)
③	Display the keys used with the operation on the circuit monitor screen shown in (2). (Touch input)

(2) Key functions

This table shows the key functions used with the operations on the circuit monitor screen.

Key	Function
	Return to screen where circuit monitor function starts.
	Move to PC Read screen to read sequence program being monitored from PC CPU. (PC read)
	Move to circuit monitor menu screen, to specify sequence program to be displayed on circuit monitor screen. (Circuit read)
	Start monitoring of sequence program that is displayed on circuit monitor screen.
	Switch display device when there are nine or more devices displaying current values and set values.
	Display one circuit; scroll up or down.
	When reading circuit with device specification, read next program with same device specification. (See *2 in Sec. 5.1.2.)

POINT

After executing PC Read, if the PC CPU comment or comment capacity is changed, the comment may not be correctly displayed on the circuit monitor screen.

When changing the comment or comment capacity, re-start the A870GOT.

5.2.2 Switching the Display Form (Decimal/Hexadecimal) and Turning the Comment Display On/Off

You can switch the display form (decimal/hexadecimal) of the word device value or the timer/counter value that is displayed on the circuit monitor screen. You can also specify whether or not to display a comment for the applicable device.

① Switching the display form (decimal/hexadecimal)


When monitoring, display the word device current value, the timer/counter current value (upper row) or the set value (lower row) in decimal or hexadecimal. (When decimal is displayed, the display changes to hexadecimal.)

② Switching the comment display on and off

Display the comment that is written in the applicable PC CPU. (When no comment is displayed, this turns on the comment display. Comment display priority order: expansion comment > Japanese character comment or Japanese kana comment)

The display change operation is explained below.

[Operation procedure]




* When there is a  at the upper left of the screen, touch it to return to the original screen.

When the screen below is currently displayed it is not necessary to touch this.


Touch the appropriate display position on the circuit monitor menu.

Move to circuit monitor screen..... After moving to the circuit monitor screen, the word device value is monitored when you touch **Mon.**

(When changing to hexadecimal display)



(When changing to comment display)




6. Error Display and Handling With Circuit Monitoring

The following chart shows the error messages that are displayed during the circuit monitor operation and the method of handling them.

Error Message	Description	Method of Handling
Keywords do not match.	The specified keyword is different from the keyword that is registered in the applicable PC CPU.	Check the keyword that is registered in the applicable PC CPU and specify again.
No applicable program	An attempt was made to switch to the circuit monitor screen when a sequence program had not been read.	Read the sequence program that is written in the applicable PC CPU. (Ex.) A sub-sequence program can only be specified as A3□CPU/A4UCPU.
Cannot communicate with CPU	Cannot communicate with CPU of the specified network no. or PC no.	Check and correct the following: (1) Does the specified PC CPU exist? (2) Is it online? (Data communication status?) (3) Has an error occurred?

System Monitor Function Operation Manual

In the System Monitor Function Operation Manual, the overall procedures for using the system monitor function and the method of operating the system monitor function are explained.




7. Operation Procedure for the System Monitor Function

The operation procedure for using the system monitor function is explained in this section.

7.1 Operation Procedure Before Starting System Monitoring


This section contains a summary of the procedure for transmitting the system program (OS) for the system monitor function from the PC to the GOT until it is installed in the built-in memory.

For details, please refer to the A8GOTP Operation Manual (Data Transmission, Debugging, Document Creation Manual). Details of the screen display and key operation are shown below.



7.2 Operation Procedure from User-Created Monitor Screen Display to Start of System Monitoring

This section explains the operating procedure for the GOT when starting each operation of the system monitor function, after the system program (OS) of the system monitor function has been installed in the GOT built-in memory.



*1 Touch the key where the touch switch (expanded) function was set with the graphics software, and start the system monitor function.

When the Utility Menu screen is displayed, touch **PC. MON.** to start the system monitor function.

8. Operation of the Various System Monitor Screens

This chapter contains an explanation of each screen operation when using the system monitor function.

POINT

If the A870GOT is being used, with any of the four windows, when using the station/monitor device or executing the test operation, it is not possible to do an operation with another window until that series of operations is finished.

8.1 Screen Configuration, Common Operations and Changing Screens When Monitoring


The common operations of each monitor function such as screen configuration and target PC CPU specification when executing system monitoring are described below.

8.1.1 Basic Screen Configuration and Key Functions (Menu)

The basic screen configuration displayed in the windows and the key functions displayed on the screen are shown below.

With the A870GOT, the following four windows are displayed. (One A85□ is displayed.)

(1) Display



(2) Key functions

The functions of keys that are used with the basic screen operation are shown in the chart below.

Key	Function
ENT MON	The entry monitor is executed with the applicable window. (See Sec. 8.2.)
BAT MON	The batch monitor is executed with the applicable window. (See Sec. 8.3.)
TC MON	The timer/counter monitor is executed with the applicable window. (See Sec. 8.4.)
BM MON	The buffer memory monitor is executed with the applicable window. (See Sec. 8.5.)
END	System monitoring ends; display returns to screen for starting system monitor function.

8.1.2 Switching the Display Form (Decimal/Hexadecimal) and Turning the Comment Display On/Off (FORM)

(1) Switching the display form (decimal/hexadecimal)

Display the word device present value or the timer/counter present value or set value in decimal or hexadecimal.

(2) Switching the comment display on and off

Display the comment that is written in the applicable PC CPU. (Comment display priority order: expanded comment > Japanese character comment or Japanese kana comment)

(When changing to hexadecimal display)

ENTRY MONITOR [MENU] [FORM] [SET]			
NETWK No.[0]		STATION[FF]	
D	15	H	80000000
D	10	H	8001
X	001	●	
M	25	○	
Y	70	●	
W	200	H	002B
R	50	H	04135
C	200	H	7000


(When changing to comment display)

ENTRY MONITOR [MENU] [FORM] [SET]			
NETWK No.[0]		STATION[FF]	
D	200	50	▲
	[Production line A]	
W	200	43	
	[Production quantity]		
R	50	68378428	DW
	[link status]	
X	10	100	
	[Production line B]	▼

Below is an explanation of the operation for changing the display, using the Entry Monitor window as an example.

The operating procedure is the same for changing the display when selecting windows other than Entry Monitor.

[Operation procedure]




When you touch **MENU** you return to the basic screen.

When you touch **SET**, the monitor station and device can be specified. (See Sec. 8.1.3.)

When you touch **FORM**, you can change this display.

FORM (Touch)



The selected **FORM** display is also found on the screen displayed after selecting the monitor function with the basic screen and on each menu screen, in addition to each monitor screen.

Display monitor station network no. and station.

* When you touch **STOP**, the display change is interrupted and the display returns to the monitor screen.

(Change display form.)

(Change comment display)

(1) Touch the display position of the selected menu.

DEC HEX

YES NO

EXEC (Touch)

(Return)
Monitor screen

POINT

After starting the system monitor, if the PC CPU comment or comment capacity is changed, the comment may not be correctly displayed on each monitor screen. When changing the comment or comment capacity, re-start the GOT.

8.1.3 Specifying the Monitor Station and Device (SET)

An explanation of the procedure for specifying the monitor station and the device for executing the system monitor is explained below, using the Entry Monitor window as an example.

The operation procedure is the same for specifying the monitor station and device when selecting windows other than Entry Monitor.

* When there is a  (keywindow), touching it to returns to the monitor screen.

[Operation procedure]

Select monitor function with basic screen.
Or, display  monitor screen or  menu screen.

..... See Sec. 8.1.1.
..... See the explanatory section for each monitor screen and the menu screen.

ENTRY MONITOR				MENU	FORM	SET
NETWK No.[0]		STATION[FF]				
D	15	-2147483648		DW		
D	10	-32767				
X	001	●				
M	25	○				
T	30	100	200	1	○	
W	200	43				
R	50	68378428		DW		
C	5	300	300	■	●	

..... When you touch  you return to the basic screen.

When you touch , you can change this display. (See Sec. 8.1.2.)


When you touch , you can specify the monitor station and device.

 (Touch)

ENTRY MONITOR			MENU	FORM	SET
NETWK No.[0]		STATION[FF]			
ENTRY	DELETE	ALL CLR			
TEST					
STOP					

 (Touch)

①



(1) Specify network no. and station of applicable PC CPU.

(*1)

(For data link system)

Network no. : 0
 Station : FF (Host station)
 0 (Master station)
 1-64 (Local station)

(For network system)

Network No.: 0 (Host loop)
 1-255 (Specified loop)
 Station : FF (Host station)
 0 (Control station)
 1-64 (Normal station)

(2) Specify the device to be monitored.


(3) When specifying the word device or buffer memory as a monitor device, specify the monitor unit.

0: 16-bit (1-word) unit
 1: 32-bit (2-word) unit

* Match the data to be entered; the touch key display at the bottom of the screen will change.

(Ex.)

(When entering network no.)



(When entering device no.)



*1 For the station, with either system specify "FF", which shows the PC CPU to be accessed, or "0" ~ "64".

*2 Data being entered can be cleared by the following keys.

[AC] : Clears all data being entered to the target area.

[DEL] : Clears one character at the cursor position.

*3 The form of data to be entered is displayed at the right side of the screen.

[DEC] : Enter in decimal

[HEX] : Enter in hexadecimal


8.2 Entry Monitor

Enter the device to be monitored in advance. The function that monitors only the device that was entered is called the "entry monitor".

The entry monitor operation when executing the system monitor function is explained below.

8.2.1 Basic Operation

The entry monitor operation procedure is shown below.



8.2.2 Entry Monitor Screen Display and Key Functions

In this section, the Entry Monitor screen display and the functions of the keys displayed at the top of the screen are explained.

(1) Display

①	<div style="border: 1px solid black; padding: 5px; display: inline-block;"> ENTRY MONITOR MENU FORM SET </div>	
②	NETWK No.[0] STATION[FF]	
③	D 200 30 [Line 1 current units] ▲ W 200 43 [Production line A] R 50 68378428 DW [link status] X 3 ● [Input switch 3] ▼	When comment is not displayed: max. 8 devices When comment is displayed: max. 4 devices Display for system monitor * Bit device ●: ON ○: OFF * Word device Current value

①

①	Displays the keys that are used with the operation of the Entry Monitor screen shown in (2). (Touch input)
②	Displays the monitor station network no. and station.
③	Displays the status and current value of the entry device.

(2) Key functions

Shows the functions of the keys that are used with the operation of the Entry Monitor screen.

Key	Function
MENU	Move to basic screen (function change menu screen) to change to another monitor function or ending the system monitor. (See Sec. 8.1.1.)
FORM	Move to the display change menu screen to change the numerical display on the Entry Monitor screen (decimal, hexadecimal) or changing the comment display (on/off). (See Sec. 8.1.2.)
SET	Move to device setting menu screen to enter the monitor device, delete the entry device, or execute a test. * Entry of monitor device (See Sec. 8.1.3.) * Deletion of entry device (See Sec. 8.2.3.) * Test (See Sec. 8.6.)
▲ ▼	Scroll the display up or down one line, and display the monitor device that is not displayed (just before or after the current display). When a monitor device with five or more points is entered, operation is enabled when the monitor device comment is displayed. ▼ : Scrolls down one line. ▲ : Scrolls up one line.

8.2.3 Deleting a Registered Device

The operation of deleting (erasing) the entry of the device being monitored with the Entry Monitor screen is explained below.

The following two methods can be used to delete the registered device.


- * Random deletion Deletes only one specified device.
- * Batch deletion Deletes all devices that are currently registered.

* If there is a  at the upper left of the screen, touching the  returns to the monitor screen.

[Operation procedure]


Display Entry Monitor screen. See Sec. 8.2.2.

SET (Touch)



(Batch deletion)
ALL CLR

(Random deletion)
DELETE (Touch either key.)



(1) Specify the device to be deleted.

* Match the data to be entered; the touch key display at the bottom of the screen will change.

*1 Data being entered can be cleared by the following keys.

AC : Clears all data being entered to the target area.

DEL : Clears one character at the cursor position.


8.3 Batch Monitor

When monitoring, the function of specifying the device at the beginning of an optional device range and monitoring it is called the "batch monitor".

The batch monitor operation when executing the system monitor is explained below.

8.3.1 Basic Operation

The batch operation procedure is shown below.



8.3.2 Batch Monitor Screen Display and Key Functions

In this section, the Batch Monitor screen display and the functions of keys displayed at the top of the screen are explained.

(1) Display

BATCH MONITOR		MENU	FORM	SET	
②	NETWK No.[0]	STATION[FF]			①
	D 10	32767	[
	D 11	0	[Inventory quantity		
	D 12	0	[Shipment quantity		
	D 13	-1]		
	D 14	0	[Warehouse A temperature		
③	D 15	3	[Warehouse B temperature		
	D 16	0]		
	D 17	0	[Production plan		
]		

①

When comment is not displayed: max. 16 devices
When comment is displayed: max. 8 devices
Display for system monitor
* Bit device●: ON ○: OFF
* Word device Current value

①	Displays the keys that are used with the operation of the Batch Monitor screen shown in (2). (Touch input)
②	Displays the monitor station network no. and station no.
③	Displays the status and current value of the monitor device (when the monitor unit in the screen above is 16 bits).

(2) Key functions

The chart below shows the functions of the keys that are used with the operation of the Batch Monitor screen.

Key	Function
MENU	Move to basic screen (function change menu screen) for changing to another monitor function or ending the system monitor. (See Sec. 8.1.1.)
FORM	Move to display change menu screen for changing the numerical display on the Batch Monitor screen (decimal/ hexadecimal) or changing the comment display (on/off). (See Sec. 8.1.2.)
SET	Move to device setting menu screen to change the monitor device or execute a test. <ul style="list-style-type: none"> • Change of monitor device (See Sec. 8.1.3.) • Test (See Sec. 8.6.)
<div style="display: flex; gap: 10px;"> ▲ ▼ </div>	Scroll the display up or down one line, and display the monitor device that is not displayed (just before or after the current display). <ul style="list-style-type: none"> ▼ : Scrolls down one line. ▲ : Scrolls up one line.


8.4 TC Monitor

The function that monitors only the timer (T) and counter (C) when monitoring is called the TC monitor.

The TC monitor operation when executing the system monitor is explained below.

8.4.1 Basic Operation

The TC operation procedure is shown below.



See Sec. 8.1.1.

When a screen other than the basic screen is displayed, touch **MENU** at the top of the currently displayed screen, display the basic screen, and select "TC Monitor".

When you touch **MENU**, you return to the basic screen.

When you touch **FORM**, you can change this display. (See Sec. 8.1.2.)

When you touch **SET**, the monitor station and device can be specified. (See Sec. 8.1.3.)

(1) Specify the station and device to be monitored.

For the method of specifying, see Sec. 8.1.3.

Do if needed.

For the display change method, see Sec. 8.1.2.

8.4.2 TC Monitor Screen Display and Key Functions

In this section, the TC Monitor screen display contents and the function of keys displayed at the top of the screen are explained.

(1) Display

The screenshot shows the TC Monitor screen with the following layout:

- Top bar: **TC MONITOR** | MENU | FORM | SET
- Line 1: NETWORK No.[0] STATION[33]
- Line 2: T 0 PV 0 SV 0 | + | - | ○ | ▲
- Line 3: [Production line A]
- Line 4: T 1 PV 0 SV 0 | + | - | ○ | -
- Line 5: [Production line B]
- Line 6: T 2 PV 150 SV 150 | ■ | ● | -
- Line 7: [Production line C]
- Line 8: T 3 PV 0 SV 0 | + | - | ○ | ▼
- Line 9: [Production line D]

Annotations:

- ①: Points to the MENU, FORM, and SET keys at the top.
- ②: Points to the NETWORK No. and STATION information.
- ③: Points to the device status information (T, PV, SV, current value, set value, and status icons).

When comment is not displayed: max. 8 devices
 When comment is displayed: max. 4 devices
 Display when system monitor
 * T/C current value, set value
 (Contact point, coil) + ● - : ON
 + ○ - : OFF

①	Displays the keys that are used with the operation of the TC Monitor screen shown in (2). (Touch input)
②	Displays the monitor station network no. and station no.
③	Displays the current value, set value, contact point and coil status of the monitor device (when the monitor unit in the screen above is 16 bits).

(2) Key functions

The chart below shows the function of the keys that are used with the operation of the TC Monitor screen.

Key	Function
MENU	Move to basic screen (function change menu screen) for changing to another monitor function or ending the system monitor. (See sec 8.1.1.)
FORM	Move to display change menu screen for changing the numerical display on the TC monitor screen (decimal/hexadecimal) or changing the comment display (on/off). (See Sec. 8.1.2.)
SET	Move to device setting menu screen to change the monitor device or execute a test. <ul style="list-style-type: none"> • Change of monitor device (See Sec. 8.1.3.) • Test (See Sec. 8.6.)
▲ ▼	Scroll the display contents up or down one line to display the monitor device that is not displayed (just before or after the current display). Operation is enabled when monitor device comment is displayed. <ul style="list-style-type: none"> ▼ : Scrolls down one line. ▲ : Scrolls up one line.


8.5 BM Monitor

When monitoring, the function that monitors the buffer memory of the special function unit is called the "BM monitor".

The BM monitor operation when executing the system monitor is explained below.

8.5.1 Basic Operation

The BM operation procedure is shown below.



8.5.2 BM Monitor Screen Display and Key Functions

In this section, the BM Monitor screen display and the functions of keys displayed at the top of the screen are explained.

(1) Display

BM MONITOR		MENU	FORM	SET
②	NETWK No.[0] I/O NO [1]	STATION[FF]		①
	BM 1110 -32768	BM 1118	0	Displays current values of a maximum of 16 devices
	BM 1111 64	BM 1119	0	
	BM 1112 149	BM 1120	150	
	BM 1113 -1111	BM 1121	131	
③	BM 1114 126	BM 1122	-32768	
	BM 1115 160	BM 1123	555	
	BM 1116 255	BM 1124	2368	
	BM 1117 1200	BM 1125	11000	

①	Displays the keys that are used with the operation of the BM Monitor screen shown in (2). (Touch input)
②	Displays the monitor station network no. and station no. and the first 2 digits of the I/O signal no. of the applicable unit.
③	Displays the current values of the buffer memory (when the monitor unit in the screen above is 16 bits).

(2) Key functions

The chart below shows the functions of the keys that are used with the operation of the BM Monitor screen.

Key	Function
MENU	This moves to the basic screen (function change menu screen) for changing to another monitor function or ending the system monitor. (See Sec. 8.1.1.)
FORM	This moves to the display change menu screen for changing the number display on the BM monitor screen (decimal/ hexadecimal). (See Sec. 8.1.2.)
SET	This moves to the device setting menu screen to change the monitor device or execute a test. <ul style="list-style-type: none"> • Change of monitor device (See Sec. 8.1.3.) • Test (See Sec. 8.6.)

8.6 Test

When monitoring with the system monitor function, you can specify an optional station or device that can be monitored and test it.

The operation of testing a bit device, word device, or special unit buffer memory of the PC CPU is explained in this section.

8.6.1 Basic Operation

The basic operation for testing when monitoring with the system monitor function is shown below.

[Operation procedure]

When monitoring with the system monitor function, display any monitor screen.

ENTRY MONITOR				MENU	FORM	SET
NETWK No.[0]		STATION[FF]				
D	15	-2147483648	DW			
D	10	-32767				
X	001					
	25					

SET (Touch)

Display device setting menu screen.

ENTRY MONITOR				MENU	FORM	SET
NETWK No.[0]		STATION[FF]				
ENTRY	DELETE	ALL CLR				
TEST						
STOP						

TEST (Touch)

Display test menu screen.

ENTRY MONITOR				MENU	FORM	SET
NETWK No.[0]		STATION[FF]				
SET/RST	VALUE16	BM VAL16				
SET VAL	VALUE32	BM VAL32				
STOP						

①


See sec 8. 2.

When a screen other than the monitor screen is displayed, display any monitor screen according to the explanatory section for each monitor function.


When Entry Monitor screen is displayed

When you touch STOP, the display moves (returns) to the previous monitor screen.


When you touch STOP, the display moves (returns) to the previous monitor screen.



When **SET/RST** is selected.



When **VALUE16** / **VALUE32** is selected.



(1) Touch either, depending on test contents.

SET/RST

SET/RST (set/reset) bit device.

VALUE16 or **VALUE32**

Change current value of word device.

SET VALUE

Change T, or C set value.


BM VAL16 or **BM VAL32**

Change current value of buffer memory.

* With VALUE16 or BM VAL16, 16 bits is the applicable unit.

With VALUE32 or BM VAL32, 32 bits is the applicable unit.

When **SET VALUE** is selected.



(2) Specify the network no. and station no. of the applicable PC CPU.

(See Sec. 8.1.3, *1.)

(For data link system)

Network no. : 0

Station : FF (Host station)

0 (Master station)

1-64 (Local station)

(For network system)

Network no. : 0 (Host loop)

1-255 (Specify loop)

Station : FF (Host station)

0 (Control station)

1-64 (Normal station)

(3) Specify applicable device.

(4) Specify test value.

- With SET/RST (set/reset) of bit device, specify 0 (RST) or 1 (SET).

- When changing current value of word device
When changing T or C set value, or when changing current value of buffer memory
Match current display form (decimal/hexadecimal) and specify change value. (*3)

Arrow : Select input area
(▶ ◀) : Left/right
Character : Enter network no., station, device name, device no., test value.
(*1)(*2)

(Touch: input confirmation)

Move (return) to screen where **SET** was specified.


9. Error Display and Handling With System Monitoring

The following chart shows the error messages that are displayed during the system monitor operation and the method of handling them.

Error Message	Description	Method of Handling
PC communications error	Communication could not be established with the PC CPU.	Check the following: <ul style="list-style-type: none">• Connections between the PC CPU and the GOT (disconnected or cut cables).• Has an error occurred in the PC CPU ?

Special Unit Monitor Function Operation Manual

The Special Unit Monitor Function Operation Manual contains a summary of the procedures for using the special unit monitor function and the method of operating the special unit monitor function.




10. Operation Procedure for Special Unit Monitor Function

The operation procedure when using the special unit monitor function is explained in this chapter.

10.1 Operation Procedure Before Starting Special Unit Monitoring


This section contains a summary of the procedure for transmitting the system program (OS) for the special unit monitor function and the special unit monitor data from the PC to the A870GOT until it is installed in built-in memory.

For details, please refer to the A8GOTP Operating Manual (Data Transmission, Debugging, Document Creation Manual). Details of the screen display and key operation are shown below.



10.2 Operation Procedure From User-Created Monitor Screen Display to Start of Special Unit Monitor

This section describes the operation procedure for the A870GOT when starting each operation of the special unit monitor function after the system program (OS) of the special unit monitor function has been installed in the A870GOT built-in memory, and downloading the special unit monitor data.



*1 Touch the key where the touch switch (expanded) function was set with the graphics software, and start the system monitor function.

When the Utility Menu screen is displayed, touch [SP. UNIT] to start the special unit monitor function.

11. Operation of Each Special Unit Monitor Screen

Each screen operation when using the special unit monitor function is explained in this chapter.


11.1 Screen Configuration, Common Operation and Changing Screens When Monitoring

The screen configuration and common operations used when executing the special unit monitor are explained in this section.

11.1.1 Composition of System Configuration Screen and Key Functions

This section describes the structure of the system configuration screen that is displayed after starting the special unit monitor function and the key functions displayed on the screen.

(1) Display



The unit format and related data are displayed at the end of the unit data read-out from the PC CPU.

(OS is automatically executed.)

①	Displays network no. and station no. of monitor station.
②	With the unit installed in the monitor station, the special function unit displays the format and the initial no. of the I/O signal with the sequencer CPU; the I/O unit displays "Input"/"Output" and the I/O points. For a special function unit that cannot be monitored, "Special" and the initial no. of the I/O signal are displayed. The display position of the unit is the key for moving the special function unit monitor of that unit to the screen where it is executed. (Touch input)
③	The keys used for the operation with the System Configuration screen shown in (2) are displayed. (Touch input)

(2) Key functions


The chart below shows the functions of keys that are used with the System Configuration screen operation.

Key	Function
END	Monitor ends, and display returns to the screen where the special unit monitor function was begun.
Unit display position	Moves to screen where the special unit monitor for that unit is executed. Slots 0 through 7 are valid for each base unit.
▲ ▼	Scrolls display up or down one level to display the system configuration of the level number just before or after the one that is currently displayed. Operation of these keys is enabled when the system configuration extends to three levels or more. ▼ : Scrolls down one level. ▲ : Scrolls up one level.

11.1.2 Monitor Screen Configuration and Key Functions

This section describes the structure of the monitor screen that is displayed by specifying the unit with the system configuration screen, and the key functions that are displayed at the top of the screen.

(1) Display (with A68RD)



All types of data are displayed when the readout from the special function unit is complete. (OS is automatically executed.)

①	Displays format of unit being monitored.
②	Displays buffer memory data of applicable unit in its current form, or in a graph. Display status of I/O signal with the PC CPU. When testing, tests after moving the cursor to the display position of the target data.
③	The keys used for the operation with the monitor screen shown in (2) are displayed. (Touch input)

(2) Key Functions

Monitor screen operation is used to indicate the function of the key to be used.

Key	Function
END	Monitoring ends; display returns to the screen where the special unit monitor function was begun.
MONIT MENU	Ends current monitoring and moves to screen that shows monitor menu. Operation can be used only if the special function unit has a Monitor menu.
Data Chg.	Starts change of current values for buffer memory of special function unit displayed on screen.
SET / RESET	Starts test set/reset for I/O signal between PC CPU and special function unit.

11.1.3 Specifying Monitor Unit and Selecting Monitor Menu

The operation when starting the special unit monitor for an optional unit is explained, using the positioning unit (AD71) as an example.


[Operation procedure]

Display System Configuration screen. See Sec. 11.1.1.

Specify unit to be monitored (Touch display position of unit).

- (1) From the units assigned to slots 0 through 7 of each base unit, specify the special function unit where the format is displayed.


* For units where the format is not displayed, monitor with the system monitor function. (See Sec. 8.5.)



- (2) Specify the menu corresponding to the type of data to be monitored.

- (3) With units for which the monitor menu cannot all be displayed in one screen, touch the ▲ ▼ keys at the right of the screen to scroll the display menu.

Specify menu to be monitored (Touch display position of menu).



- (4) Check the contents of the display. Carry out the subsequent operation according to Secs. 11.2 ~ 11.26.

- (5) Carry out tests for the displayed data according to Sec. 11.1.4.

- Change current value of buffer memory
- Turn output signal from PC CPU on and off.

Proceed to Sec. 11.1.4 and Secs. 11.2 ~ 11.26.

11.1.4 Test for Special Function Unit




You can test the data displayed on the current monitor screen.

This section describes the operation for changing the current value of the buffer memory and turning the output signal from the PC CPU to the special function unit on and off.

POINT

- (1) When testing, test for the buffer memory that can be written in from the PC CPU and the output signal that is output from the PC CPU.
- (2) Be sure to carry out the test operation with the PC CPU in STOP status.
If the PC CPU is tested during RUN status, it returns to the output values and output status from the sequence program.

[Operation procedure]



When **Data Chg.** is touched (changes current value of buffer memory)


- All of the following operations can be carried out by touching the keys in the displayed key window.
- When you touch  at the upper left of the key window, the key window closes and the display returns to the monitor screen.

- (1) Move the cursor to the position where the data to be tested is displayed. (*1)
(  : Up/down   : Left/right)
- (2) Use the numeric keys to specify the value to be changed. (*2)
The **DEL** key can be used to clear individual characters among those input.

When **SET / RESET** is touched (tests the I/O signal)

- All of the following operations can be carried out by touching the keys in the displayed key window.
- When you touch  at the upper left of the key window, the key window closes and the display returns to the monitor screen.

- (1) Use the alphabetic character keys to specify the name of the device to be tested, and then touch . (*1)



*1 Do not perform the following tests.

When testing, the unit may not operate correctly or the buffer memory/input signal may return to the output value/output status from the special function unit.

- ① Read out from the PC CPU and test the special purpose buffer memory.
- ② Test the input signal to the PC CPU from the special function unit.

*2 When testing buffer memory data, specify the change value in the following way.

- ① For data where 16/32 bits is displayed with one number, specify the change value in decimal.
- ② For data where one number of 16/32 bits is displayed as a percent, such as with an A/D conversion unit, specify the change value corresponding to the percentage in decimal.

Ex:

When the set value of the offset or gain is 0 ~ 2000, when specifying a change value of 50%, input 1000.

- ③ For data where 16 bits is displayed one bit at a time as "0" and "1", specify the change value of 16 bits in decimal.


CAUTION

- For a test operation during a run (forced output, data change), read the manual thoroughly and check the safety conditions carefully.

The machine can be damaged or accidents can occur due to operation error.

11.1.5 Changing the Screen

This section describes how to change the screen when executing each monitor function of the special unit monitor function from the status where the user-created monitor screen is displayed.



*1 Touch the key where the touch switch (expanded) function was set with the graphics software, and start the special unit monitor operation.

When the Utility Menu screen is displayed, touch **SP. UNIT** and start the special unit monitor function.

The system monitor function and special unit monitor function can also be started from the Utility Menu screen.

Go to user-created monitor screen or utility screen.

11.2 A61LS Unit Monitor

11.2.1 Operation Monitor

A61LS Operation Monitor Screen				SET/ RESET	Data Chg.	MONIT MENU	END
①	Limit Switch Function Program No. 0		Positioning Data	Set Value A	Set Value B		
②	Channel No.	FEDCBA9876543210	Channel 0	0123	0123		
	Output Status	0110110110110110	Channel 1	0123	0123		
	Output Enable	0110110110110110	Channel 2	0123	0123		
	Status 0:OFF 1:ON Enable 0:Enabled 1:Disabled		Channel 3	0123	0123		
③	Measured Distance	0123456789	Channel 4	0123	0123		
④	Resolver Speed	0123 rpm	Channel 5	0123	0123		
⑤	Target Address	0123	Channel 6	0123	0123		
		Error 01	Channel 7	0123	0123		
⑥	Compensation Val.	0123	Channel 8	0123	0123		
		Underflow 0	Channel 9	0123	0123		
		Overflow 0	Channel A	0123	0123		
⑦	Compensated Address	0123	Channel B	0123	0123		
		Batt.Error 0	Channel C	0123	0123		
		0:Normal 1:Error	Channel D	0123	0123		
			Channel E	0123	0123		
			Channel F	0123	0123		

No.	Contents of display	Buffer memory address to reference (decimal)
①	The number of the program being used is displayed.	11
②	The output status of each channel is displayed.	4
	The specified status for the Output Enable command of each channel is displayed.	10
③	The measured distance value for the distance detection function is displayed.	5, 6
④	The rotation speed of the resolver connected to A61LS is displayed.	3
⑤	The set value of the target address for the positioning function is displayed.	12
⑥	The compensation value for the zero point compensation function is displayed.	7
⑦	The current value of the resolver after compensation by the zero point compensation function is displayed.	0
⑧	The error code is displayed when an error occurs.	8
⑨	When an A61LS resolver underflow is detected, "1" is displayed.	2
	When an A61LS resolver overflow is detected, "1" is displayed.	1
	When a low battery charge is detected, "1" is displayed.	9
⑩	The set values A and B for executing the positioning function are displayed for each channel.	13 ~ 44

11.2.2 I/O Monitor

A61LS Input/Output Monitor Screen				SET/ RESET	Data Chg.	MONIT MENU	END
Inputs (X)				Outputs (Y)			
00	WDT Error	10		00		00	PC READY
01	Online	11		01		01	Posit. Start
02	Overflow Detect.	12		02		02	Limit Func.Start
03	Underflow Detect.	13		03		03	Overflow Reset
04	Resolver Direct.	14		04		04	Underflow Reset
05	Comp. Val. Exceed	15		05		05	Error Reset
06	Resolver Error	16		06		06	
07	Error Detect	17		07		07	
08	CH0 ON/OFF Status	18		08		08	
09	CH1 ON/OFF Status	19		09		09	
0A	CH2 ON/OFF Status	1A		0A		0A	
0B	CH3 ON/OFF Status	1B		0B		0B	
0C	CH4 ON/OFF Status	1C		0C		0C	
0D	CH5 ON/OFF Status	1D		0D		0D	
0E	CH6 ON/OFF Status	1E		0E		0E	
0F	CH7 ON/OFF Status	1F		0F		0F	

①

No.	Contents of display
①	The ON/OFF status of the I/O signal corresponding to the PC CPU is displayed. The I/O signal is ON when displayed in a reverse display.

11.3 AD61 Unit Monitor

11.3.1 Operation Monitor

AD61 Operation Monitor Screen				SET/ RESET	Data Chg.	MONIT MENU	END
Channel 1	Present Value	Set Value	Mode	0	Mode		
Channel 2	01234567 ①	01234567 ②	0 ③	1: 1-Phase			
				2: 2-Phase			
Inputs (X)				Outputs (Y)			
00	CH1 Count Greater	10	00	10	CH1 Equal Reset		
01	CH1 Count Equal	11	01	11	CH1 Preset Cmd.		
02	CH1 Count Less	12	02	12	CH1 Equal O/P		
03	CH1 Ext. Preset	13	03	13	CH1 Down Count		
04	CH2 Count Greater	14	04	14	CH1 Count Enable		
05	CH2 Count Equal	15	05	15	CH1 Value Read		
06	CH2 Count Less	16	06	16	CH1 Ext. Preset		
07	CH2 Ext. Preset	17	07	17	CH2 Equal Reset		
08		18	08	18	CH2 Preset Cmd.		
09		19	09	19	CH2 Equal O/P		
0A		1A	0A	1A	CH2 Down Count		
0B		1B	0B	1B	CH2 Count Enable		
0C		1C	0C	1C	CH2 Value Read		
0D		1D	0D	1D	CH2 Ext. Preset		
0E		1E	0E	1E			
0F		1F	0F	1F			

No.	Contents of display	Buffer memory address to reference (decimal)
①	The current values of channels 1 and 2 are displayed.	4, 5, 36, 37
②	The set values of channels 1 and 2 are displayed.	6, 7, 38, 39
③	The specified status of the mode register of channels 1 and 2 is displayed.	3, 35
④	The ON/OFF status of the I/O signal corresponding to the PC CPU is displayed. The I/O signal is ON when displayed in a reverse display.	—

11.4 A1SD61 Unit Monitor

11.4.1 Operation Monitor

The Channel 1 and 2 Monitor Screen is used as an example.

A1SD61 Operation Monitor Screen (CH1,2)						SET/ RESET	Data Chg.	MONIT MENU	END				
Y10	Count Enable	Y15	Limit Switch Output	Present Value	01234567890	<div style="display: flex; justify-content: space-between;"> ⑦ ⑧ ⑨ ⑩ ⑪ </div>							
Y11	Decremental Count	Y14	Counter Function Start	Counter Function Count Value	01234567890								
Y12	Preset Command	Counter Setting: 0		Preset Value	01234567890								
Y13	Ring Counter	⑤		Ring Counter Value	01234567890								
Y14	Sampling/Periodic	0: No setting 1: Latch counter 2: Sampling counter 3: Periodic pulse counter 4: Counter disable		Pulse I/P Mode	012345								
X08	External Preset	⑥ Channel No.		0: A-Phase I/P and decremental count 1: A-Phase and B-Phase I/P 2: 2-Phase I/P X 1 3: 2-Phase I/P X 2 4: 2-Phase I/P X 4									
Y15	Reset Ext. Preset	LS. O/P Status											
Y17	Error Reset	8 7 6 5 4 3 2 1											
■ WDT Error		■ Error Code: 012		No. of Dogs						ON		OFF	
③		③		0						0		0	
D 0	012345678900	1234567890	D 0	012345678900	1234567890					D 0	012345678900	1234567890	④
O 1	012345678900	1234567890	O 1	012345678900	1234567890	O 1	012345678900	1234567890					
G 2	012345678900	1234567890	G 2	012345678900	1234567890	G 2	012345678900	1234567890					
3	012345678900	1234567890	3	012345678900	1234567890	3	012345678900	1234567890					

No.	Contents of display	Buffer memory address to reference (decimal)
①	The ON/OFF status of the I/O signal corresponding to the PC CPU is displayed. The I/O signal is ON when displayed in a reverse display.	—
②	A "■" is displayed when a watchdog timer error occurs.	—
	A "■" is displayed when a writing data error occurs; the channel where it occurred and the error code are displayed.	11
③	The number of multi-dogs that are set is displayed.	12 ~147
④	The set value for the on position and off position of the multi-dog no. is displayed for each channel.	12 ~147
⑤	The specified status of the counter function selection is displayed.	5
⑥	The limit switch output status of each channel is displayed. 0: OFF 1: ON	—
⑦	The current value of the counter is displayed for the following situations: in pulse input mode, when preset, when the ring counter function is being executed, and when the counter is disabled.	0, 1
⑧	The count value for execution of the latch counter, sampling counter, and periodic pulse counter set with the counter function selection (5) is displayed.	2, 3
⑨	The preset value is displayed.	6, 7
⑩	The ring counter value that was set is displayed.	8, 9
⑪	The set status of the pulse input mode is displayed.	4

11.4.2 I/O Monitor

A1SD61 Input/Output Monitor Screen				SET/ RESET	Data Chg.	MONIT MENU	END
Inputs (X)				Outputs (Y)			
00	WDT Error	10		00		10	Count Enable
01	CH1 LS Output	11		01		11	Decrement Count
02	CH2 LS Output	12		02		12	Preset Command
03	CH3 LS Output	13		03		13	Ring Counter
① 04	CH4 LS Output	14		04		14	Counter Function
05	CH5 LS Output	15		05		15	LS Output
06	CH6 LS Output	16		06		16	Reset Preset
07	CH7 LS Output	17		07		17	Error Reset
08	CH8 LS Output	18		08		18	
09	LS O/P Enable	19		09		19	
0A	Ext. Preset	1A		0A		1A	
0B	Error Flag	1B		0B		1B	
0C	Fuse/Power OFF	1C		0C		1C	
0D	Sampling/Period	1D		0D		1D	
0E		1E		0E		1E	
0F		1F		0F		1F	

No.	Contents of display
①	The ON/OFF status of the I/O signal corresponding to the PC CPU is displayed. The I/O signal is ON when displayed in a reverse display.


11.5 A62DA-S1 Unit Monitor

11.5.1 Operation Monitor

A62DA-S1 Operation Monitor Screen				SET/ RESET	Data Chg.	MONIT MENU	END
Channel 1 Output 01234.6 % ①	Voltage check 0123 Current check ② 0123	Channel 2 Output 01234.6 % ①	Voltage check 0123 Current check ② 0123				
	Inputs (X)		Outputs (Y)				
③	00 WDT Error	10	00	10			
	01 READY	11	01	11			
	02	12	02	12			
	03	13	03	13			
	04	14	04	14			
	05	15	05	15			
	06	16	06	16			
	07	17	07	17			
	08	18	08	18			
	09	19	09	19			
	0A	1A	0A	1A			
	0B	1B	0B	1B			
	0C	1C	0C	1C			
	0D	1D	0D	1D			
	0E	1E	0E	1E			
	0F	1F	0F	1F			
				1B	Output Enable		

No.	Contents of display	Buffer memory address to reference (decimal)
①	The current input value, a value between 0 ~ 4000 for the digital input value of channels 1 and 2, is displayed as a percentage ranging from 0 to 100%.	0, 1
②	"1" is displayed for Output Over when an input value of 4001 or greater was set for channel 1 or 2; "1" is displayed for Output Under when a negative number was set.	2 ~ 5
③	The ON/OFF status of the I/O signal corresponding to the PC CPU is displayed. The I/O signal is ON when displayed in a reverse display.	—


11.5.2 Graph Monitor



No.	Contents of display	Buffer memory address to reference (decimal)
①	The current input value, a value between 0 ~ 4000 for the digital input value of channels 1 and 2, is displayed as a percentage ranging from 0 to 100%.	0, 1
②	A "■" is displayed in the Over Error column when an input value of 4001 or greater was set for channel 1 or 2.	2, 4
③	A "■" is displayed in the Under Error column when an input value consisting of a negative number was set for channel 1 or 2.	3, 5
④	A "■" is displayed when a watchdog timer error occurs.	—

11.6 A1S62DA Unit Monitor

11.6.1 Operation Monitor




No.	Contents of display	Buffer memory address to reference (decimal)
①	The specified enable/disable status for the analog output of each channel is displayed. 0: Enable 1: Disable	0
②	The channel 1 digital input value is displayed.	1
③	The channel 2 digital input value is displayed.	2
④	The ON/OFF status of the I/O signal corresponding to the PC CPU is displayed. The I/O signal is ON when displayed in a reverse display.	—
⑤	The current input value, a value between -4000~4000 for the digital input value of channels 1 and 2, is displayed in a graph as a percentage ranging from 0 to 100%.	1, 2
⑥	The current input value, a value between -8000~8000 for the digital input value of channels 1 and 2, is displayed in a graph as a percentage ranging from 0 to 100%.	
⑦	The current input value, a value between -12000~12000 for the digital input value of channels 1 and 2, is displayed in a graph as a percentage ranging from 0 to 100%.	
⑧	The current input value, a value between 0~4000 for the digital input value of channels 1 and 2, is displayed in a graph as a percentage ranging from 0 to 100%.	1, 2
⑨	The current input value, a value between 0~8000 for the digital input value of channels 1 and 2, is displayed in a graph as a percentage ranging from 0 to 100%.	
⑩	The current input value, a value between 0~12000 for the digital input value of channels 1 and 2, is displayed in a graph as a percentage ranging from 0 to 100%.	
⑪	When the channel 1 digital input value was set outside the allowable setting range, a check code is displayed.	10
⑫	When the channel 2 digital input value was set outside the allowable setting range, a check code is displayed.	11
⑬	The set resolution selection is displayed. 1: 1/4000 2: 1/8000 3: 1/12000	9

11.7 A62LS Unit Monitor

11.7.1 Operation Monitor

As a screen example, we will store the monitor screens from CH. 0 ~ CH. 3 in the memory.



No.	Contents of display	Buffer memory address to reference (decimal)
①	The ON/OFF status of the I/O signal corresponding to the PC CPU is displayed. The I/O signal is ON when displayed in a reverse display.	—
②	The error code is displayed when an error occurs.	7
③	The output status of each channel is displayed. 0: OFF 1: ON	4
	The set limit switch output enable/disable status for each channel is displayed. 0: Enable 1: Disable	8
④	The sensor binary current value is displayed.	2, 3
⑤	After unit conversion of the sensor binary current value to mm or inches, the value added to the minimum current value is displayed as the scaling binary current value.	0, 1
⑥	The set value of the positioning target stop position is displayed.	10, 11
⑦	The program number used with the limit switch output function is displayed.	9
⑧	The answer back program number corresponding to the program number used with the limit switch output function is displayed.	5
⑨	The A62LS operation mode status is displayed. "1" is displayed in the bit corresponding to the selected operation mode.	6
⑩	The number of multi-dogs that are set is displayed.	12 ~ 226
⑪	The set value for the on position and off position of the multi-dog no. is displayed for each channel.	12 ~ 226


11.7.2 I/O Monitor

A62LS Input/Output Monitor Screen				SET/ RESET	Data Chg.	MONIT MENU	END
Inputs (X)				Outputs (Y)			
00	00	WDT Error	20	00	10	00	PC READY
01	01	Online	21	01	11	01	Posit. Start
02	02	Upper Lim.Error	22	02	12	02	Posit. Stop
03	03	Lower Lim.Error	23	03	13	03	Fwd Jog Start
①	04	Sensor Error	24	04	14	04	Rev Jog Start
05	05	Correction Err.	25	05	15	05	LS O/P Enable
06	06	Position Error	26	06	16	06	Error Reset
07	07	Error	27	07	17	07	P1 Disable
08	08	CH 0/8 Status	28	08	18	08	P2 Disable
09	09	CH 1/9 Status	29	09	19	09	
0A	0A	CH 2/10 Status	2A	0A	1A	0A	
0B	0B	CH 3/11 Status	2B	0B	1B	0B	
0C	0C	CH 4/12 Status	2C	0C	1C	0C	
0D	0D	CH 5/13 Status	2D	0D	1D	0D	
0E	0E	CH 6/14 Status	2E	0E	1E	0E	
0F	0F	CH 7/15 Status	2F	0F	1F	0F	

No.	Contents of display
①	The ON/OFF status of the I/O signal corresponding to the PC CPU is displayed. The I/O signal is ON when displayed in a reverse display.

11.8 A1S62RD Unit Monitor

11.8.1 Operation Monitor




No.	Contents of display	Buffer memory address to reference (decimal)
①	The temperature detection value of each channel is displayed up to 1 digit after the decimal point.	10, 11
②	The temperature detection value of each channel is displayed up to 3 digits after the decimal point.	18 ~ 21
③	The values set for the time and count of times for averaging processing of each of the channels is displayed.	2, 3
④	The specified conversion enabled/disabled status of each channel is displayed.	0
⑤	The Conversion Completed flag status for each channel is displayed.	35
⑥	The specified status for the averaging processing/sampling processing of each channel is displayed.	1
⑦	The specified status for the averaging processing of each channel is displayed.	1
⑧	A "■" is displayed when a watchdog timer error occurs. A "■" is displayed when a writing data error occurs; the channel where it occurred and error code are displayed.	— 34
⑨	The specified status of the platinum temperature sensor that is used is displayed.	36
⑩	For A1S62RD3 A "■" is displayed in a channel where broken wire was detected. For A1S62RD4 A "■" is displayed in CH1 when a broken wire is detected in any channel.	—

11.8.2 I/O Monitor

A1S62RD Input/Output Monitor Screen				SET/ RESET	Data Chg.	MONIT MENU	END
Inputs (X)			Outputs (Y)				
00	MDT Error	10	00	10			
01	READY	11	01	11			
02	Error Detection	12	02	12	Error Reset		
03	CH1 Disconnected	13	03	13			
04	CH2 Disconnected	14	04	14			
05		15	05	15			
06		16	06	16			
07		17	07	17			
08		18	08	18			
09		19	09	19			
0A		1A	0A	1A			
0B		1B	0B	1B			
0C		1C	0C	1C			
0D		1D	0D	1D			
0E		1E	0E	1E			
0F		1F	0F	1F			

No.	Contents of display
①	The ON/OFF status of the I/O signal corresponding to the PC CPU is displayed. The I/O signal is ON when displayed in a reverse display.


11.8.3 Graph Monitor



No.	Contents of display	Buffer memory address to reference (decimal)
①	The temperature detection value of each channel is displayed as a graph.	10, 11
②	The specified conversion enabled/disabled status for each channel is displayed.	0
③	The status of the Conversion Complete flag for each channel is displayed.	35
④	The specified status for the averaging processing/sampling processing of each channel is displayed.	1
⑤	The specified status for the averaging processing of each channel is displayed.	1
⑥	A "■" is displayed when a watchdog timer error occurs.	—
	A "■" is displayed when a writing data error occurs; the channel where it occurred and the error code are displayed.	34
⑦	The specified status of the platinum temperature sensor that is used is displayed.	36
⑧	For A1S62RD3 A "■" is displayed in a channel where a broken wire was detected.	—
	For A1S62RD4 A "■" is displayed in CH1 when a broken wire is detected in any channel.	


11.9 A1S63DA Unit Monitor

11.9.1 Operation Monitor



No.	Contents of display	Buffer memory address to reference (decimal)
①	The specified conversion enabled/disabled status for each channel is displayed.	0
②	The Conversion Completed flag status for channels 1 and 2 is displayed.	15
③	The specified status for the averaging processing/sampling processing of channels 1 and 2 is displayed.	1
④	The specified status for the averaging processing of channels 1 and 2 is displayed.	
⑤	The values set for the time and number of times for averaging processing of channels 1 and 2 is displayed.	2, 3
⑥	The current output value, a value between 0 ~ 4000 for the digital output value of channels 1 and 2, is displayed as a percentage ranging from 0 to 100%. (Resolution selection: 2: 0~8000, 3: 0~12000)	11, 12
⑦	The upper limit of the digital value following D/A conversion with channel 3 is displayed.	4
⑧	The lower limit of the digital value following D/A conversion with channel 3 is displayed.	5
⑨	The set value of the digital value following D/A conversion with channel 3 is displayed.	10
⑩	The digital value of channel 3 calculated by simple loop control is displayed.	13
⑪	The error code is displayed when a writing data error occurs.	16
⑫	The set resolution selection is displayed.	14

11.9.2 Simple Loop Monitor



No.	Contents of display	Buffer memory address to reference (decimal)
①	The specified simple loop control execution enabled/disabled status is displayed.	—
②	The control mode set status is displayed.	6
③	The set value of the simple loop control constant is displayed.	7, 8, 9
④	The set values of channel 1 coordinates that were set in each point are displayed.	18 ~ 37
⑤	The set values of channel 3 coordinates that were set in each point are displayed.	
⑥	The number of coordinate points of the simple loop control that was set is displayed.	17
⑦	The error code is displayed when a writing data error occurs.	16
⑧	The set resolution selection is displayed.	14

11.9.3 I/O Monitor

A1S63ADA Input/Output Monitor Screen				SET/ RESET	Data Chg.	MONIT MENU	END
Inputs (X)			Outputs (Y)				
00	WDT Error	10	00	00	10	CH3 Output	
01	Conversion READY	11	01	01	11	Loop Control	
02	Error Detection	12	02	02	12	Error Reset	
03	CH3 Up Limit	13	03	03	13	CH3 Unlimited	
04	CH3 Low Limit	14	04	04	14		
05	Loop Control	15	05	05	15		
06		16	06	06	16		
07		17	07	07	17		
08	Resolution	18	08	08	18	Resol. Selection	
09	Resolution	19	09	09	19	Resol. Selection	
0A	CH1 Volt./Current	1A	0A	0A	1A	CH1 Volt./Current	
0B	CH2 Volt./Current	1B	0B	0B	1B	CH2 Volt./Current	
0C	CH3 Volt./Current	1C	0C	0C	1C	CH3 Volt./Current	
0D		1D	0D	0D	1D	Offset/Gain Set.	
0E		1E	0E	0E	1E		
0F		1F	0F	0F	1F		

①

No.	Contents of display
①	The ON/OFF status of the I/O signal corresponding to the PC CPU is displayed. The I/O signal is ON when displayed in a reverse display.

11.10 A1S64DA Unit Monitor

11.10.1 Operation Monitor

A1S64AD Operation Monitor Screen					SET/ RESET	Data Chg.	MONIT MENU	END
①	Channel No	4321		0: A/D Conversion Disabled 1: A/D Conversion Enabled				
	Setting	0110110110110110						
		Sample/Average	Time/Count	Sample/Average	Time/Count			
②	Chann. No	4321	4321	0: Sampling 1: Averaging		0: Count Average 1: Time Average		
③	Setting	0110110110110110						
		Time/Count Value	Input Status [%] Resolution 1	Input Status [%] Resolution 2	Input Status [%] Resolution 3			
	Channel 1	01234	0123.5	0123.5	0123.5			
	Channel 2	01234	0123.5	0123.5	0123.5			
	Channel 3	01234	0123.5	0123.5	0123.5			
	Channel 4	01234	0123.5	0123.5	0123.5			
		④	⑤					
	Error Code: 012	Resolution Setting 0 [1:1/4000,2:1/8000,3:1/12000]						
					⑥			
					⑦			


No.	Contents of display	Buffer memory address to reference (decimal)
①	The specified conversion enabled/disabled status of each channel is displayed.	0
②	The specified status for the averaging processing/sampling processing of each channel is displayed.	1
③	The specified status for the averaging processing of each channel is displayed.	1
④	The values set for the time and number of times for averaging processing of each channel is displayed.	2 ~ 5
⑤	The current output value, a value between 0 ~ 4000 for the digital output value of each channel, is displayed as a percentage ranging from 0 to 100%. (Resolution selection: 2: 0~8000, 3: 0~12000)	10 ~ 13
⑥	The error code is displayed when a writing data error occurs.	18
⑦	The set resolution selection is displayed.	20

11.10.2 I/O Monitor

A1S64AD Input/Output Monitor Screen				SET/ RESET	Data Chg.	MONIT MENU	END
Inputs (X)			Outputs (Y)				
00	WDT Error Flag	10	00				10
01	READY	11	01				11
02	Error Flag	12	02				12
03		13	03				13
04		14	04				14
05		15	05				15
06		16	06				16
07		17	07				17
08		18	08				18
09		19	09				19
0A		1A	0A				1A
0B		1B	0B				1B
0C		1C	0C				1C
0D		1D	0D				1D
0E		1E	0E				1E
0F		1F	0F				1F

No.	Contents of display
①	The ON/OFF status of the I/O signal corresponding to the PC CPU is displayed. The I/O signal is ON when displayed in a reverse display.

11.10.3 Graph Monitor



No.	Contents of display	Buffer memory address to reference (decimal)
①	The current output value, a value between 0 ~ 4000 for the digital output value of each channel, is displayed in a graph as a percentage ranging from 0 to 100%. (Resolution selection: 2: 0~8000, 3: 0~12000)	10 ~ 13
②	The set resolution selection is displayed. 1: 1/4000 2: 1/8000 3: 1/12000	20
③	A "■" is displayed when a writing data error occurs.	—
④	A "■" is displayed when a watchdog timer error occurs.	—

11.11 A68AD Unit Monitor

11.11.1 Operation Monitor

A68AD Operation Monitor Screen				SET/ RESET	Data Chg.	MONIT MENU	END
	Sample/Average	Time/Count	Sample/Average Count/Time				
①	Channel No.	87654321	87654321	0:Sampling		0:Count Average	
②	Setting	01101101	10110110	1:Averaging		1:Time Average	
	Count/Time Value	Input Status [%]		No. of Channels Used 0			
	Channel 1	01234	01234.6	Writing Data Error 01			
	Channel 2	01234	01234.6				
	Channel 3	01234	01234.6				
	Channel 4	01234 ③	01234.6 ④				
	Channel 5	01234	01234.6				
	Channel 6	01234	01234.6				
	Channel 7	01234	01234.6				
	Channel 8	01234	01234.6				


No.	Contents of display	Buffer memory address to reference (decimal)
①	The specified status for the averaging processing/sampling processing of each channel is displayed.	1
②	The specified status for the averaging processing of each channel is displayed.	1
③	The values set for the time and number of times for averaging processing of each channel is displayed.	2 ~ 9
④	The current output value, a value between 0 ~ 2000 for the digital output value of each channel, is displayed as a percentage ranging from 0 to 100%.	10 ~ 17
⑤	The number of channels that are used is displayed. (With A68AD-S2 monitoring, the display value is invalid.)	0
⑥	The error code is displayed when a writing data error occurs.	34

11.11.2 I/O Monitor

A68AD Input/Output Monitor Screen				SET/ RESET	Data Chg.	MONIT MENU	END
Inputs (X)			Outputs (Y)				
00	WDT Error	10	00		10		
01	READY	11	01		11		
02		12	02		12		
03		13	03		13		
04		14	04		14		
05		15	05		15		
06		16	06		16		
07		17	07		17		
08		18	08		18		
09		19	09		19		
0A		1A	0A		1A		
0B		1B	0B		1B		
0C		1C	0C		1C		
0D		1D	0D		1D		
0E		1E	0E		1E		
0F		1F	0F		1F		

No.	Contents of display
①	The ON/OFF status of the I/O signal corresponding to the PC CPU is displayed. The I/O signal is ON when displayed in a reverse display.

11.11.3 Graph Monitor



No.	Contents of display	Buffer memory address to reference (decimal)
①	The current output value, a value between 0 ~ 2000 for the digital output value of each channel, is displayed in a graph as a percentage ranging from 0 to 100%.	10 ~ 17
②	A "■" is displayed when a watchdog timer error occurs.	—

11.12 A1S68AD Unit Monitor

11.12.1 Operation Monitor

A1S68AD		Movement Monitor Screen								SET/ RESET	Data Chg.	MONIT MENU	END				
	C H		8	7	6	5	4	3	2	1							
①	A/D Conversion		0	1	1	0	1	1	0	1	0 : Disabled	1 : Enabled					
②	A/D Method		0	1	1	0	1	1	0	1	0 : Sampling	1 : Averaging					
③	Averaging		0	1	1	0	1	1	0	1	0 : Number	1 : Time					
④	A/D Conversion		0	1	1	0	1	1	0	1	0 : Incomplete	1 : Complete					
			Averaging Time/Number				Input Status [%]										
	CH 1		0	1	2	3	4				0	1	2	3	4	.6	
	CH 2		0	1	2	3	4				0	1	2	3	4	.6	
	CH 3		0	1	2	3	4				0	1	2	3	4	.6	
	CH 4		0	1	2	3	4				0	1	2	3	4	.6	
	CH 5	⑤	0	1	2	3	4				⑥	0	1	2	3	4	.6
	CH 6		0	1	2	3	4				0	1	2	3	4	.6	
	CH 7		0	1	2	3	4				0	1	2	3	4	.6	
	CH 8		0	1	2	3	4				0	1	2	3	4	.6	
			Error Code								0	1	2				

⑦


No.	Contents of display	Buffer memory address to reference (decimal)
①	The A/D conversion enabled/disabled status of each channel is displayed.	0
②	The specified status for the averaging processing/sampling processing of each channel is displayed.	2
③	The specified status for the averaging processing of each channel (Time/count) is displayed.	2
④	The A/D Conversion Complete flag status for each channel is displayed.	28
⑤	The values set for the time and count of times for averaging processing of each channel is displayed.	10 ~ 17
⑥	The current output value, a value between 0 ~ 2000 for the digital output value of each channel, is displayed as a percentage ranging from 0 to 100%.	20 ~ 27
⑦	The error code is displayed when a writing data error occurs.	1

11.12.2 I/O Monitor

A1S68AD		Input/Output Monitor Screen		SET/ RESET	Data Chg.	MONIT MENU	END
	X		Y				
<input checked="" type="checkbox"/>	WDT Error	10	00				
<input type="checkbox"/>	Ready	11	01				
<input checked="" type="checkbox"/>	Error Detect	12	02			<input checked="" type="checkbox"/>	Error Reset
<input type="checkbox"/>	03	13	03				
<input type="checkbox"/>	04	14	04				
<input type="checkbox"/>	05	15	05				
<input type="checkbox"/>	06	16	06				
<input type="checkbox"/>	07	17	07				
<input type="checkbox"/>	08	18	08				
<input type="checkbox"/>	09	19	09				
<input type="checkbox"/>	0A	1A	0A				
<input type="checkbox"/>	0B	1B	0B				
<input type="checkbox"/>	0C	1C	0C				
<input type="checkbox"/>	0D	1D	0D				
<input type="checkbox"/>	0E	1E	0E				
<input type="checkbox"/>	0F	1F	0F				

No.	Contents of display
①	The ON/OFF status of the I/O signal corresponding to the PC CPU is displayed. The I/O signal is ON when displayed in a reverse display.

11.12.3 Graph Monitor



No.	Contents of display	Buffer memory address to reference (decimal)
①	The current output value, a value between 0 ~ 2000 for the digital output value of each channel, is displayed in a graph as a percentage ranging from 0 to 100%.	20 ~ 27
②	A "■" is displayed when a watchdog timer error occurs.	—

11.13 A68ADN Unit Monitor

11.13.1 Operation Monitor

A68ADN Operation Monitor Screen					SET/ RESET	Data Chg.	MONIT MENU	END
①	Channel Setting	87654321 0110110110110110		0:Disabled		1:Enabled		
		Sample/Average	Count/Time	Sample/Average	Count/Time			
②	Channel Setting	87654321 0110110110110110		0:Sampling		0:Count Average		
③				1:Averaging		1:Time Average		
		Count/Time Value	Input Status [%] Resolution 1	Input Status [%] Resolution 2	Input Status [%] Resolution 3			
	Channel 1	01234	0123.5	0123.5	0123.5			
	Channel 2	01234	0123.5	0123.5	0123.5			
	Channel 3	01234	0123.5	0123.5	0123.5			
	Channel 4	01234 ④	0123.5 ⑤	0123.5	0123.5			
	Channel 5	01234	0123.5	0123.5	0123.5			
	Channel 6	01234	0123.5	0123.5	0123.5			
	Channel 7	01234	0123.5	0123.5	0123.5			
	Channel 8	01234	0123.5	0123.5	0123.5			
	Error Code	012		Resolution Selection 0 [1:1/4000,2:1/8000,3:1/12000]				
		⑥		⑦				


No.	Contents of display	Buffer memory address to reference (decimal)
①	The specified conversion enabled/disabled status of each channel is displayed.	0
②	The specified status for the averaging processing/sampling processing of each channel is displayed.	1
③	The specified status for the averaging processing of each channel is displayed.	1
④	The values set for the time and count of times for averaging processing of each channel is displayed.	2 ~ 9
⑤	The current output value, a value between 0 ~ 4000 for the digital output value of each channel, is displayed as a percentage ranging from 0 to 100%. (Resolution selection: 2: 0~8000, 3: 0~12000)	10 ~ 17
⑥	The error code is displayed when a writing data error occurs.	18
⑦	The resolution selection that was set is displayed.	20

11.13.2 I/O Monitor

A68ADN Input/Output Monitor Screen				SET/ RESET	Data Chg.	MONIT MENU	END
Inputs (X)			Outputs (Y)				
00	WDT Error	10	00	10			
01	READY	11	01	11			
02	Error	12	02	12	Error Reset		
03		13	03	13			
04		14	04	14			
05		15	05	15			
06		16	06	16			
07		17	07	17			
08		18	08	18			
09		19	09	19			
0A		1A	0A	1A			
0B		1B	0B	1B			
0C		1C	0C	1C			
0D		1D	0D	1D			
0E		1E	0E	1E			
0F		1F	0F	1F			

No.	Contents of display
①	The ON/OFF status of the I/O signal corresponding to the PC CPU is displayed. The I/O signal is ON when displayed in a reverse display.

11.13.3 Graph Monitor



No.	Contents of display	Buffer memory address to reference (decimal)
①	The current output value, a value between 0 ~ 4000 for the digital output value of each channel, is displayed as a percentage ranging from 0 to 100%. (Resolution selection: 2: 0~8000, 3: 0~12000)	10 ~ 17
②	The set resolution selection is displayed. 1: 1/4000 2: 1/8000 3: 1/12000	20
③	A "■" is displayed when a writing data error occurs.	—
④	A "■" is displayed when a watchdog timer error occurs.	—

11.14 A68RD Unit Monitor

11.14.1 Operation Monitor

A68RD Operation Monitor Screen				SET/ RESET	Data Chg.	MONIT MENU	END
	Temp. Value (16 bits)	Temp. Value (32 bits)	Time/ Count	Disabled/Enabled 87654321 0110110110110110			
1	0123.5 ①	0123.567 ②	③01234	1: Enabled 0: Disabled			
2	0123.5	0123.567	01234	Conversion 87654321 0110110110110110			
3	0123.5	0123.567	01234	1: Completed 0: Not Completed			
4	0123.5	0123.567	01234	Average/Sample Time/Count 8765432187654321 0110110110110110			
5	0123.5	0123.567	01234	1: Averaging ⑥ 1: Time Average ⑦ 0: Sampling 0: Count Average			
6	0123.5	0123.567	01234	■ CH1 disconn. ■ CH5 disconn. ■ CH2 disconn. ■ CH6 disconn. ■ CH3 disconn. ■ CH7 disconn. ■ CH4 disconn. ■ CH8 disconn.			
7	0123.5	0123.567	01234	■ WDT Error ■ Error Code:012345			
8	0123.5	0123.567	01234	Temp. Sensor Type 0 0:New JIS,DIN 1:Old JIS			

No.	Contents of display	Buffer memory address to reference (decimal)
①	The temperature detection value of each channel is displayed up to 1 digit after the decimal point.	10 ~ 17
②	The temperature detection value of each channel is displayed up to 3 digits after the decimal point.	18 ~ 33
③	The values set for the time and count of times for averaging processing of each channel is displayed.	2 ~ 9
④	The specified conversion enabled/disabled status of each channel is displayed.	0
⑤	The Conversion Complete flag status for each channel is displayed.	35
⑥	The specified status for the averaging processing/sampling processing of each channel is displayed.	1
⑦	The specified status for the averaging processing of each channel is displayed.	1
⑧	A "■" is displayed when a watchdog timer error occurs.	—
	A "■" is displayed when a writing data error occurs; the channel where it occurred and the error code are displayed.	34
⑨	The specified status of the platinum temperature sensor that is used is displayed.	36
⑩	For A68RD3 A "■" is displayed in a channel where a broken wire was detected.	—
	For A68RD4 A "■" is displayed in CH1 when a broken wire is detected in any channel.	—


11.14.2 I/O Monitor

A68RD Input/Output Monitor Screen				SET/ RESET	Data Chg.	MONIT MENU	END
Inputs (X)				Outputs (Y)			
00	WDT Error	10		00		10	
01	READY	11		01		11	
02	Write Data Error	12		02		12	Error Reset
03	CH1 Disconnected	13		03		13	
04	CH2 Disconnected	14		04		14	
05	CH3 Disconnected	15		05		15	
06	CH4 Disconnected	16		06		16	
07	CH5 Disconnected	17		07		17	
08	CH6 Disconnected	18		08		18	
09	CH7 Disconnected	19		09		19	
0A	CH8 Disconnected	1A		0A		1A	
0B		1B		0B		1B	
0C		1C		0C		1C	
0D		1D		0D		1D	
0E		1E		0E		1E	
0F		1F		0F		1F	

①

No.	Contents of display
①	The ON/OFF status of the I/O signal corresponding to the PC CPU is displayed. The I/O signal is ON when displayed in a reverse display.

11.14.3 Graph Monitor



No.	Contents of display	Buffer memory address to reference (decimal)
①	The temperature detection value of each channel is displayed in a graph.	10 ~ 17
②	The specified conversion enabled/disabled status of each channel is displayed.	0
③	The Conversion Complete flag status for each channel is displayed.	35
④	The specified status for the averaging processing/sampling processing of each channel is displayed.	1
⑤	The specified status for the averaging processing of each channel is displayed.	1
⑥	A "■" is displayed when a watchdog timer error occurs. A "■" is displayed when a writing data error occurs; the channel where it occurred and the error code are displayed.	— 34
⑦	The specified status of the platinum temperature sensor that is used is displayed.	36
⑧	For A68RD3 A "■" is displayed in a channel where a broken wire was detected. For A68RD4 A "■" is displayed in CH1 when a broken wire is detected in any channel.	—

11.15 A1S68DAI, A1S68DAV Unit Monitor

The contents displayed on each monitor of the A1S68DAI unit and A1S68DAV unit are nearly identical, except for the sections displaying the unit format.

The A1S68DAV unit monitor screen is used as an example in each of the following sections.

11.15.1 Operation Monitor

A1S68DAV Movement Monitor Screen		SET/ RESET	Data Chg.	MONIT MENU	END
C	H	8 7 6 5 4 3 2 1			
Analog Output		01101101			0 : Disabled 1 : Enabled
		Output Status [%]	Up Limit	Low Limit	
CH	1	012345.7	0	0	
CH	2	012345.7	0	0	
CH	3	012345.7	0	0	
CH	4	012345.7	0	0	
CH	5	012345.7	0	0	
CH	6	012345.7	0	0	
CH	7	012345.7	0	0	
CH	8	012345.7	0	0	
Up/Low Limit		0 : OK	1 : Error		


No.	Contents of display	Buffer memory address to reference (decimal)
①	The analog output enabled/disabled status for each channel is displayed.	0
②	For A1S68DAI: The present input value, a value between 0 ~ 4000 for the digital input value of each channel, is displayed as a percentage ranging from 0 to 100%. For A1S68DAV: The present input value, a value between -2000 ~ 2000 for the digital input value of each channel, is displayed as a percentage ranging from 0 to 100%.	1 ~ 8
③	When the digital input value set for each channel is greater than the allowable value, "1" is displayed.	10 ~ 17
④	When the digital input value set for each channel is less than the allowable value, "1" is displayed.	10 ~ 17

11.15.2 I/O Monitor

A1S680AV Input/Output Monitor Screen				SET/ RESET	Data Chg.	MONIT MENU	END
	X			Y			
①	00	WDT Error	10	00	00	CH1 Enable	
	01	Ready	11	01	01	CH2 Enable	
	02	Error Detect	12	02	02	CH3 Enable	
	03		13	03	03	CH4 Enable	
	04		14	04	04	CH5 Enable	
	05		15	05	05	CH6 Enable	
	06		16	06	06	CH7 Enable	
	07		17	07	07	CH8 Enable	
	08		18	08	08	Error Reset	
	09		19	09	09		
	0A		1A	0A	0A		
	0B		1B	0B	0B		
	0C		1C	0C	0C		
	0D		1D	0D	0D		
	0E		1E	0E	0E		
	0F		1F	0F	0F		

No.	Contents of display
①	The ON/OFF status of the I/O signal corresponding to the PC CPU is displayed. The I/O signal is ON when displayed in a reverse display.

11.15.3 Graph Monitor



No.	Contents of display	Buffer memory address to reference (decimal)
①	For A1S68DAI: The present input value, a value between 0 ~ 4000 for the digital input value of each channel, is displayed in a graph as a percentage ranging from 0 to 100%. For A1S68DAV: The present input value, a value between -2000 ~ 2000 for the digital input value of each channel, is displayed in a graph as a percentage ranging from 0 to 100%.	1 ~ 8
②	The analog output enabled/disabled status for each channel is displayed.	0
③	A "■" is displayed when a watchdog timer error occurs. When the digital input value set for each channel is greater than/ less than the allowable value, a "■" is displayed.	— 10 ~ 17


11.16 A616AD Unit Monitor

11.16.1 Operation Monitor

A616AD Operation Monitor Screen		SET/ RESET	Data Chg.	MONIT MENU	END
① Enable	FEDCBA9876543210 0110110110110110 0: Disabled 1: Enabled	Error Code		01	
② Data Format Setting	FEDCBA9876543210 0110110110110110	Error		FEDCBA9876543210 CNT No. 0110110110110110	
		Sampling time		01234 ms	
Input Status [%] For Data Format 0: Refer to left hand side values. Format 1: Refer to right hand side values.					
CH 0	01234.6	01234.6	CH 8	01234.6	01234.6
CH 1	01234.6	01234.6	CH 9	01234.6	01234.6
CH 2	01234.6	01234.6	CH A	01234.6	01234.6
CH 3	01234.6 ③	01234.6	CH B	01234.6	01234.6
CH 4	01234.6	01234.6	CH C	01234.6	01234.6
CH 5	01234.6	01234.6	CH D	01234.6	01234.6
CH 6	01234.6	01234.6	CH E	01234.6	01234.6
CH 7	01234.6	01234.6	CH F	01234.6	01234.6
Direct Access INPUT CH:0		MX CH:0	I/P: 01234.6	01234.6	

No.	Contents of display	Buffer memory address to reference (hexadecimal)
①	The specified conversion enabled/disabled status of each channel is displayed.	F
②	The set status of the data format for each channel is displayed. 0: Data format 48-4047 1: Data format 2048-2047	4
③	The current output value, a value between 0 ~ 4000 for the digital output value of each channel, is displayed as a percentage ranging from 0 to 100%.	30 ~ 3F
④	The error code is displayed when an error occurs.	5
⑤	The set value of the sampling period is displayed.	3
⑥	The channels where direct access occurs are displayed.	0
⑦	The current output value, a value between 0 ~ 4000 for the digital output value for each channel where direct access occurs, is displayed as a percentage ranging from 0 to 100%.	2

11.16.2 Operation Monitor (Connect No. 0 - Connect No. 7 When Multiplex Unit is Used)




No.	Contents of display	Buffer memory address to reference (hexadecimal)
①	The connect number of the monitor being used is displayed.	—
②	The specified conversion enabled/disabled status of each channel is displayed.	10 ~ 17
③	The set status of the data format for each channel is displayed. 0: Data format 48-4047 1: Data format 2048-2047	4
④	The current output value, a value between 0 ~ 4000 for the digital output value of each channel, is displayed as a percentage ranging from 0 to 100%.	100 ~ 17F
⑤	The error code is displayed when an error occurs.	5
⑥	"1" is displayed when an error with error code 01-03 occurs for any channel.	6
⑦	The set value of the sampling period is displayed.	3
⑧	The channels where direct access occurs are displayed.	1
⑨	The current output value, a value between 0 ~ 4000 for the digital output value for each channel where direct access occurs, is displayed as a percentage ranging from 0 to 100%.	2

11.16.3 I/O Monitor

A616AD Input/Output Monitor Screen				SET/ RESET	Data Chg.	MONIT MENU	END
Inputs (X)				Outputs (Y)			
① 00	WDT Error	10	00	10			
01	READY	11	01	11			
02	Error	12	02	12			
03		13	03	13			
04		14	04	14			
05		15	05	15			
06		16	06	16			
07		17	07	17			
08		18	08	18			
09		19	09	19			
0A		1A	0A	1A			
0B		1B	0B	1B			
0C		1C	0C	1C			
0D		1D	0D	1D			
0E		1E	0E	1E			
0F		1F	0F	1F			
				1E	Direct Access		


No.	Contents of display
①	The ON/OFF status of the I/O signal corresponding to the PC CPU is displayed. The I/O signal is ON when displayed in a reverse display.

11.16.4 Graph Monitor



No.	Contents of display	Buffer memory address to reference (hexadecimal)
①	The current output value, a value between 0 ~ 4000 for the digital output value of each channel, is displayed as a percentage ranging from 0 to 100%.	30 ~ 3F
②	A "■" is displayed when watchdog timer error occurs.	—
	A "■" is displayed when an error occurs.	—
③	The set status of the data format for each channel is displayed.	4
	The specified conversion enabled/disabled status of each channel is displayed.	F

11.16.5 Graph Monitor (Connect No. 0 - Connect No. 7 When Multiplex Unit is Used)



No.	Contents of display	Buffer memory address to reference (hexadecimal)
①	The connect number of the monitor being used is displayed.	—
②	The current output value, a value between 0 ~ 4000 for the digital output value of each channel, is displayed in a graph as a percentage ranging from 0 to 100%.	100 ~ 17F
③	A "■" is displayed when watchdog timer error occurs.	—
	A "■" is displayed when an error occurs.	—
④	The set status of the data format for each channel is displayed.	4
	The specified conversion enabled/disabled status of each channel is displayed.	10 ~ 17

11.17 A616DAI, A616DAV Unit Monitor

The contents displayed on each monitor of the A616DAI unit and A616DAV unit are nearly identical, except for the sections displaying the unit format.

The A616DAI unit monitor screen is used as an example in each of the following sections.

11.17.1 Operation Monitor

A616DAI Operation Monitor Screen								SET/ RESET	Data Chg.	MONIT MENU	END
Channel No. FEDCBA9876543210											
D/A Conversion 0110110110110110								0: Disabled			
Output Enable 0110110110110110								1: Enabled			
	Output [%]	Over Error	Under Error		Output [%]	Over Error	Under Error				
CH 0	012345.7	0	0	CH 8	012345.7	0	0	③			
CH 1	012345.7	0	0	CH 9	012345.7	0	0	④			
CH 2	012345.7	0	0	CH A	012345.7	0	0				
CH 3	012345.7	0	0	CH B	012345.7	0	0				
CH 4	012345.7	0	0	CH C	012345.7	0	0				
CH 5	012345.7	0	0	CH D	012345.7	0	0				
CH 6	012345.7	0	0	CH E	012345.7	0	0				
CH 7	012345.7	0	0	CH F	012345.7	0	0				
Over/Under Error								0: Normal 1: Error			


No.	Contents of display	Buffer memory address to reference (hexadecimal)
①	The set D/A conversion enabled/disabled status for each channel is displayed.	0
	The set analog output enabled/disabled status for each channel is displayed.	1
②	The current input value, a value between 0 ~ 4000 for the digital input value of each channel, is displayed as a percentage ranging from 0 to 100%.	10 ~ 1F
③	When the digital input value for any channel is set to 4096 or higher, "1" is displayed in the Over Error column.	30 ~ 3F
④	For A616DAI: When the digital input value for any channel is set as a negative number, "1" is displayed in the Under Error column.	30 ~ 3F
	For A616DAV: When the digital input value for any channel is set to 4097 or less, "1" is displayed in the Under Error column.	

11.17.2 I/O Monitor

A616DAI Input/Output Monitor Screen				SET/ RESET	Data Chg.	MONIT MENU	END
Inputs (X)			Outputs (Y)				
00	WDT Error	10	00		10		
01	READY	11	01		11		
02	Error	12	02		12		
03		13	03		13		
04		14	04		14		
05		15	05		15		
06		16	06		16		
07		17	07		17		
08		18	08		18		
09		19	09		19		
0A		1A	0A		1A		
0B		1B	0B		1B	Output Enable	
0C		1C	0C		1C		
0D		1D	0D		1D		
0E		1E	0E		1E		
0F		1F	0F		1F		

No.	Contents of display
①	The ON/OFF status of the I/O signal corresponding to the PC CPU is displayed. The I/O signal is ON when displayed in a reverse display.


11.17.3 Graph Monitor



No.	Contents of display	Buffer memory address to reference (hexadecimal)
①	The current input value, a value between 0 ~ 4000 for the digital input value of each channel, is displayed in a graph as a percentage ranging from 0 to 100%.	10 ~ 1F
②	The set D/A conversion enabled/disabled status for each channel is displayed.	0
	The set analog output enabled/disabled status for each channel is displayed.	1
③	A "■" is displayed when a watchdog timer error occurs.	—
	For A616DAI: A "■" is displayed when the digital input value of any channel is set to 4096 or higher, or to a negative number. For A616DAV: A "■" is displayed when the digital input value of any channel is set to 4096 or higher, or to -4097 or lower.	—


11.18 A616TD Unit Monitor

11.18.1 Operation Monitor (INPUT 0-F)



No.	Contents of display	Buffer memory address to reference (hexadecimal)
①	The specified D/A conversion enabled/disabled status for each channel is displayed.	F
②	The set status of the data format for each channel is displayed.	0
③	An error code is displayed when an error occurs.	1
④	"1" is displayed for CNT No. when an error with error code 01-04 has occurred due to a malfunction of the A60MXT unit or a setting error.	2
⑤	"0" is displayed for the sampling period current value.	4
⑥	For a channel not connected to the A60MX□□, the current output value, a value between 0 ~ 4000 for the digital output of that channel, is displayed as a percentage ranging from 0 to 100%. When a channel is connected to the A60MX□□, the above is displayed for the digital output value for CH0 of A60MX□□.	70 ~ 7F
⑦	When the A60MXT is used, "■" is displayed when a temperature was input that exceeds the temperature range set according to the digital output value set for each channel.	—
⑧	When the A60MXT is used, "■" is displayed when a temperature was input that exceeds the measurement temperature range set for the measurement range of each channel.	—
⑨	When the A60MXT is used, "■" is displayed when broken wire is detected in the thermocouple or the compensating lead wire.	—

11.18.2 Operation Monitor (Connect No. 0 - Connect No. 7 When Multiplex Unit is Used)




No.	Contents of display	Buffer memory address to reference (hexadecimal)
①	The connect number of the monitor being used is displayed.	—
②	The specified conversion enabled/disabled status for each channel is displayed.	F
③	The set status of the data format for each channel is displayed. 0: Data format 48-4047 1: Data format 2048-4047	0
④	The current output value, a value between 0 ~ 4000 for the digital output value of each channel, is displayed as a percentage ranging from 0 to 100%.	180 ~ 1FF
⑤	When the A60MXT is used, "1" is displayed when a temperature was input that exceeds the temperature range set according to the digital output value set for each channel.	50 ~57
⑥	When the A60MXT is used, "1" is displayed when a temperature was input that exceeds the measurement temperature range set for the measurement range of each channel.	60 ~ 67
⑦	When the A60MXT is used, "1" is displayed when broken wire is detected in the thermocouple or the compensating lead wire.	40 ~ 47
⑧	When the A60MXT is used, the set status of the broken wire detection for the thermocouple that is connected to each channel is displayed. 0: Broken wire detection disabled 1: Broken wire detection enabled	20 ~ 27
⑨	When the A60MXT is used, the temperature detection value of each channel is displayed.	200 ~ 27F
⑩	The set temperature value (when the digital value is 0 or 4000) of the channel to which the A60MXT being monitored is connected is displayed.	30 ~ 3F
⑪	A "■" is displayed when an error occurs.	—

11.18.3 I/O Monitor

A616TD Input/Output Monitor Screen				SET/ RESET	Data Chg.	MONIT MENU	END
Inputs (X)			Outputs (Y)				
① 00	WDT Error	10	00	00	10	LED Display	
01	READY	11	01	01	11		
02	Error	12	02	02	12		
03	Discon. Error	13	03	03	13		
04	Digital Error	14	04	04	14		
05	Temp. Error	15	05	05	15		
06		16	06	06	16		
07		17	07	07	17		
08		18	08	08	18		
09		19	09	09	19		
0A		1A	0A	0A	1A		
0B		1B	0B	0B	1B		
0C		1C	0C	0C	1C		
0D		1D	0D	0D	1D		
0E		1E	0E	0E	1E		
0F		1F	0F	0F	1F		


No.	Contents of display
①	The ON/OFF status of the I/O signal corresponding to the PC CPU is displayed. The I/O signal is ON when displayed in a reverse display.

11.18.5 Temperature Monitor (Connect No. 0 - Connect No. 7 when A60MXT is used)




No.	Contents of display	Buffer memory address to reference (hexadecimal)
①	The connect number of the monitor being used is displayed.	—
②	The temperature detection value for each channel is graphically displayed.	200 ~ 27F
③	The set status of the data format for each channel is displayed.	0
	The specified conversion enabled/disabled status for each channel is displayed.	F
④	A "■" is displayed when a watchdog timer error occurs.	—
	A "■" is displayed when an error occurs.	—
	A "■" is displayed when a temperature was input that exceeds the measurement temperature range set for the measurement range of each channel.	—

11.18.6 Graph Monitor (INPUT 0-F)



No.	Contents of display	Buffer memory address to reference (hexadecimal)
①	For a channel not connected to the A60MX□, the current output value, a value between 0 ~ 4000 for the digital output of that channel, is displayed as a percentage ranging from 0 to 100%. When a channel is connected to the A60MX□, the above is displayed for the digital output value for CHO of A60MX□.	70 ~ 7F
②	A "■" is displayed when a watchdog timer error occurs. A "■" is displayed when an error occurs. When the A60MXT is used, "■" is displayed when a temperature was input that exceeds the temperature range set according to the digital output value set for each channel. When the A60MXT is used, "■" is displayed when a temperature was input that exceeds the measurement temperature range set for the measurement range of each channel.	—
③	The set status of the data format for each channel is displayed. The specified conversion enabled/disabled status for each channel is displayed.	0 F

11.18.7 Graph Monitor (Connect No. 0 - Connect No. 7 When Multiplex Unit is Used)



No.	Contents of display	Buffer memory address to reference (hexadecimal)
①	The connect number of the monitor being used is displayed.	—
②	The current output value, a value between 0 ~ 4000 for the digital output value of each channel, is displayed in a graph as a percentage ranging from 0 to 100%.	180 ~ 1FF
③	When the A60MXT is used, the temperature detection value of each channel is displayed.	200 ~ 27F
④	A "■" is displayed when a watchdog timer error occurs.	—
	A "■" is displayed when an error occurs.	—
	When the A60MXT is used, "1" is displayed when a temperature was input that exceeds the temperature range set according to the digital output value set for each channel.	—
	When the A60MXT is used, "1" is displayed when a temperature was input that exceeds the measurement temperature range set for the measurement range of each channel.	—
⑤	The set status of the data format for each channel is displayed.	0
	The specified conversion enabled/disabled status for each channel is displayed.	F

No.	Contents of display	Buffer memory address to reference (decimal)
⑪	The error code is displayed when an error occurs that can be handled by a sequence program such as a startup data error or BUSY in progress.	104
⑫	The error code is displayed when an error occurs that causes monitoring to stop due to an external signal when starting or when a startup is in progress.	105
⑬	The change value (PLS) of the current value is displayed.	80, 81
⑭	The change value (PLS) of the speed/position/travel distance is displayed.	88, 89
⑮	The change value of the velocity change is displayed.	82, 83
⑯	The set value of the JOG velocity is displayed.	84, 85
⑰	The set value (PLS) of the upper stroke limit is displayed.	0, 1
⑱	The set value (PLS) of the lower stroke limit is displayed.	2, 3
⑲	The command pulse ratio numerator (CMX) and denominator (CDV) are displayed.	4, 5
⑳	The set value of the velocity limit is displayed.	20, 21
㉑	The set value of the acceleration time is displayed.	22
㉒	The set value of the deceleration time is displayed.	23
㉓	The set value (PLS) of the in-position range is displayed.	24
㉔	The set status of the positioning mode is displayed. 0: Positioning 1: Velocity positioning	25


11.19.3 I/O Monitor

AD70 Input/Output Monitor Screen				SET/ RESET	Data Chg.	MONIT MENU	END
Inputs (X)			Outputs (Y)				
00	WDT Error	10	00	Zero Rtn Start	10	Zero Rtn Start	
01	AD70 READY	11	01	Posit. Start	11	Posit. Start	
02	Zero Rtn Request	12	02	Forward Start	12	Forward Start	
03	Zero Rtn Comple.	13	03	Reverse Start	13	Reverse Start	
04	BUSY	14	04	Fwd. Jog Start	14	Fwd. Jog Start	
05	Posit.Complete	15	05	Rev. Jog Start	15	Rev. Jog Start	
06	In-position	16	06	Vel/Pos Restart	16	Vel/Pos Restart	
07	Excessive Error	17	07	Stop	17	Stop	
08	Error Detection	18	08	Error Reset	18	Error Reset	
09	Overflow	19	09	Overflow Reset	19	Overflow Reset	
0A	Underflow	1A	0A	Underflow Reset	1A	Underflow Reset	
0B	Servo Ready	1B	0B		1B		
0C	Near Zero Point	1C	0C	V/P Switchover	1C	V/P Switchover	
0D	Stop (External)	1D	0D	PC READY	1D	PC READY	
0E	Upper Limit LS	1E	0E		1E		
0F	Lower Limit LS	1F	0F		1F		

No.	Contents of display
①	The ON/OFF status of the I/O signal corresponding to the PC CPU is displayed. The I/O signal is ON when displayed in a reverse display.

No.	Contents of display	Buffer memory address to reference (decimal)																												
⑫	The error code is displayed when an error occurs that can be handled by a sequence program such as a data error or BUSY in progress.	121																												
⑬	The error code is displayed when an error occurs that causes monitoring to stop due to an external signal when starting or when a startup is in progress.	122																												
⑭	The error code output from the servo amp that was converted into an error code for AD70D is displayed.	123																												
⑮	The change value (PLS) of the current value is displayed.	80, 81																												
⑯	The change value (PLS) of the speed/position/travel distance is displayed.	86, 87																												
⑰	The change value of the velocity change is displayed.	82, 83																												
⑱	The set value of the JOG velocity is displayed.	84, 85																												
⑲	The change value of the torque limit is displayed.	89																												
⑳	The actual number of revolutions of the motor is displayed.	110																												
㉑	The motor current is displayed as 100% of the rated current.	111																												
㉒	The data for monitoring the load of the regeneration resistance is displayed.	112																												
㉓	The maximum torque is displayed when it is 100% of the rated torque.	113																												
⑳	<p>Valid when using peripheral equipment (SW: GP-AD70DP).</p> <table border="1" data-bbox="359 887 1135 997"> <thead> <tr> <th>Bit</th> <th>8</th> <th>7</th> <th>6</th> <th>5</th> <th>4</th> <th>3</th> <th>2</th> <th>1</th> </tr> </thead> <tbody> <tr> <td rowspan="2">Contents of display</td> <td>0</td> <td>Servo ready OFF</td> <td>—</td> <td>—</td> <td>—</td> <td>—</td> <td>Test mode normal</td> <td>Not in test mode</td> </tr> <tr> <td>1</td> <td>Servo ready ON</td> <td>—</td> <td>—</td> <td>—</td> <td>—</td> <td>Test mode request error</td> <td>Test mode in progress</td> </tr> </tbody> </table>	Bit	8	7	6	5	4	3	2	1	Contents of display	0	Servo ready OFF	—	—	—	—	Test mode normal	Not in test mode	1	Servo ready ON	—	—	—	—	Test mode request error	Test mode in progress	125		
Bit	8	7	6	5	4	3	2	1																						
Contents of display	0	Servo ready OFF	—	—	—	—	Test mode normal	Not in test mode																						
	1	Servo ready ON	—	—	—	—	Test mode request error	Test mode in progress																						
㉑	<p>The set status of the AD70D slide switch is displayed.</p> <table border="1" data-bbox="359 1079 1135 1190"> <thead> <tr> <th>Bit</th> <th>8</th> <th>7</th> <th>6</th> <th>5</th> <th>4</th> <th>3</th> <th>2</th> <th>1</th> </tr> </thead> <tbody> <tr> <td rowspan="2">Contents of display</td> <td>0</td> <td>SW8 "OFF"</td> <td>SW7 "OFF"</td> <td>SW6 "OFF"</td> <td>SW5 "OFF"</td> <td>SW4 "OFF"</td> <td>SW3 "OFF"</td> <td>SW2 "OFF"</td> <td>SW1 "OFF"</td> </tr> <tr> <td>1</td> <td>SW8 "ON"</td> <td>SW7 "ON"</td> <td>SW6 "ON"</td> <td>SW5 "ON"</td> <td>SW4 "ON"</td> <td>SW3 "ON"</td> <td>SW2 "ON"</td> <td>SW1 "ON"</td> </tr> </tbody> </table>	Bit	8	7	6	5	4	3	2	1	Contents of display	0	SW8 "OFF"	SW7 "OFF"	SW6 "OFF"	SW5 "OFF"	SW4 "OFF"	SW3 "OFF"	SW2 "OFF"	SW1 "OFF"	1	SW8 "ON"	SW7 "ON"	SW6 "ON"	SW5 "ON"	SW4 "ON"	SW3 "ON"	SW2 "ON"	SW1 "ON"	126
Bit	8	7	6	5	4	3	2	1																						
Contents of display	0	SW8 "OFF"	SW7 "OFF"	SW6 "OFF"	SW5 "OFF"	SW4 "OFF"	SW3 "OFF"	SW2 "OFF"	SW1 "OFF"																					
	1	SW8 "ON"	SW7 "ON"	SW6 "ON"	SW5 "ON"	SW4 "ON"	SW3 "ON"	SW2 "ON"	SW1 "ON"																					

11.20.2 Zero Return Monitor



No.	Contents of display	Buffer memory address to reference (decimal)
①	The ON/OFF status of the I/O signal corresponding to the PC CPU is displayed. The I/O signal is ON when displayed in a reverse display.	---
②	The calculated command pulse number (PLS) based on the command value is displayed.	100, 101
③	The actual amount of servo movement (feedback pulse number) (PLS) calculated from the feedback pulse is displayed.	102, 103
④	The difference between the command pulse number x CMS/CDV and the feedback pulse number (PLS) is displayed.	104, 105
⑤	The set value (PLS) of the zero address is displayed.	30, 31
⑥	The set value of the zero return velocity is displayed.	32, 33
⑦	The set value of the creep velocity is displayed.	34, 35
⑧	After zero return starts, the near zero point signal goes off, decelerates and stops. The travel distance (PLS) from that point until zero return is complete is displayed.	108, 109
⑨	After zero return starts, the travel distance (PLS) from when the near zero point signal goes on until zero return is complete is displayed.	106, 107
⑩	The set value (PLS) of the travel distance after the near zero point signal goes ON is displayed.	36, 37
⑪	The status of the control mode when changing modes from velocity to position control is displayed. 0: Positioning control in progress 1: Velocity control in progress	119
⑫	This displays whether the torque command (electrical current command) for the motor is controlled by the rated torque written in the motor catalog x the "torque limit value". 0: When motor is rotating within set torque limit 1: Limited	120

No.	Contents of display	Buffer memory address to reference (decimal)																													
⑬	The error code is displayed when an error occurs that can be handled by a sequence program such as a data error or BUSY in progress.	121																													
⑭	The error code is displayed when an error occurs that causes monitoring to stop due to an external signal when starting or when a startup is in progress.	122																													
⑮	The error code output from the servo amp that was converted into an error code for AD70D is displayed.	123																													
⑯	The change value (PLS) of the current value is displayed.	80, 81																													
⑰	The change value (PLS) of the speed/position/travel distance is displayed.	86, 87																													
⑱	The change value of the velocity change is displayed.	82, 83																													
⑲	The set value of the JOG velocity is displayed.	84, 85																													
⑳	The change value of the torque limit is displayed.	89																													
㉑	The actual number of revolutions of the motor is displayed.	110																													
㉒	The motor current is displayed as 100% of the rated current.	111																													
㉓	The data for monitoring the load of the regeneration resistance is displayed.	112																													
㉔	The maximum torque is displayed when it is 100% of the rated torque.	113																													
㉕	Valid when using peripheral equipment (SW \square GP-AD70DP). <table border="1" data-bbox="359 880 1134 990"> <thead> <tr> <th>Bit</th> <th>8</th> <th>7</th> <th>6</th> <th>5</th> <th>4</th> <th>3</th> <th>2</th> <th>1</th> </tr> </thead> <tbody> <tr> <td>Contents of display</td> <td>0</td> <td>Servo ready OFF</td> <td>—</td> <td>—</td> <td>—</td> <td>—</td> <td>Test mode normal</td> <td>Not in test mode</td> </tr> <tr> <td></td> <td>1</td> <td>Servo ready ON</td> <td>—</td> <td>—</td> <td>—</td> <td>—</td> <td>Test mode request error</td> <td>Test mode in progress</td> </tr> </tbody> </table>	Bit	8	7	6	5	4	3	2	1	Contents of display	0	Servo ready OFF	—	—	—	—	Test mode normal	Not in test mode		1	Servo ready ON	—	—	—	—	Test mode request error	Test mode in progress	125		
Bit	8	7	6	5	4	3	2	1																							
Contents of display	0	Servo ready OFF	—	—	—	—	Test mode normal	Not in test mode																							
	1	Servo ready ON	—	—	—	—	Test mode request error	Test mode in progress																							
㉖	The set status of the AD70D slide switch is displayed. <table border="1" data-bbox="359 1075 1134 1185"> <thead> <tr> <th>Bit</th> <th>8</th> <th>7</th> <th>6</th> <th>5</th> <th>4</th> <th>3</th> <th>2</th> <th>1</th> </tr> </thead> <tbody> <tr> <td>Contents of display</td> <td>0</td> <td>SW8 *OFF*</td> <td>SW7 *OFF*</td> <td>SW6 *OFF*</td> <td>SW5 *OFF*</td> <td>SW4 *OFF*</td> <td>SW3 *OFF*</td> <td>SW2 *OFF*</td> <td>SW1 *OFF*</td> </tr> <tr> <td></td> <td>1</td> <td>SW8 *ON*</td> <td>SW7 *ON*</td> <td>SW6 *ON*</td> <td>SW5 *ON*</td> <td>SW4 *ON*</td> <td>SW3 *ON*</td> <td>SW2 *ON*</td> <td>SW1 *ON*</td> </tr> </tbody> </table>	Bit	8	7	6	5	4	3	2	1	Contents of display	0	SW8 *OFF*	SW7 *OFF*	SW6 *OFF*	SW5 *OFF*	SW4 *OFF*	SW3 *OFF*	SW2 *OFF*	SW1 *OFF*		1	SW8 *ON*	SW7 *ON*	SW6 *ON*	SW5 *ON*	SW4 *ON*	SW3 *ON*	SW2 *ON*	SW1 *ON*	126
Bit	8	7	6	5	4	3	2	1																							
Contents of display	0	SW8 *OFF*	SW7 *OFF*	SW6 *OFF*	SW5 *OFF*	SW4 *OFF*	SW3 *OFF*	SW2 *OFF*	SW1 *OFF*																						
	1	SW8 *ON*	SW7 *ON*	SW6 *ON*	SW5 *ON*	SW4 *ON*	SW3 *ON*	SW2 *ON*	SW1 *ON*																						

11.20.3 Parameter Data Monitor

AD70D Parameter Data Monitor Screen			SET/ RESET	Data Chg.	MONIT MENU	END	
Y11 Posit. Start	Upper Limit ②	01234567890	In-position Range	012345	PLS	⑬	
Y12 Forward Start	Lower Limit ③	01234567890	Feedback Pulses	012345	PLS	⑭	
Y13 Reverse Start	Electronic Gear ④	0123/ 0123	Rotation Direction	0		⑮	
Y14 Fwd. Jog Start	System Setting ⑤	0	Torque Limit	012345	%	⑯	
Y15 Rev. Jog Start	Regen. Resistance ⑥	0	Velocity Limit	0123456	PLS/s	⑰	
Y16 Vel/Pos Restart	Motor Type ⑦	0	Accel. Time	012345	ms	⑱	
X05 Posit. Complete	⑧	Motor Capacity	0123.5	kW	Decel. Time	012345	ms
① Zero Rtn Request	⑨	Motor Rotations	012345	rpm	Positioning Mode	0	
Y10 Zero Rtn Start	⑩	Pos. Loop Gain	012345	rad/s	Amplifier Ver.	A01W012-ABC	
X03 Zero Rtn Comple.	⑪	Vel. Loop Gain	012345		Test Mode	0110110110110110 87654321	
Y17 Stop	⑫	Vel. Integration	012345	ms	S/Switch	0110110110110110	
X04 BUSY							
In-position							
Y18 Servo OFF							
Y19 V/P Switchover							
X00 WDT Error							
X08 Error Detection							

No.	Contents of display	Buffer memory address to reference (decimal)
①	The ON/OFF status of the I/O signal corresponding to the PC CPU is displayed. The I/O signal is on when displayed in a reverse display.	—
②	The set value (PLS) of the upper stroke limit is displayed.	0, 1
③	The set value (PLS) of the lower stroke limit is displayed.	2, 3
④	The command pulse ratio numerator (CMX) and denominator (CDV) are displayed.	4, 5
⑤	The set status of the system is displayed. 0: MR-SB (standard) 1: MR-SB (absolute values)	10
⑥	The set status of the regeneration resistance is displayed. 0: None 1: RB30 2: RB50,51 3: RB100, 101	11
⑦	The set status of the motor type is displayed. 0: Standard 1: Low inertia L 2: Flat U	12
⑧	The motor output capacity is displayed.	13
⑨	The set status of the motor rpm is displayed.	14
⑩	The set value of the position loop gain is displayed.	15
⑪	The set value of the velocity loop gain is displayed.	16
⑫	The set value of the velocity integration is displayed.	17
⑬	The set value of the in-position range is displayed.	18
⑭	The feedback pulse number (PLS) of one revolution of the motor is displayed.	19
⑮	The set status of the direction of rotation is displayed. 0: Counter-clockwise with address increase 1: Clockwise with address increase	20
⑯	The set value of the torque limit is displayed.	21
⑰	The set value of the velocity limit is displayed.	40, 41

No.	Contents of display	Buffer memory address to reference (decimal)																											
⑱	The set value of the acceleration time is displayed.	42																											
⑲	The set value of the deceleration time is displayed.	43																											
⑳	The set status of the positioning mode is displayed. 0: Positioning mode 1: Velocity → position control change mode	44																											
㉑	The servo amp model code and version are displayed.	114 ~ 117																											
㉒	Valid when using peripheral instrument (SW \square GP-AD70DP) <table border="1" data-bbox="359 522 1134 632"> <thead> <tr> <th>Bit</th> <th>8</th> <th>7</th> <th>6</th> <th>5</th> <th>4</th> <th>3</th> <th>2</th> <th>1</th> </tr> </thead> <tbody> <tr> <td>Contents of display 0</td> <td>Servo ready OFF</td> <td>—</td> <td>—</td> <td>—</td> <td>—</td> <td>—</td> <td>Test mode normal</td> <td>Not in test mode</td> </tr> <tr> <td>1</td> <td>Servo ready ON</td> <td>—</td> <td>—</td> <td>—</td> <td>—</td> <td>—</td> <td>Test mode re-quest error</td> <td>Test mode in progress</td> </tr> </tbody> </table>	Bit	8	7	6	5	4	3	2	1	Contents of display 0	Servo ready OFF	—	—	—	—	—	Test mode normal	Not in test mode	1	Servo ready ON	—	—	—	—	—	Test mode re-quest error	Test mode in progress	125
Bit	8	7	6	5	4	3	2	1																					
Contents of display 0	Servo ready OFF	—	—	—	—	—	Test mode normal	Not in test mode																					
1	Servo ready ON	—	—	—	—	—	Test mode re-quest error	Test mode in progress																					
㉓	The set status of the AD70D slide switch is displayed. <table border="1" data-bbox="359 714 1134 825"> <thead> <tr> <th>Bit</th> <th>8</th> <th>7</th> <th>6</th> <th>5</th> <th>4</th> <th>3</th> <th>2</th> <th>1</th> </tr> </thead> <tbody> <tr> <td>Contents of display 0</td> <td>SW8 *OFF*</td> <td>SW7 *OFF*</td> <td>SW6 *OFF*</td> <td>SW5 *OFF*</td> <td>SW4 *OFF*</td> <td>SW3 *OFF*</td> <td>SW2 *OFF*</td> <td>SW1 *OFF*</td> </tr> <tr> <td>1</td> <td>SW8 *ON*</td> <td>SW7 *ON*</td> <td>SW6 *ON*</td> <td>SW5 *ON*</td> <td>SW4 *ON*</td> <td>SW3 *ON*</td> <td>SW2 *ON*</td> <td>SW1 *ON*</td> </tr> </tbody> </table>	Bit	8	7	6	5	4	3	2	1	Contents of display 0	SW8 *OFF*	SW7 *OFF*	SW6 *OFF*	SW5 *OFF*	SW4 *OFF*	SW3 *OFF*	SW2 *OFF*	SW1 *OFF*	1	SW8 *ON*	SW7 *ON*	SW6 *ON*	SW5 *ON*	SW4 *ON*	SW3 *ON*	SW2 *ON*	SW1 *ON*	126
Bit	8	7	6	5	4	3	2	1																					
Contents of display 0	SW8 *OFF*	SW7 *OFF*	SW6 *OFF*	SW5 *OFF*	SW4 *OFF*	SW3 *OFF*	SW2 *OFF*	SW1 *OFF*																					
1	SW8 *ON*	SW7 *ON*	SW6 *ON*	SW5 *ON*	SW4 *ON*	SW3 *ON*	SW2 *ON*	SW1 *ON*																					

11.20.4 I/O Monitor

AD70D Input/Output Monitor Screen				SET/ RESET	Data Chg.	MONIT MENU	END
Inputs (X)				Outputs (Y)			
00	NDT Error	10		00		10	Zero Rtn Start
01	READY	11		01		11	Posit. Start
02	Zero Rtn Request	12		02		12	Forward Start
03	Zero Rtn Comple.	13		03		13	Reverse Start
04	BUSY	14		04		14	Fwd. Jog Start
05	Posit. Complete	15		05		15	Rev. Jog Start
06	In-position	16		06		16	Vel/Pos Restart
07	Zero Return	17		07		17	Stop
08	Error Detection	18		08		18	Error Reset
09	Overflow	19		09		19	Overflow Reset
0A	Underflow	1A		0A		1A	Underflow Reset
0B	Servo Ready	1B		0B		1B	Servo OFF
0C	Near Zero Point	1C		0C		1C	V/P Switchover
0D	Stop (External)	1D		0D		1D	PC READY
0E	Upper Limit LS	1E		0E		1E	
0F	Lower Limit LS	1F		0F		1F	

①

No.	Contents of display
①	The ON/OFF status of the I/O signal corresponding to the PC CPU is displayed. The I/O signal is ON when displayed in a reverse display.

11.21 AD71 Unit Monitor


11.21.1 Positioning Monitor

AD71 Positioning Data Monitor Screen						SET/ RESET	Data Chg.	MONIT MENU	END
X	Y			③ X Axis	④ Y Axis			X	Y
Y10 Y11		Posit. Start	Exec.Data No.	012 Pt 01	012 Pt 01			01 012	012
	Y12	Interpolation						02 012	012
X02 X03		Posit. Compl.	Present Value	⑤ 0123456789	0123456789			03 012	012
								04 012	012
								05 012	012
① X06 X07		Zero Request	Change Value	⑥ 0123456789	0123456789			06 012	012
Y13 Y14		Zero Start						07 012	012
X0C X0D		Zero Complete	Zero Address	⑦ 0123456789	0123456789			08 012	012
								09 012	012
Y17 Y19		Fwd.Jog Start	Output Speed	⑧ 01234567	01234567			10 012	012
Y18 Y1A		Rev.Jog Start						11 012	012
			Speed Limit	⑨ 01234567	01234567			12 012	012
Y15 Y16		Stop	Speed Change	⑩ 01234567	01234567			13 012	012
								14 012	012
X08 X09		Pos. Started	Jog Speed	⑪ 01234567	01234567			15 012	012
X04 X05		BUSY						16 012	012
X0E X0F		M Code ON	Jog Spd.Limit	⑫ 01234567	01234567			17 012	012
								18 012	012
X00		HDT Err Man.Pulse	MCode/ErrCode	012 01	012 01			19 012	012
X0A		Batt.Err X:Wi						20 012	012
X0B		Error Y:Wi							

No.	Contents of display	Buffer memory address to reference (decimal)	
		X axis	Y axis
①	The ON/OFF status of the I/O signal corresponding to the PC CPU is displayed. The I/O signal is ON when displayed in a reverse display.	—	—
②	The set manual pulser run enabled/disabled status is displayed.	47	347
③	The data number during execution of current positioning is displayed.	48	348
④	The remaining pointer value is displayed.	39	339
⑤	The current value during execution of current positioning is displayed.	602 603	604 605
⑥	The change value of the current value is displayed.	41 42	341 342
⑦	The zero address set value is displayed.	7912 7913	7922 7923
⑧	The set value of the output speed is displayed.	600	601
⑨	The set value of the speed limit is displayed.	7874	7894
⑩	The change value of the speed change is displayed.	40	340
⑪	The set value of the jog speed is displayed.	44	344
⑫	The set value of the jog speed limit is displayed.	7875	7895
⑬	The set value of the M code is displayed. 0: M code not used	46	346
⑭	The error code is displayed when an error occurs.	45	345
⑮	The starting data number of each point is displayed.	0 ~ 37	300 ~ 337

11.21.2 Zero Return Monitor

AD71 Zero Return Data Monitor Screen				SET/ RESET	Data Chg.	MONIT MENU	END
X	Y			③ X Axis	④ Y Axis	X Axis Zero Data ABC	
Y10 Y11	Posit. Start	Exec.Data No.	012 Pt 01	012 Pt 01	0110110110110110		
Y12	Interpolation	Present Value	⑤ 0123456789	0123456789	Y Axis Zero Data ABC		
X02 X03	Posit. Compl.	Change Value	⑥ 0123456789	0123456789	0110110110110110		
X06 X07	Zero Request	Zero Address	⑦ 0123456789	0123456789	A:0 PG Zero Point 1 Mech. Stop		
Y13 Y14	Zero Start	Output Speed	⑧ 01234567	01234567	B:0 Fwd. 1:Rev. C:0 Stop/Time Out 1 Stop/Signal		
X08 X09	Zero Complete	Speed Limit	⑨ 01234567	01234567	Torque Limit		
Y17 Y18	Fwd.Jog Start	Speed Change	⑩ 01234567	01234567	X Axis: 012		
Y19 Y1A	Rev.Jog Start	Zeroing Speed	⑪ 01234567	01234567	Y Axis: 012		
Y15 Y16	Stop	Creep Speed	⑫ 01234567	01234567	Zero Dwell Time		
X08 X09	Pos. Started	MCode/ErrCode	012 01	012 01	X Axis: 012		
X04 X05	BUSY				Y Axis: 012		
X0E X0F	M Code ON						
X00	WDT Err Man.Pulse						
X0A	Batt.ErrX:Wi						
X0B	Error Y:Wi						

No.	Contents of display	Buffer memory address to reference (decimal)	
		X axis	Y axis
①	The ON/OFF status of the I/O signal corresponding to the PC CPU is displayed. The I/O signal is ON when displayed in a reverse display.	—	—
②	The set manual pulser run enabled/disabled status is displayed.	47	347
③	The data number during execution of current positioning is displayed.	48	348
④	The remaining pointer value is displayed.	39	339
⑤	The current value during execution of current positioning is displayed.	602 603	604 605
⑥	The change value of the current value is displayed.	41 42	341 342
⑦	The zero address set value is displayed.	7912 7913	7922 7923
⑧	The set value of the output speed is displayed.	600	601
⑨	The set value of the speed limit is displayed.	7874	7894
⑩	The change value of the speed change is displayed.	40	340
⑪	The set value of the zero return speed is displayed.	7914	7924
⑫	The set value of the zero return creep speed is displayed.	7915	7925
⑬	The set value of the M code is displayed. 0: M code not used	46	346
⑭	The error code is displayed when an error occurs.	45	345
⑮	The zero return data is displayed. 	7918	7928
⑯	The set value of the torque limit is displayed.	7917	7927
⑰	The set value of the dwell time is displayed.	7916	7926

11.21.3 Parameter Data Monitor

AD71 Parameter Data Monitor Screen

		SET/ RESET	Data Chg.	MONIT MENU	END	
X	Y					ABCDDEFF
Y10 Y11	Posit. Start	Travel/Pulse	③ 01234567	01234567	0110110110110110	⑬
Y12	Interpolation	Inching Trav.	④ 0123456789	0123456789	Y ABCDDEFF	
X02 X03	Posit. Compl.	Speed Limit	⑤ 01234567	01234567	0110110110110110	⑬
X06 X07	Zero Request	Jog Spd.Limit	⑥ 01234567	01234567	A:Pulse O/P Mode	
Y13 Y14	Zero Start	Acc/Dec Time	⑦ 01234567	01234567	0 B Type	
X0C X0D	Zero Complete	Backlash Comp	⑧ 01234567	01234567	1 A Type	
Y17 Y19	Fwd.Jog Start	Upper Limit	⑨ 0123456789	0123456789	0 WITH Mode	
Y18 Y1A	Rev.Jog Start	Lower Limit	⑩ 0123456789	0123456789	1 AFTER Mode	
Y15 Y16	Stop	Error Comp.	⑪ 0123456789	0123456789	0 OFF 1 ON	
X08 X09	Pos. Started	Starting Bias	⑫ 01234567	01234567	C:M Code ON/OFF	
X04 X05	BUSY	Compl.O/P Time	⑬ 01234567	01234567	00 ABS 01 INC	
X0E X0F	M Code ON	MCode/ErrCode	012 01	012 01	10 ABS + INC	
X00	WDT Err Man.Pulse				E:Direction	
X0A	Batt.ErrX:Wi				0 Fwd 1 Rev	
X0B	Error Y:Wi				FF:Unit Setting	
					00 mm 01 inch	
					10 deg 11 PLS	

① ② ③ ④ ⑤ ⑥ ⑦ ⑧ ⑨ ⑩ ⑪ ⑫ ⑬ ⑭ ⑮ ⑯

No.	Contents of display	Buffer memory address to reference (decimal)	
		X axis	Y axis
①	The ON/OFF status of the I/O signal corresponding to the PC CPU is displayed. The I/O signal is ON when displayed in a reverse display.	—	—
②	The set manual pulser run enabled/disabled status is displayed.	47	347
③	The set value of the travel distance per 1 pulse is displayed.	7873	7893
④	The set value of the travel distance per 1 pulse using the manual pulser is displayed.	7884 7885	7904 7905
⑤	The set value of the speed limit is displayed.	7874	7894
⑥	The set value of the jog speed limit is displayed.	7875	7895
⑦	The set value of the acceleration/deceleration time is displayed.	7876	7896
⑧	The set value of the backlash compensation amount is displayed.	7877	7897
⑨	The set value of the upper stroke limit is displayed.	7878 7879	7898 7899
⑩	The set value of the lower stroke limit is displayed.	7880 7881	7900 7901
⑪	The set value of the error compensation amount is displayed.	7882 7883	7902 7903
⑫	The set value of the starting bias speed is displayed.	7886	7906
⑬	The set value of the positioning complete signal output time is displayed.	7887	7907
⑭	The set value of the M code is displayed.	46	346
⑮	The error code is displayed when an error occurs.	45	345
⑯	The set status of the parameter data is displayed.	7872	7892

11.21.4 M Code Comment Monitor

AD71 M Code Comment Monitor Screen				SET/ RESET	Data Chg.	MONIT MENU	END
X	Y		X Axis M Code 012	Y Axis M Code 012	X Axis		
Y10 Y11	Posit. Start	01	ABCDEFGHIJKLMN	ABCDEFGHIJKLMN	Executing		
Y12 Y13	Interpolation	02	ABCDEFGHIJKLMN	ABCDEFGHIJKLMN	Data No.: 012		
X02 X03	Posit. Compl.	03	ABCDEFGHIJKLMN	ABCDEFGHIJKLMN	Pointer: 012		
X05 X07	Zero Request	05	ABCDEFGHIJKLMN	ABCDEFGHIJKLMN	Error Code:012		
Y13 Y14	Zero Start	06	ABCDEFGHIJKLMN	ABCDEFGHIJKLMN	Status: 012		
X02 X03	Zero Complete	07	ABCDEFGHIJKLMN	ABCDEFGHIJKLMN	-----		
Y17 Y18	Fwd.Jog Start	09	ABCDEF④JKLMN	ABCDEFGHIJKLMN	Y Axis		
Y18 Y19	Rev.Jog Start	10	ABCDEFGHIJKLMN	ABCDEFGHIJKLMN	Executing		
Y15 Y16	Stop	12	ABCDEFGHIJKLMN	ABCDEFGHIJKLMN	Data No.: 012		
X08 X09	Pos. Started	14	ABCDEFGHIJKLMN	ABCDEFGHIJKLMN	Pointer: 012		
X04 X05	BUSY	15	ABCDEFGHIJKLMN	ABCDEFGHIJKLMN	Error Code:012		
X0E X0F	M Code ON	16	ABCDEFGHIJKLMN	ABCDEFGHIJKLMN	Status: 012		
X00	WDT Err Man.Pulse	17	ABCDEFGHIJKLMN	ABCDEFGHIJKLMN	-----		
X0A	Batt.Errx:Wi	18	ABCDEFGHIJKLMN	ABCDEFGHIJKLMN	Y Axis		
X0B	Error Y:Wj	19	ABCDEFGHIJKLMN	ABCDEFGHIJKLMN	Executing		

①

②

⑤

⑥

⑦

⑧

No.	Contents of display	Buffer memory address to reference (decimal)												
		X axis	Y axis											
①	The ON/OFF status of the I/O signal corresponding to the PC CPU is displayed. The I/O signal is ON when displayed in a reverse display.	—	—											
②	The set manual pulser run enabled/disabled status is displayed.	47	347											
③	The set value of the M code is displayed.	46	346											
④	The set value of the comment for the M code is displayed.	49~200	349~500											
⑤	The data number during execution of current positioning is displayed.	48	348											
⑥	The remaining pointer value is displayed.	39	339											
⑦	The error code is displayed when an error occurs.	45	345											
⑧	<p>The 8 bits where the status is saved are displayed in hexadecimal format. When "FF" is displayed</p> <table border="1" style="margin-left: 20px;"> <thead> <tr> <th>*1* display conditions</th> <th>*0* display conditions</th> </tr> </thead> <tbody> <tr> <td>Battery alarm</td> <td rowspan="8">Not condition at left</td> </tr> <tr> <td>Zero return request</td> </tr> <tr> <td>During dwell time</td> </tr> <tr> <td>During positioning busy status (except for zero return, jog run, manual pulser run)</td> </tr> <tr> <td>Zero return complete</td> </tr> <tr> <td>Near signal on</td> </tr> <tr> <td>Drive unit ready signal on</td> </tr> <tr> <td>Stop signal from drive unit on</td> </tr> </tbody> </table>	*1* display conditions	*0* display conditions	Battery alarm	Not condition at left	Zero return request	During dwell time	During positioning busy status (except for zero return, jog run, manual pulser run)	Zero return complete	Near signal on	Drive unit ready signal on	Stop signal from drive unit on	43	343
1 display conditions	*0* display conditions													
Battery alarm	Not condition at left													
Zero return request														
During dwell time														
During positioning busy status (except for zero return, jog run, manual pulser run)														
Zero return complete														
Near signal on														
Drive unit ready signal on														
Stop signal from drive unit on														

11.21.5 I/O Monitor

AD71 Input/Output Monitor Screen				SET/ RESET	Data Chg.	MONIT MENU	END
Inputs (X)				Outputs (Y)			
00	WDT Error	10		00		10	X Posit. Start
01	READY	11		01		11	Y Posit. Start
02	X Posit. Complete	12		02		12	Interpolation
03	Y Posit. Complete	13		03		13	X Zeroing Start
04	X Axis BUSY	14		04		14	Y Zeroing Start
05	Y Axis BUSY	15		05		15	X Stop
06	X Zero Request	16		06		16	Y Stop
07	Y Zero Request	17		07		17	X Fwd. Jog Start
08	X Posit. Started	18		08		18	X Rev. Jog Start
09	Y Posit. Started	19		09		19	Y Fwd. Jog Start
0A	Battery Error	1A		0A		1A	Y Rev. Jog Start
0B	Error Detection	1B		0B		1B	X M Code OFF
0C	X Zero Complete	1C		0C		1C	Y M Code OFF
0D	Y Zero Complete	1D		0D		1D	PC READY
0E	X M Code ON	1E		0E		1E	
0F	Y M Code ON	1F		0F		1F	

①

No.	Contents of display
①	The ON/OFF status of the I/O signal corresponding to the PC CPU is displayed. The I/O signal is ON when displayed in a reverse display.

11.21.6 Positioning Data Monitor

The positioning Data Monitor Screen No. 1 is used as an example.

AD71 Positioning Data Monitor Screen										No.01		SET/ RESET	Data Chg.	MONIT MENU	END
X	Address	Speed	Dwell	M	Code *	Y	Address	Speed	Dwell	M	Code *				
001	01234567	01234	012	012	0	001	01234567	01234	012	012	0				
002	01234567	01234	012	012	0	002	01234567	01234	012	012	0				
003	01234567	01234	012	012	0	003	01234567	01234	012	012	0				
004	01234567	01234	012	012	0	004	01234567	01234	012	012	0				
005	01234567	01234	012	012	0	005	01234567	01234	012	012	0				
006	01234567	01234	012	012	0	006	01234567	01234	012	012	0				
007	01234567	01234	012	012	0	007	01234567	01234	012	012	0				
008	01234567	01234	012	012	0	008	01234567	01234	012	012	0				
009	01234567	01234	012	012	0	009	01234567	01234	012	012	0				
010	01234567	01234	012	012	0	010	01234567	01234	012	012	0				
011	01234567	01234	012	012	0	011	01234567	01234	012	012	0				
012	01234567	01234	012	012	0	012	01234567	01234	012	012	0				
013	01234567	01234	012	012	0	013	01234567	01234	012	012	0				
014	01234567	01234	012	012	0	014	01234567	01234	012	012	0				
015	01234567	01234	012	012	0	015	01234567	01234	012	012	0				
016	01234567	01234	012	012	0	016	01234567	01234	012	012	0				
017	01234567	01234	012	012	0	017	01234567	01234	012	012	0				
018	01234567	01234	012	012	0	018	01234567	01234	012	012	0				
019	01234567	01234	012	012	0	019	01234567	01234	012	012	0				
020	01234567	01234	012	012	0	020	01234567	01234	012	012	0				

① ② ③ ④ ⑤

No.	Contents of display	Buffer memory address to reference (decimal)	
		X axis	Y axis
①	The set value of the positioning address for each data number is displayed.	5072-5111	7072-7111
②	The set value of the positioning speed for each data number is displayed.	4272-4291	6272-6291
③	The set value of the dwell time for each data number is displayed.	4672-4691	6672-6691
④	The set value of the M code for each data number is displayed.	3872-3891	5872-5891
⑤	<p>The 4 bits where the set status of the positioning pattern, the positioning method, and the positioning direction for each data number is stored are displayed in hexadecimal format.</p> <p>When "F" is displayed</p> <p>① Positioning pattern 00: Positioning complete 01: Positioning continues 11: Speed changes and positioning continues</p> <p>② Positioning method 0: Absolute 1: Incremental</p> <p>③ Positioning direction (only valid in incremental mode) 0: Forward direction (address increase direction) 1: Reverse direction (address decrease direction)</p>	3872-3891	5872-5891

11.22 AD72, A1SD71 Unit Monitor

The contents displayed on each monitor of the AD72 unit and the A1SD71 unit are nearly identical, except for the sections displaying the unit format.


The AD72 unit monitor screen is used as an example in each of the following sections.


11.22.1 Positioning Monitor

AD72/A1SD71 Positioning Data Monitor Screen				SET/ RESET	Data Chg.	MONIT MENU	END
X	Y			③ X Axis	④ Y Axis	X	Y
Y20 Y21	Posit. Start	Exec.Data No.	012 Pt 01	012 Pt 01	012 Pt 01	01	012
Y22	Interpolation					02	012
X12 X13	Posit. Compl.	Present Value	0123456789	0123456789	0123456789	03	012
		Change Value	0123456789	0123456789	0123456789	04	012
① X16 X17	Zero Request	Zero Address	0123456789	0123456789	0123456789	05	012
Y23 Y24	Zero Start					06	012
X1C X1D	Zero Complete					07	012
	Fwd.Jog Start	Output Speed	⑧ 01234567	01234567	01234567	08	012
Y27 Y29	Rev.Jog Start					09	012
Y28 Y2A	Stop	Speed Limit	⑨ 01234567	01234567	01234567	10	012
		Speed Change	⑩ 01234567	01234567	01234567	11	012
Y25 Y26	Pos. Started	Jog Speed	⑪ 01234567	01234567	01234567	12	012
	BUSY	Jog Spd.Limit	⑫ 01234567	01234567	01234567	13	012
X18 X19	M Code ON	MCode/ErrCode	012 01	012 01	012 01	14	012
X14 X15	In-position					15	012
X1E X1F	Excessive Err					16	012
						17	012
X10	WDT Err Man.Pulse					18	012
X1A	Batt.ErrX:Wi					19	012
X1B	Error Y:Wi					20	012


No.	Contents of display	Buffer memory address to reference (decimal)	
		X axis	Y axis
①	The ON/OFF status of the I/O signal corresponding to the PC CPU is displayed. The I/O signal is ON when displayed in a reverse display.	—	—
②	The set manual pulser run enabled/disabled status is displayed.	47	347
③	The data number during execution of current positioning is displayed.	48	348
④	The remaining pointer value is displayed.	39	339
⑤	The current value during execution of current positioning is displayed.	602 603	604 605
⑥	The change value of the current value is displayed.	41 42	341 342
⑦	The zero address set value is displayed.	7912 7913	7922 7923
⑧	The set value of the output speed is displayed.	600	601
⑨	The set value of the speed limit is displayed.	7874	7894
⑩	The change value of the speed change is displayed.	40	340
⑪	The set value of the jog speed is displayed.	44	344
⑫	The set value of the jog speed limit is displayed.	7875	7895
⑬	The set value of the M code is displayed. 0: M code not used	46	346
⑭	The error code is displayed when an error occurs.	45	345
⑮	The starting data number of each point is displayed.	0~37	300~337

11.22.2 Zero Return Monitor



No.	Contents of display	Buffer memory address to reference (decimal)	
		X axis	Y axis
①	The ON/OFF status of the I/O signal corresponding to the sequencer CPU is displayed. The I/O signal is ON when displayed in a reverse display.	—	—
②	The set manual pulser run enabled/disabled status is displayed.	47	347
③	The data number during execution of current positioning is displayed.	48	348
④	The remaining pointer value is displayed.	39	339
⑤	The current value during execution of current positioning is displayed.	602 603	604 605
⑥	The change value of the current value is displayed.	41 42	341 342
⑦	The zero address set value is displayed.	7912 7913	7922 7923
⑧	The set value of the output speed is displayed.	600	601
⑨	The set value of the speed limit is displayed.	7874	7894
⑩	The change value of the speed change is displayed.	40	340
⑪	The set value of the zero return speed is displayed.	7914	7924
⑫	The set value of the zero return creep speed is displayed.	7915	7925
⑬	The set value of the M code is displayed. 0: M code not used	46	346
⑭	The error code is displayed when an error occurs.	45	345
⑮	The zero return data is displayed. Method where return is complete when stopper stops 	7918	7928
⑯	The set value of the torque limit is displayed.	7917	7927
⑰	The set value of the dwell time is displayed.	7916	7926

11.22.3 Parameter Data Monitor




No.	Contents of display	Buffer memory address to reference (decimal)	
		X axis	Y axis
①	The ON/OFF status of the I/O signal corresponding to the sequencer CPU is displayed. The I/O signal is ON when displayed in a reverse display.	—	—
②	The set manual pulser run enabled/disabled status is displayed.	47	347
③	The set value of the travel distance per 1 pulse is displayed.	7873	7893
④	The set value of the travel distance per 1 pulse using the manual pulser is displayed.	7884 7885	7904 7905
⑤	The set value of the speed limit is displayed.	7874	7894
⑥	The set value of the jog speed limit is displayed.	7875	7895
⑦	The set value of the acceleration/deceleration time is displayed.	7876	7896
⑧	The set value of the backlash compensation amount is displayed.	7877	7897
⑨	The set value of the upper stroke limit is displayed.	7878 7879	7898 7899
⑩	The set value of the lower stroke limit is displayed.	7880 7881	7900 7901
⑪	The set value of the error compensation amount is displayed.	7882 7883	7902 7903
⑫	The set value of the starting bias speed is displayed.	7886	7906
⑬	The set value of the positioning complete signal output time is displayed.	7887	7907
⑭	The set value of the M code is displayed. 0: M code not used	46	346
⑮	The error code is displayed when an error occurs.	45	345
⑯	The set status of the parameter data is displayed.	7872	7892

11.22.4 M Code Comment Monitor

SET/ Data MONIT END
RESET Chg. MENU

X	Y	X Axis M Code:012	Y Axis M Code:012	X Axis
Y20 Y21	Posit. Start	01 ABCDEFGHIJKLMN	OP ABCDEFGHIJKLMN	Executing
Y22	Interpolation	02 ABCDEFGHIJKLMN	OP ABCDEFGHIJKLMN	Data No.: 012
X18 X19	Posit. Compl.	03 ABCDEFGHIJKLMN	OP ABCDEFGHIJKLMN	Pointer: 012
X16 X17	Zero Return	04 ABCDEFGHIJKLMN	OP ABCDEFGHIJKLMN	Error Code:012
Y23 Y24	Zero Start	05 ABCDEFGHIJKLMN	OP ABCDEFGHIJKLMN	Status: 012
X10 X10	Zero Complete	06 ABCDEFGHIJKLMN	OP ABCDEFGHIJKLMN	-----
Y27 Y29	Fwd.Jog Start	07 ABCDEFGHIJKLMN	OP ABCDEFGHIJKLMN	Y Axis
Y28 Y28	Stop	08 ABCDEFGHIJKLMN	OP ABCDEFGHIJKLMN	Executing
Y25 Y26	Pos. Started	09 ABCDEFGHIJKLMN	OP ABCDEFGHIJKLMN	Data No.: 012
	BUSY	10 ABCDEFGHIJKLMN	OP ABCDEFGHIJKLMN	Pointer: 012
X18 X19	M Code ON	11 ABCDEFGHIJKLMN	OP ABCDEFGHIJKLMN	Error Code:012
X14 X15	In-position	12 ABCDEFGHIJKLMN	OP ABCDEFGHIJKLMN	Status: 012
X1E X1F	Excessive Err	13 ABCDEFGHIJKLMN	OP ABCDEFGHIJKLMN	-----
X10	WDT Err Man.Pulse	14 ABCDEFGHIJKLMN	OP ABCDEFGHIJKLMN	Y Axis
X1A	Batt.ErrX:Hi	15 ABCDEFGHIJKLMN	OP ABCDEFGHIJKLMN	Executing
X1B	Error Y:Hi	16 ABCDEFGHIJKLMN	OP ABCDEFGHIJKLMN	Data No.: 012
		17 ABCDEFGHIJKLMN	OP ABCDEFGHIJKLMN	Pointer: 012
		18 ABCDEFGHIJKLMN	OP ABCDEFGHIJKLMN	Error Code:012
		19 ABCDEFGHIJKLMN	OP ABCDEFGHIJKLMN	Status: 012

No.	Contents of display	Buffer memory address to reference (decimal)												
		X axis	Y axis											
①	The ON/OFF status of the I/O signal corresponding to the sequencer CPU is displayed. The I/O signal is ON when displayed in a reverse display.	—	—											
②	The set manual pulser run enabled/disabled status is displayed.	47	347											
③	The set value of the M code is displayed.	46	346											
④	The set value of the comment for the M code is displayed.	49~200	349~500											
⑤	The data number during execution of current positioning is displayed.	48	348											
⑥	The remaining pointer value is displayed.	39	339											
⑦	The error code is displayed when an error occurs.	45	345											
⑧	<p>The 8 bits where the status is saved are displayed in hexadecimal format.</p> <p>When "FF" is displayed</p>  <table border="1" style="display: inline-table; margin-left: 20px;"> <thead> <tr> <th>*1* display conditions</th> <th>*0* display conditions</th> </tr> </thead> <tbody> <tr> <td>Battery alarm</td> <td rowspan="8" style="text-align: center;">Not condition at left</td> </tr> <tr> <td>Zero return request</td> </tr> <tr> <td>During dwell time</td> </tr> <tr> <td>During positioning busy status (except for zero return, jog run, manual pulser run)</td> </tr> <tr> <td>Zero return complete</td> </tr> <tr> <td>Near signal on</td> </tr> <tr> <td>Drive unit ready signal on</td> </tr> <tr> <td>Stop signal from drive unit on</td> </tr> </tbody> </table>	*1* display conditions	*0* display conditions	Battery alarm	Not condition at left	Zero return request	During dwell time	During positioning busy status (except for zero return, jog run, manual pulser run)	Zero return complete	Near signal on	Drive unit ready signal on	Stop signal from drive unit on	43	343
1 display conditions	*0* display conditions													
Battery alarm	Not condition at left													
Zero return request														
During dwell time														
During positioning busy status (except for zero return, jog run, manual pulser run)														
Zero return complete														
Near signal on														
Drive unit ready signal on														
Stop signal from drive unit on														

11.22.5 I/O Monitor

AD72/A1SD71 Input/Output Monitor Screen						SET/ RESET	Data Chg.	MONIT MENU	END
Inputs (X)			Outputs (Y)						
00	10	MDT Error	20	X In-position	00	10	20	X Posit. Start	
01	11	READY	21	Y In-position	01	11	21	Y Posit. Start	
02	12	X Pos. Complete	22	X Excessive Err	02	12	22	Interpolation	
03	13	Y Pos. Complete	23	Y Excessive Err	03	13	23	X Zero Start	
04	14	X Axis BUSY	24		04	14	24	Y Zero Start	
05	15	Y Axis BUSY	25		05	15	25	X Stop	
06	16	X Zero Request	26		06	16	26	Y Stop	
07	17	Y Zero Request	27		07	17	27	X Fwd.Jog Start	
08	18	X Posit.Started	28		08	18	28	X Rev.Jog Start	
09	19	Y Posit.Started	29		09	19	29	Y Fwd.Jog Start	
0A	1A	Battery Error	2A		0A	1A	2A	Y Rev.Jog Start	
0B	1B	Error Detection	2B		0B	1B	2B	X M Code OFF	
0C	1C	X Zero Complete	2C		0C	1C	2C	Y M Code OFF	
0D	1D	Y Zero Complete	2D		0D	1D	2D	PC READY	
0E	1E	X M Code ON	2E		0E	1E	2E		
0F	1F	Y M Code ON	2F		0F	1F	2F		

①

No.	Contents of display
①	The ON/OFF status of the I/O signal corresponding to the sequencer CPU is displayed. The I/O signal is ON when displayed in a reverse display.

11.22.6 Positioning Data Monitor

The Positioning Data Monitor Screen No. 1 is used as an example.

AD72/A1SD71 Positioning Data Monitor Screen No.01

X	Address	Speed	Dwell	M	Code *	Y	Address	Speed	Dwell	M	Code *
001	01234567	01234	012	012	0	001	01234567	01234	012	012	0
002	01234567	01234	012	012	0	002	01234567	01234	012	012	0
003	01234567	01234	012	012	0	003	01234567	01234	012	012	0
004	01234567	01234	012	012	0	004	01234567	01234	012	012	0
005	01234567	01234	012	012	0	005	01234567	01234	012	012	0
006	01234567	01234	012	012	0	006	01234567	01234	012	012	0
007	01234567	01234	012	012	0	007	01234567	01234	012	012	0
008	01234567	01234	012	012	0	008	01234567	01234	012	012	0
009	01234567	01234	012	012	0	009	01234567	01234	012	012	0
010	01234567	01234	012	012	0	010	01234567	01234	012	012	0
011	01234567	01234	012	012	0	011	01234567	01234	012	012	0
012	01234567	01234	012	012	0	012	01234567	01234	012	012	0
013	01234567	01234	012	012	0	013	01234567	01234	012	012	0
014	01234567	01234	012	012	0	014	01234567	01234	012	012	0
015	01234567	01234	012	012	0	015	01234567	01234	012	012	0
016	01234567	01234	012	012	0	016	01234567	01234	012	012	0
017	01234567	01234	012	012	0	017	01234567	01234	012	012	0
018	01234567	01234	012	012	0	018	01234567	01234	012	012	0
019	01234567	01234	012	012	0	019	01234567	01234	012	012	0
020	01234567	01234	012	012	0	020	01234567	01234	012	012	0

①
②
③
④
⑤

No.	Contents of display	Buffer memory address to reference (decimal)	
		X axis	Y axis
①	The set value of the positioning address for each data number is displayed.	5072~5111	7072~7111
②	The set value of positioning speed for each data number is displayed.	4272~4291	6272~6291
③	The set value of the dwell time for each data number is displayed.	4672~4691	6672~6691
④	The set value of the M code for each data number is displayed.	3872~3891	5872~5891
⑤	<p>The 4 bits where the set status of the positioning pattern, the positioning method, and the positioning direction for each data number is stored are displayed in hexadecimal format.</p> <p>When "F" is displayed</p> <div style="text-align: center;"> </div> <p>① Positioning pattern 00: Positioning complete 01: Positioning continues 11: Speed changes and positioning continues</p> <p>② Positioning method 0: Absolute 1: Incremental</p> <p>③ Positioning direction (only valid in incremental mode) 0: Forward direction (address increase direction) 1: Reverse direction (address decrease direction)</p>	3872~3891	5872~5891

11.23 AD75, A1SD75 Unit Monitor

The contents displayed on each monitor of the AD75P1 (P2, P3) unit and the A1SD75P1 (P2, P3) unit are nearly identical, except for the sections displaying the unit format.


The AD75P3 unit monitor screen is used as an example in this section.

11.23.1 I/O Monitor

AD75P		I/O Monitor Screen		SET/ RESET	Data Chg.	MONIT MENU	END
X				Y			
00	AD75 Ready	10		00		00	Axis#1 Start
01	Axis#1 Started	11		01		01	Axis#2 "
02	Axis#2 "	12		02		02	Axis#3 "
03	Axis#3 "	13		03		03	Axis#1 Stop
04	Axis#1 BUSY	14		04		04	Axis#2 "
05	Axis#2 "	15		05		05	Spar
06	Axis#3 "	16		06		06	Axis#1 FWD JOG
07	Axis#1 Completed	17		07		07	Axis#1 RVS "
08	Axis#2 "	18		08		08	Axis#2 FWD "
09	Axis#3 "	19		09		09	Axis#2 RVS "
0A	Axis#1 Error	1A		0A		0A	Axis#3 FWD "
0B	Axis#2 "	1B		0B		0B	Axis#3 RVS "
0C	Axis#3 "	1C		0C		0C	Axis#3 Stop
0D	Axis#1 M Code	1D		0D		0D	Ready
0E	Axis#2 "	1E		0E		0E	Not for use
0F	Axis#3 "	1F		0F		0F	Not for use

No.	Contents of display
①	The ON/OFF status of the I/O signal corresponding to the PC CPU is displayed. The I/O signal is ON when displayed in a reverse display.

11.23.2 Operation Monitor



No.	Contents of display	Buffer memory address to reference (decimal)		
		Axis 1	Axis 2	Axis 3
①	The feed current value is displayed.	800 801	900 901	1000 1001
②	The axis speed is displayed.	812 813	912 913	1012 1013
③	The axis operation status is displayed.	809	909	1009
④	The axis error No. is displayed when an axis error occurs.	807	907	1007
⑤	The axis warning No. is displayed when an axis warning occurs.	808	908	1008
⑥	The M code (valid M code) that is set in the data during positioning is displayed.	806	906	1006
⑦	Positioning data No. during positioning is displayed. (The actual data No. is also displayed when specified indirectly.)	835	935	1035
⑧ ⑨ ⑩ ⑪	The positioning identifier of the positioning data during positioning is displayed. <div style="text-align: center;"> Bit 15 ~ 8 7 6 5 4 3 ~ 0 <div style="display: flex; justify-content: center; gap: 10px;"> <div style="border: 1px solid black; padding: 2px 5px;">⑨</div> <div style="border: 1px solid black; padding: 2px 5px;">⑪</div> <div style="border: 1px solid black; padding: 2px 5px;">⑩</div> <div style="border: 1px solid black; padding: 2px 5px;">⑧</div> </div> <div style="display: flex; justify-content: center; margin-top: 5px;"> <div style="margin-right: 20px;">↑</div> <div style="margin-right: 20px;">↑</div> <div style="margin-right: 20px;">↑</div> <div>↑</div> </div> <div style="display: flex; justify-content: center; margin-top: 5px;"> <div style="margin-right: 20px;">↑</div> <div style="margin-right: 20px;">↑</div> <div style="margin-right: 20px;">↑</div> <div>↑</div> </div> </div>	838	938	1038

11.23.3 Basic Parameter Monitor

(1) Basic Parameter 1

AD75P Basic Parameter 1		SET/ RESET	Data chg.	MONIT MENU	END
Parameter	Valid Range	1Axis	2Axis	3Axis	
① Unit	0:mm 1:inch 2:degree 3:PULSE	0	0	0	
② Pulse Per Revolution	1 to 65535 [PLS]	01234	01234	01234	
③ Travel Per Revolution	0 to 65535 [$\times 10^{-1}$ mm] [$\times 10^{-5}$ inch] [PLS]	01234	01234	01234	
④ Unit Multiplier	1: x1 10: x10 100: x100 1000: x1000	0123	0123	0123	
⑤ Pulse Output Mode	0:PLS/SIGN Mode 1:CW/CCW Mode 2:A/B Mode	0	0	0	
⑥ Rotation Direction	0:Forward Pulses 1:Reverse Pulses	0	0	0	

No.	Contents of display	Buffer memory address to reference (decimal)		
		Axis 1	Axis 2	Axis 3
①	The command unit for positioning control is displayed.	0	150	300
②	The pulse number per 1 revolution of the motor determined by the machine system is displayed.	1	151	301
③	The travel distance per 1 revolution of the motor determined by the machine system is displayed.	2	152	302
④	The multiplier of the travel distance per 1 pulse is displayed.	3	153	303
⑤	The pulse output mode is displayed.	4	154	304
⑥	The direction of rotation when the current value is increased is displayed.	5	155	305

(2) Basic parameter 2

AD75P		Basic Parameter 2			SET/ RESET	Data Chg.	MONIT MENU	END
Parameter	Valid Range	1Axis	2Axis	3Axis				
① — Speed Limit	1 to 600000000 [$\times 10^{-5}$ mm/min] 1 to 600000000 [$\times 10^{-3}$ inch/min] 1 to 600000000 [$\times 10^{-3}$ deg/min] 0 to 1000000 [PLS/sec]	012345678	012345678	012345678				
② — Accel.Time #0	1 to 65535 [msec]	01234	01234	01234				
③ — Decel.Time #0	1 to 65535 [msec]	01234	01234	01234				

No.	Contents of display	Buffer memory address to reference (decimal)		
		Axis 1	Axis 2	Axis 3
①	The maximum speed for the positioning operation (also including zero return) and the manual pulser operation is displayed.	6 7	156 157	306 307
②	With the positioning operation, the acceleration time 0 from speed 0 until the speed limit has been attained is displayed.	8 9	158 159	308 309
③	With the positioning operation, the deceleration time 0 from the speed limit to 0 speed is displayed.	10 11	160 161	310 311

11.23.4 Extended Parameter Monitor

(1) Extended Parameter 1

AD75P		Extended Parameter 1			SET/ RESET	Data Chg.	MONIT MENU	END
Parameter	Valid Range	Axis1	Axis2	Axis3				
① Back Lash Compensation	0 to 65535 [$\times 10^{-1}$ μm] [$\times 10^{-5}$ inch] [PLS]	01234	01234	01234				
② Upper S/W Stroke Limit	-2147483648 to 2147483647 [$\times 10^{-1}$ μm] [$\times 10^{-5}$ inch] [PLS]	01234567890	01234567890	01234567890				
③ Lower S/W Stroke Limit	-2147483648 to 2147483647 [$\times 10^{-1}$ μm] [$\times 10^{-5}$ inch] [PLS]	01234567890	01234567890	01234567890				
④ S/WStrokeLimMode	0:ValComman 1:ValMechan	0	0	0				
⑤ S/WStrokeLimit For JOG & MPG	0:Disabled 1:Enabled	0	0	0				
⑥ Torque Limit	1 to 500 [%]	012	012	012				

No.	Contents of display	Buffer memory address to reference (decimal)		
		Axis 1	Axis 2	Axis 3
①	The machine backlash compensation amount when the positioning direction changes is displayed.	15	165	315
②	The upper limit of the range that the machine can travel is displayed. (Software stroke upper limit)	16	166	316
		17	167	317
③	The lower limit of the range that the machine can travel is displayed. (Software stroke lower limit)	18	168	318
		19	169	319
④	This shows whether the software stroke limit is applied to the feed current value or the feed machine value. Check the feed current value with the operation monitor (Sec. 11.23.1). Check the feed machine value with the target value and the machine value monitor (Sec. 11.23.13).	20	170	320
⑤	This shows whether the software stroke limit for the jog operation and the manual pulser operation is enabled/disabled.	21	171	321
⑥	The torque limit is displayed.	24	174	324

(2) Extended Parameter 2

AD75P		Extended Parameter 2			SET/ RESET	Data Chg.	MONIT MENU	END
Parameter	Valid Range	Axis1	Axis2	Axis3				
① []	Accel.Time#1	1 to 65535 [msec]	012345	012345	012345			
	Accel.Time#2	1 to 65535 [msec]	012345	012345	012345			
	Accel.Time#3	1 to 65535 [msec]	012345	012345	012345			
② []	Decel.Time#1	1 to 65535 [msec]	012345	012345	012345			
	Decel.Time#2	1 to 65535 [msec]	012345	012345	012345			
	Decel.Time#3	1 to 65535 [msec]	012345	012345	012345			

No.	Contents of display	Buffer memory address to reference (decimal)		
		Axis 1	Axis 2	Axis 3
①	With the positioning operation, acceleration time 1 through acceleration time 3 from speed 0 until the speed limit is attained is displayed.	36~41	186~191	336~341
②	With the positioning operation, deceleration time 1 through deceleration time 3 from the speed limit to 0 speed is displayed.	42~47	192~197	342~347

11.23.5 Zero Return Parameter Monitor

(1) Basic parameters for zero return

AD75P		OPR Basic Parameter			SET/ RESET	Data Chg.	MONIT MENU	END
Parameter	Valid Range	1Axis	2Axis	3Axis				
① Method	0:DOG 4:Count#1 1:Stopper#1 5:Count#2 2:Stopper#2 3:Stopper#3	0	0	0				
② Direction	0:Forward 1:Reverse 2147483648 to 2147483647	0	0	0				
③ Address	[$\times 10^{-5}$ μ m] [$\times 10^{-5}$ inch] [PLS] 0 to 35999999	01234567890	01234567890	01234567890				
④ Return Speed	[$\times 10^{-5}$ deg] 1 to 600000000 [$\times 10^{-2}$ mm/min] [$\times 10^{-3}$ inch/mm] [$\times 10^{-3}$ deg/mm] 1 to 1000000 [PLS/sec]	012345678	012345678	012345678				
⑤ Creep Speed	1 to 600000000 [$\times 10^{-2}$ mm/min] [$\times 10^{-3}$ inch/mm] [$\times 10^{-3}$ deg/mm] 1 to 1000000 [PLS/sec]	012345678	012345678	012345678				
⑥ Return Retry	0:No Retru 1:retru	0	0	0				

No.	Contents of display	Buffer memory address to reference (decimal)		
		Axis 1	Axis 2	Axis 3
①	The zero return method is displayed.	70	220	370
②	The zero return direction is displayed. Forward: address increase direction Reverse: address decrease direction	71	221	371
③	The zero address that is set when the zero return is complete is displayed.	72 73	222 223	372 373
④	The maximum speed for the zero return is displayed.	74 75	224 225	374 375
⑤	The creep speed after the near signal turns on is displayed. (speed before zero return is complete)	76 77	226 227	376 377
⑥	This indicates whether or not to retry the zero return with the zero return retry function.	78	228	378

(2) Detailed parameters for origin return

AD75P		OPR Extended Parameter			SET/ RESET	Data Chg.	MONIT MENU	END
Parameter	Valid Range	1Axis	2Axis	3Axis				
① OPR Dwell Time	0 to 65535 [msec]	01234	01234	01234				
② OPR Torque Limit	1 to 300 [%]	012	012	012				
③ Travel Distance After DOG	0 to 2147483647 [$\times 10^{-1}$ μ m] [$\times 10^{-5}$ inch] [PLS]	0123456789	0123456789	0123456789				
④ OPR Accel. Time	0 to 3	0	0	0				
⑤ OPR Decel. Time	0 to 3	0	0	0				
⑥ OP Distance From Zero	-2147483648 to 2147483647 [$\times 10^{-1}$ μ m] [$\times 10^{-5}$ inch] [PLS]	01234567890	01234567890	01234567890				
	0 to 35999999 [$\times 10^{-5}$ deg]							

No.	Contents of display	Buffer memory address to reference (decimal)		
		Axis 1	Axis 2	Axis 3
①	The time from when the proximity dog goes ON to when the origin point return is completed is displayed. (for stopper stop ①)	79	229	379
②	The restriction value used to limit the torque of the servo motor after reaching the creeping speed is displayed.	86	236	386
③	The amount of movement after the proximity dog goes ON is displayed. (for count equation)	80 81	230 231	380 381
④	The display shows which acceleration time, 0 ~ 3 (basically, this is set using the detailed parameters) is to be used as the acceleration time when making an origin point return.	82	232	382
⑤	The display shows which deceleration time, 0 ~ 3 (basically, this is set using the detailed parameters) is to be used as the deceleration time when making an origin point return.	83	233	383
⑥	The shift amount (amount of movement) for an origin point shift is displayed.	84 85	234 235	384 385

11.23.7 Monitoring the Error Temporary Startup History and Startup History

AD75P Start Error. Start History					SET/ RESET	Data chg.	MONIT MENU	END			
[Start Error History]					[Start History]						
No.Ax.	Start	Mode	Time	Res.	No.Ax.	Start	Mode	Time	Res.		
1	○	01	Op0123	00:00:00.00	012	1	○	01	Op0123	00:00:00.00	012
2	○	01	Op0123	00:00:00.00	012	2	○	01	Op0123	00:00:00.00	012
3	○	01	Op0123	00:00:00.00	012	3	○	01	Op0123	00:00:00.00	012
4	○	01	Op0123	00:00:00.00	012	4	○	01	Op0123	00:00:00.00	012
5	○	01	Op0123	00:00:00.00	012	5	○	01	Op0123	00:00:00.00	012
6	○	01	Op0123	00:00:00.00	012	6	○	01	Op0123	00:00:00.00	012
7	○	01	Op0123	00:00:00.00	012	7	○	01	Op0123	00:00:00.00	012
8	○	01	Op0123	00:00:00.00	012	8	○	01	Op0123	00:00:00.00	012
9	○	01	Op0123	00:00:00.00	012	9	○	01	Op0123	00:00:00.00	012
10	○	01	Op0123	00:00:00.00	012	10	○	01	Op0123	00:00:00.00	012
11	○	01	Op0123	00:00:00.00	012	11	○	01	Op0123	00:00:00.00	012
12	○	01	Op0123	00:00:00.00	012	12	○	01	Op0123	00:00:00.00	012
13	○	01	Op0123	00:00:00.00	012	13	○	01	Op0123	00:00:00.00	012
14	○	01	Op0123	00:00:00.00	012	14	○	01	Op0123	00:00:00.00	012
15	○	01	Op0123	00:00:00.00	012	15	○	01	Op0123	00:00:00.00	012
16	○	01	Op0123	00:00:00.00	012	16	○	01	Op0123	00:00:00.00	012

①

②

No.	Contents of display	Buffer memory address to reference (decimal)		
		Axis 1	Axis 2	Axis 3
①	The error startup history is displayed. Axis : Startup axis no. Startup source: Source which initiates startup (*1) 00: PC CPU (Y) 01: External signal 10: Peripheral equipment (AD75P) Type of operation: Type of operation at startup (*2) If restarting from a stopped status, "Re" is displayed just before this. Time : Startup time (hour: minutes: sec- onds: 100 milliseconds) Judgment : Error code when startup error oc- curred (decimal) The numeric values of the least significant 14 bits of the buffer memory are displayed.	543~622	(543, 548...) (544, 549...)	(544, 549...)
②	The startup history is displayed. (The contents of the display are the same as in ①.) Axis : Startup axis no. Startup source: Source which initiates startup (*1) Type of operation: Type of operation at startup (*2) Time : Startup time (hour: minutes: sec- onds: 100 milliseconds) Judgment : Error code when startup error oc- curred (decimal)	462~541	(462, 467...) (463, 468...) (463, 468...)	(464 · 465, 469 · 470...) (466, 471...)

- *1 The display is based on the data in Bits 13 and 14 of the applicable buffer memory.
- *2 The correspondance between the numeric value displayed in the "Operation Type" column and the type of startup is shown below. The display is based on the data in Bits 0 ~ 12 of the applicable buffer memory.

Data no.	Type of startup	Remarks
1~600	Startup with positioning operation	Indicates the data number at the time of startup
7000	Startup with block positioning operation	
8051	Startup with origin point return	
8052	Startup with high-speed origin point return	
8053	Startup with change in current value	
8160	Startup with jogging operation	
8161	Startup with manual pulser operation	

Items with the "Re" prefix are displayed based on the data of Bit 15 of the applicable buffer memory.

11.23.8 Monitoring Speed/Position Control

AD75P		Speed Position Control			
		SET/ RESET	Data chg.	MONIT MENU	END
		Axis1	Axis2	Axis3	
①	Travel After Switch [$\times 10^{-1}$ mm] [$\times 10^{-5}$ inch] [$\times 10^{-5}$ deg] [PLS]	01234567890	01234567890	01234567890	
②	Travel Correction Register [$\times 10^{-1}$ mm] [$\times 10^{-5}$ inch] [$\times 10^{-5}$ deg] [PLS]	01234567890	01234567890	01234567890	
③	V/P Switch Latch	●	○	●	
④	Switch Enabled 0:Disable 1:Enable	0	0	0	
⑤	V-Control	○	●	●	

No.	Contents of display	Buffer memory address to reference (decimal)		
		Axis 1	Axis 2	Axis 3
①	The address (amount of movement) for position control in speed/position changing control is displayed.	814 815	914 915	1014 1015
②	The changed value is displayed when the position control address (amount of movement) in the speed control function is changed in speed/position changing control.	1164 1165	1214 1215	1264 1265
③	The ON/OFF status of the speed/position changing latch flag (the flag indicating the control status) is displayed. (The status of Bit 1 of the pertinent buffer memory is displayed.) ● :Position control in progress ○ :Speed control in progress/positioning is in progress in another control method or operation method (such as jogging)	817	917	1017
④	This displays whether control switching in response to an external signal is effective or not in speed/position changing control. 1 :Switching is permitted 0 :Switching is not permitted	1163	1213	1263
⑤	The ON/OFF status flag during speed control (the flag indicating the control status) is displayed. (The status of Bit 0 of the pertinent buffer memory is displayed.) ● :Speed control in progress ○ :Position control in progress/positioning is in progress in another control method or operation method (such as jogging)	817	917	1017

11.23.9 Monitoring Special Startup, Jogging, and Manual Pulser Operation

AD75P SP Start JOG MPG Drive					SET/ RESET	Data chg.	MONIT MENU	END
[Special Star]								
	Operation	Information	Parameter	Data No.				
①	#1 012	01 H	012	0123				
	#2 012	01 H	012	0123				
	#3 012	01 H	012	0123				
[JOG & MPG]								
		Axis1	Axis2	Axis3				
②	JOG Speed	012345678	012345678	012345678				
③	MPG Magnify	012	012	012				
④	MPG Enabled 0:Disable 1:Enable	0	0	0				

No.	Contents of display	Buffer memory address to reference (decimal)		
		Axis 1	Axis 2	Axis 3
①	The information for the special startup currently in progress is displayed. Operation : Startup data pointer Information : Command code of the special startup data specified by the startup data pointer Parameter : Parameters for the special startup data specified by the startup data pointer Data No. : Positioning data number specified by the startup data pointer	832 827 828 829	932 927 928 929	1032 1027 1028 1029
②	The jogging speed used during jogging operation is displayed.	1160 1161	1210 1211	1260 1261
③	The input magnification per one pulse from the manual pulser is displayed.	1168 1169	1218 1219	1268 1269
④	The display shows whether or not manual pulser operation is permitted.	1167	1217	1267

11.23.11 Monitoring Axis Control Data

AD75P		Axis Control Data			SET/ RESET	Data chg.	MONIT MENU	END
		Axis1	Axis2	Axis3				
①	Correcting Address	[$\times 10^{-1}$ μ m] [$\times 10^{-5}$ inch] [$\times 10^{-5}$ deg] [PLS]	01234567890	01234567890	01234567890			
②	Correcting Speed	[$\times 10^{-5}$ mm/min] [$\times 10^{-3}$ inch/min] [$\times 10^{-3}$ deg/min] [PLS/sec]	012345678	012345678	012345678			
③	Speed Dump	[%]	012	012	012			
④	Step Valid Flag	0:Disable 1:Enable	0	0	0			
⑤	Step Mode	0:Dec Unit 1:Data No.	0	0	0			
⑥	Skip Command	0:Completed 1:Req	0	0	0			
⑦	EXT.Start Enable	0:Disable 1:Enable	0	0	0			

No.	Contents of display	Buffer memory address to reference (decimal)		
		Axis 1	Axis 2	Axis 3
①	The value for the current value change is displayed.	1154 1155	1204 1205	1254 1255
②	The speed change value is displayed.	1156 1157	1206 1207	1256 1257
③	The override value in relation to the positioning speed is displayed.	1159	1209	1259
④	The ON/OFF status for the flag indicating whether step action is effective is displayed; this flag confirms the actions of the various positioning data in the step function. 1 : Step effective (step action is carried out) 0 : Step invalid (step action is not carried out)	1172	1222	1272
⑤	This displays the unit to be used for step action in operation based on the step function. 1 : Step action in data number units 0 : Step action in reduced-speed units	1173	1223	1273
⑥	The ON/OFF status of the skip command is displayed. 1 : Request for skip in progress 0 : Request for skip has been completed/No request	1175	1225	1275
⑦	The display shows whether control based on an external startup signal is effective or invalid. 1 : External startup effective 0 : External startup invalid	1171	1221	1271

11.23.12 Monitoring the Output Speed

AD75P		Output Speed			SET/ RESET	Data Chg.	MONIT MENU	END
		Axis1	Axis2	Axis3				
①	Target Speed	[$\times 10^{-5}$ mm/min] [$\times 10^{-3}$ inch/min] [$\times 10^{-3}$ deg/min] [PLS/sec]	012345678	012345678	012345678			
②	Current Speed	[$\times 10^{-5}$ mm/min] [$\times 10^{-3}$ inch/min] [$\times 10^{-3}$ deg/min] [PLS/sec]	012345678	012345678	012345678			
③	Axis Speed	[$\times 10^{-5}$ mm/min] [$\times 10^{-3}$ inch/min] [$\times 10^{-3}$ deg/min] [PLS/sec]	012345678	012345678	012345678			


No.	Contents of display	Buffer memory address to reference (decimal)		
		Axis 1	Axis 2	Axis 3
①	When positioning, the actual speed, taking the override and the speed limit value into consideration, is displayed. When using interpolation operation, the target speeds for the composite speed/reference axis speed are displayed on the reference axis side, and "0" is displayed on the other axis side. When using jogging operation, the actual speed taking the jogging speed limit value into consideration is displayed.	820 821	920 921	1020 1021
②	The speed set for the positioning data is displayed. When using interpolation operation, the target speeds for the composite speed/reference axis speed are displayed on the reference axis side, and "0" is displayed on the other axis side.	810 811	910 911	1010 1011
③	The actual positioning speed is displayed.	812 813	912 913	1012 1013

11.23.13 Monitoring the Target values and Machine Values

AD75P		Destination . Mechanical Val			SET/ RESET	Data Chg.	MONIT MENU	END
		Axis1	Axis2	Axis3				
①	Destina [$\times 10^{-1}$ μ m] [$\times 10^{-5}$ inch] [$\times 10^{-5}$ deg] [PLS]	01234567890	01234567890	01234567890				
②	Mechanical Address [$\times 10^{-1}$ μ m] [$\times 10^{-5}$ inch] [$\times 10^{-5}$ deg] [PLS]	01234567890	01234567890	01234567890				

No.	Contents of display	Buffer memory address to reference (decimal)		
		Axis 1	Axis 2	Axis 3
①	The target values when using positioning based on position control are displayed. (With ABS: address/With INC: amount of movement) When using speed/position changing control, the amount of movement following a change to position control is displayed.	818 819	918 919	1018 1019
②	The individual position determined by the machine is used as the machine origin point, and the current machine feed value (position) is displayed.	802 803	902 903	1002 1003

11.23.14 Monitoring External I/O Signals and Status Signals (Flags)



No.	Contents of display	Buffer memory address to reference (decimal)		
		Axis 1	Axis 2	Axis 3
①	<p>The ON/OFF status for the external I/O signal corresponding to the signal name shown on the screen is displayed. ○ : OFF ● : ON</p> <p>Bit 15 ~ 9 8 7 6 5 4 3 2 1 0</p>	816	916	1016
②	<p>The ON/OFF status for the various flags corresponding to the flag shown on the screen is displayed. ○ : OFF ● : ON</p> <p>Bit 15 ~ 12 11 10 9 ~ 4 3 2 1 0</p>	817	917	1017

11.23.15 Monitoring Positioning Information

										SET/ RESET	Data chg.	MONIT MENU	END	
AD75P Positioning Information Monitor Screen No. 1														
①	Ax 1	No.	Pat rn	Me thod	▲	▼	Address	Arc Address	Speed	Dwell Time	M Code			
		1	01	01	01	01	01234567890	01234567890	012345678	01234	01234			
		2	01	01	01	01	01234567890	01234567890	012345678	01234	01234			
		3	01	01	01	01	01234567890	01234567890	012345678	01234	01234			
		4	01	01	01	01	01234567890	01234567890	012345678	01234	01234			
5	01	01	01	01	01234567890	01234567890	012345678	01234	01234					
②	Ax 2	No.	Pat rn	Me thod	▲	▼	Address	Arc Address	Speed	Dwell Time	M Code			
		1	01	01	01	01	01234567890	01234567890	012345678	01234	01234			
		2	01	01	01	01	01234567890	01234567890	012345678	01234	01234			
		3	01	01	01	01	01234567890	01234567890	012345678	01234	01234			
		4	01	01	01	01	01234567890	01234567890	012345678	01234	01234			
5	01	01	01	01	01234567890	01234567890	012345678	01234	01234					
③	Ax 3	No.	Pat rn	Me thod	▲	▼	Address	Arc Address	Speed	Dwell Time	M Code			
		1	01	01	01	01	01234567890	01234567890	012345678	01234	01234			
		2	01	01	01	01	01234567890	01234567890	012345678	01234	01234			
		3	01	01	01	01	01234567890	01234567890	012345678	01234	01234			
		4	01	01	01	01	01234567890	01234567890	012345678	01234	01234			
5	01	01	01	01	01234567890	01234567890	012345678	01234	01234					

No.	Contents of display	Buffer memory address to reference (decimal)
①	<p>The positioning data corresponding to the data number and data name shown on the screen for Axis 1 is displayed.</p> <p>Pattern : This is displayed based on Bits 0 ~ 1 of the applicable buffer memory address.</p> <p>Control method : Acceleration : Deceleration : Address : Arc address : Specified speed : Dwell time : M code :</p>	<p>1300~2299</p> <p>(1300, 1310...)</p> <p>(1300, 1310...)</p> <p>(1300, 1310...)</p> <p>(1300, 1310...)</p> <p>(1306 · 1307, 1316 · 1317...)</p> <p>(1308 · 1309, 1318 · 1319...)</p> <p>(1304, 1314...)</p> <p>(1302, 1312...)</p> <p>(1301, 1311...)</p>
②	<p>The positioning data corresponding to the data number and data name shown on the screen for Axis 2 is displayed.</p> <p>Pattern : (The contents of the display are the same as for (1).)</p> <p>Address : Arc address : Dwell time : M code :</p>	<p>2300~3299</p> <p>(2300, 2310...)</p> <p>(2306 · 2307, 2316 · 2317...)</p> <p>(2308 · 2309, 2318 · 2319...)</p> <p>(2302, 2312...)</p> <p>(2301, 2311...)</p>
③	<p>The positioning data corresponding to the data number and data name shown on the screen for Axis 3 is displayed.</p> <p>Pattern : (The contents of the display are the same as for (1).)</p> <p>Address : Arc address : Dwell time : M code :</p>	<p>3300~4299</p> <p>(3300, 3310...)</p> <p>(3306 · 3307, 3316 · 3317...)</p> <p>(3308 · 3309, 3318 · 3319...)</p> <p>(3302, 3312...)</p> <p>(3301, 3311...)</p>

11.24 Monitoring the AJ71PT32-S3 and A1SJ71PT32-S3 Units

The contents displayed on the monitor screens of the AJ71PT32-S3 and A1SJ71PT32-S3 units are the same, except for the section where the unit model name is displayed.

In this section, we will look at the monitor screens for the AJ71PT32-S3.

11.24.1 I/O Monitor (I/O Mode)

AJ71PT32-S3 I/O Monitor Scr. (I/O Dedicated Mode)				SET/ RESET	Data Chg.	MONIT MENU	END
Inputs (X)			Outputs (Y)				
00	Hardware Fault	10	00				10
01	Link Working	11	01				11
02		12	02				12
03		13	03				13
04		14	04				14
05	Test Mode	15	05				15
06	Link Error Detect	16	06				16
07	Link Comms. Error	17	07				17
08		18	08				18 Link Comms.Start
09		19	09				19
0A		1A	0A				1A FROM/TO Response
0B		1B	0B				1B Faulty Sta.Clear
0C		1C	0C				1C
0D		1D	0D				1D Error Reset
0E		1E	0E				1E
0F		1F	0F				1F

No.	Contents of display
①	The ON/OFF status of the I/O signal corresponding to the PC CPU of the master unit is displayed. The I/O signal is ON when displayed in a reversed display.

11.24.2 Monitoring the Link Status

AJ71PT32-S3 Link Data Monitor Screen		SET/ RESET	Data Chg.	MONIT MENU	END	
①	No. of Remote Stations 01	Communication Error Code 01				④
	Remote I/O Units Card Data	Accumulative Faulty Station Detection 0: Normal 1: Error				
	ST : 8 7 6 5 4 3 2 1	FEDCBA9876543210				
	8 - 10110110110110110	16- 10110110110110110				⑤
	16 - 90110110110110110	32-170110110110110110				
②	24 - 170110110110110110	48-330110110110110110				
	32 - 250110110110110110	64-490110110110110110				
	40 - 330110110110110110	Faulty Station Detection				
	48 - 410110110110110110	FEDCBA9876543210				
	56 - 490110110110110110	16- 10110110110110110				⑥
	64 - 570110110110110110	32-170110110110110110				
	Card Data: 00 No remote unit or no initial communication	48-330110110110110110				
	01 Input, partial refresh or remote terminal	64-490110110110110110				⑦
	10 Output remote unit	Accumulative Input Error Detection for Partial Refresh				
	Remote Terminal Unit Faulty Station	FEDCBA9876543210				
③	No. FEDCBA9876543210	0110110110110110				⑧
		Input Faulty Error Detection for Partial Refresh				
		FEDCBA9876543210				
		0110110110110110				

No.	Contents of display	Buffer memory address to reference (decimal)
①	The total number of remote stations connected is displayed.	0
②	This shows whether the station number of the connected remote unit is for input or output.	70~77
③	A "1" is displayed for the remote terminal unit number where the error has occurred.	195
④	When an error occurs in link communications, the communications error code is displayed. 0: No error 1: Initial data error 2: Circuit error 3: Erroneous station issued 4: Separate refresh type remote I/O unit error	107
⑤	A communications error has occurred, and a "1" is displayed for the station number of the remote unit. The detection status is maintained until the error is reset.	90~93
⑥	A communications error has occurred, and a "1" is displayed for the station number of the remote unit. If the automatic recovery function is on, a "0" is displayed when normal communications have been resumed.	100~103
⑦	A "1" is displayed for the station number of a separate refresh type remote I/O unit where the input information could not be read out within a given time period. The detection status is maintained until the error is reset.	598
⑧	A "1" is displayed for the station number of a separate refresh type remote I/O unit where the input information could not be read out within a given time period. If the automatic recovery function is on, a "0" is displayed when the station is able to read the input normally.	599

11.24.3 Monitoring Batch Refreshing

SET/
Data
MONIT
END
RESET
Chg.
MENU

AJ71PT32-S3 Batch Refresh Data Monitor Screen

Station Number	Transmission Data	Receive Data
	76543210765432107654321076543210	76543210765432107654321076543210
4 - 1	01101101101101101101101101101101	01101101101101101101101101101101
8 - 5	01101101101101101101101101101101	01101101101101101101101101101101
12 - 9	01101101101101101101101101101101	01101101101101101101101101101101
16 -13	01101101101101101101101101101101	01101101101101101101101101101101
20 -17	01101101101101101101101101101101	01101101101101101101101101101101
24 -21	01101101101101101101101101101101	01101101101101101101101101101101
28 -25	01101101101101101101101101101101	01101101101101101101101101101101
32 -29	01101101101101101101101101101101	01101101101101101101101101101101
36 -33	01101101101101101101101101101101	01101101101101101101101101101101
40 -37	01101101101101101101101101101101	01101101101101101101101101101101
44 -41	01101101101101101101101101101101	01101101101101101101101101101101
48 -45	01101101101101101101101101101101	01101101101101101101101101101101
52 -49	01101101101101101101101101101101	01101101101101101101101101101101
56 -53	01101101101101101101101101101101	01101101101101101101101101101101
60 -57	01101101101101101101101101101101	01101101101101101101101101101101
64 -61	01101101101101101101101101101101	01101101101101101101101101101101

①
②

No.	Contents of display	Buffer memory address to reference (decimal)
①	The output status for the batch refresh type remote I/O unit is displayed. 0: OFF 1: ON	10~41
②	The input status for the batch refresh type remote I/O unit is displayed. 0: OFF 1: ON	110~141

11.24.5 Monitoring Input and Output (Expansion Mode)

AJ71PT32-S3 I/O Monitor Screen (Extension Mode)				SET/ RESET	Data Chg.	MONIT MENU	END
Inputs (X)				Outputs (Y)			
00 Tx.Complete No.1	15 Tx.Complete No.12	00 Tx.Request No.1	15 Tx.Request No.12				
01 Read Request	16 Read Request	01 Read Complete	16 Read Complete				
02 Tx.Complete No.2	17 Tx.Complete No.13	02 Tx.Request No.2	17 Tx.Request No.13				
03 Read Request	18 Read Request	03 Read Complete	18 Read Complete				
04 Tx.Complete No.3	19 Tx.Complete No.14	04 Tx.Request No.3	19 Tx.Request No.14				
05 Read Request	20 Read Request	05 Read Complete	20 Read Complete				
06 Tx.Complete No.4		06 Tx.Request No.4					
07 Read Request		07 Read Complete					
08 Tx.Complete No.5	20 Hardware Fault	08 Tx.Request No.5	20				
09 Read Request	21 Link Working	09 Read Complete	21				
0A Tx.Complete No.6	22	0A Tx.Request No.6	22				
0B Read Request	23 RxData Clear Comp	0B Read Complete	23 RxData Clear Req.				
0C Tx.Complete No.7	24 RTU Error Detect	0C Tx.Request No.7	24 RTU Error Clear				
0D Read Request	25 Test Mode	0D Read Complete	25				
0E Tx.Complete No.8	26 Link Error	0E Tx.Request No.8	26				
0F Read Request	27 Link Comms. Error	0F Read Complete	27				
10 Tx.Complete No.9	28 ROM Error	10 Tx.Request No.9	28 Link Comms.Start				
11 Read Request	29	11 Read Complete	29				
12 Tx.Complete No.10	2A	12 Tx.Request No.10	2A FROM/TO Response				
13 Read Request	2B	13 Read Complete	2B Faulty Sta.Clear				
14 Tx.Complete No.11	2C	14 Tx.Request No.11	2C Switch BM Chann.				
15 Read Request	2D	15 Read Complete	2D Error Reset				

No.	Contents of display
①	The ON/OFF status for the I/O signal corresponding to the PC CPU of the master unit is displayed. An I/O signal is ON when it is displayed in a reverse display.

11.25 Monitoring the AJ71ID1 (ID2)-R4 and A1SK71ID1 (ID2)-R4 Units

11.25.1 Action Monitor (CH 1 and CH 2)

AJ71ID		Movement Monitor Screen CH1							
Addr	Data	Addr	Data	Addr	Data	Addr	Data	Addr	Data
K 100	H 0123	K 116	H 0123	K 132	H 0123	K 148	H 0123		
K 101	H 0123	K 117	H 0123	K 133	H 0123	K 149	H 0123		
K 102	H 0123	K 118	H 0123	K 134	H 0123	K 150	H 0123		
K 103	H 0123	K 119	H 0123	K 135	H 0123	K 151	H 0123		
K 104	H 0123	K 120	H 0123	K 136	H 0123	K 152	H 0123		
K 105	H 0123	K 121	H 0123	K 137	H 0123	K 153	H 0123		
K 106	H 0123	K 122	H 0123	K 138	H 0123	K 154	H 0123		
K 107	H 0123	K 123	H 0123	K 139	H 0123	K 155	H 0123		
K 108	H 0123	K 124	H 0123	K 140	H 0123	K 156	H 0123		
K 109	H 0123	K 125	H 0123	K 141	H 0123	K 157	H 0123		
K 110	H 0123	K 126	H 0123	K 142	H 0123	K 158	H 0123		
K 111	H 0123	K 127	H 0123	K 143	H 0123	K 159	H 0123		
K 112	H 0123	K 128	H 0123	K 144	H 0123	K 160	H 0123		
K 113	H 0123	K 129	H 0123	K 145	H 0123	K 161	H 0123		
K 114	H 0123	K 130	H 0123	K 146	H 0123	K 162	H 0123		
K 115	H 0123	K 131	H 0123	K 147	H 0123	K 163	H 0123		

No.	Contents of display	Buffer memory address to reference (decimal)	
		CH. 1	CH. 2
①	The contents of the data storage area are displayed in address units. (The illustration above shows the results when the CH 1 side is monitored.) (Addresses are displayed in decimal format and data in hexadecimal format.)	100~163	4100~4163

11.25.2 I/O Monitor

AJ71ID		Input/Output Monitor Screen		SET/ RESET	Data Chg.	MONIT MENU	END				
				X				Y			
00	WDT Error	10		00		10					
01		11		01		11					
02		12		02		12					
03	CH1 ID-BUSY	13		03		13					
04	ID-CommandComplete	14		04		14	CH1 ID-Command Exe				
05	ID-Error	15		05		15					
06	ID-READY	16		06		16					
07		17		07		17					
08		18		08		18					
09		19		09		19					
0A		1A		0A		1A					
0B	CH2 ID-BUSY	1B		0B		1B					
0C	ID-CommandComplete	1C		0C		1C	CH2 ID-Command Exe				
0D	ID-Error	1D		0D		1D					
0E		1E		0E		1E					
0F		1F		0F		1F					

No.	Contents of display
①	The ON/OFF status for the I/O signal corresponding to the PC CPU is displayed. An I/O signal is ON when it is displayed in a reverse display.

11.25.3 Monitoring Set Information

AJ71ID Set Up Information Monitor Screen		SET/ RESET	Data chg.	MONIT MENU	END
		Valid range		CH1	CH2
①	ID Command			Continual Write	Comparison Write
②	Address. Data	0~4094 · 1~3900		K 0123 · K 0123Word	K 0123 · K 0123Word
③	Retry	0~32767		01234	01234
④	Total Communica.			0123456789	0123456789
⑤	Comparison			<input type="checkbox"/> Disagreement <input checked="" type="checkbox"/> OFF	<input checked="" type="checkbox"/> Disagreement <input type="checkbox"/> OFF
⑥	Copy direction	12: CH1 → CH2 21: " ← "		CH1 → CH2	
⑦	LED Status			<input checked="" type="checkbox"/> DC24V <input type="checkbox"/> IDERR <input type="checkbox"/> ERR	<input checked="" type="checkbox"/> DC24V <input type="checkbox"/> IDERR <input type="checkbox"/> ERR
⑧	Err Record Latst Past1 Past2 Past3 Past4			Execution Word Number Error Execution Address Error Write Incompletion Error Set Up Address Error Set Up Word Number Error	Data Carrier Absent Error Data Carrier Communicate Error Command Execution Error Command Code Error Communicate Condition Error

No.	Contents of display	Buffer memory address to reference (decimal)	
		CH. 1	CH. 2
①	The output command for the data carrier is displayed.	0	4000
②	The first address for the data carrier which is reading and writing the data is displayed, along with the number of processing points for the data being read and written.	1 2	4001 4002
③	The number of retries when a data communications error occurs is displayed.	8	4008
④	The number of communications (accumulated number of times) for the data carrier is displayed (excluding the CM, CL, OF, and ON commands).	22 23	4022 4023
⑤	The results of executing the Compare command (CM) are displayed.	4 5	4004 4005
⑥	The direction in which data is copied when the Copy Data command (CO) is executed is displayed.	—	4010
⑦	The lighting status of the Error LED is displayed. ("■" is displayed when an error occurs.)	12	4012
⑧	The error codes for the five most recent times that an error has occurred is displayed.	14~18	4014~4018

11.26 Monitoring the A84AD Unit


11.26.1 Action Monitor

A84AD Operation Monitor Screen				SET/ RESET	Data Chg.	MONIT MENU	END
	Input/Output Status [%]		Temp. Value [C]	Module Code	O/P Over	O/P Under	
Channel 1	01234.6 ①	01234.6	01234 ②	01	0	0	③
Channel 2	01234.6	01234.6	01234	01	0	0	④
Channel 3	01234.6	01234.6	01234	01	0	0	⑤
Channel 4	01234.6	01234.6	01234	01	0	0	
Loaded Module Code	02,04,05,10,12 13,14,15,18,1A 1C,1E,1F	06,07,16,17	18,1A,1C 1E,1F	Writing Data Error CH:0 Code:0			⑥
Channel	4321		<input type="checkbox"/> WDT Error <input type="checkbox"/> Module 1 Fault <input type="checkbox"/> Module 2 Fault <input type="checkbox"/> Module 3 Fault <input type="checkbox"/> Module 4 Fault				⑨
O/P Enable Valid	0110110110110110						
O/P Enabled	0000						

⑦ ⑧

No.	Contents of display	Buffer memory address to reference (decimal)
①	The current I/O data, a value between 0 ~ 1000 or 0 ~ 2000 for the digital I/O value of the various channels, is displayed as a percentage ranging from 0 to 100%, in the corresponding module code column.	10~13
②	The temperature detection values for the various channels are displayed.	18~21
③	The codes for installed modules for the various channels are displayed.	28~31
④	If the digital values for the various channels have been set to values larger than the maximum value for the various modules, a "1" is displayed in the "Output Over" column.	22~25
⑤	If the digital values for the various channels have been set to values smaller than the maximum value for the various modules, a "1" is displayed in the "Output Under" column.	22~25
⑥	If an error occurs in the data being written, the channel on which the error occurred, and the error code, are displayed.	26
⑦	The specified effective/invalid status for the analog Output Enable signal for each of the channels is displayed. 0: Effective 1: Invalid	27
⑧	The specified status for the Output Enable command of each of the channels is displayed. 0: The offset value is output as an analog value. 1: The analog value following D/A conversion is output.	—
⑨	A "■" is displayed when a watchdog timer error occurs. A "■" is displayed when an error occurs in a module on the various channels.	— —

11.26.2 Setting Monitor




No.	Contents of display	Buffer memory address to reference (decimal)
①	The specified status for the averaging processing/sampling processing of each of the channels is displayed.	1
②	The specified status for the averaging processing of each of the channels is displayed.	1
③	The values set for the time and number of times for averaging processing of each of the channels is displayed.	2~5
④	When a temperature sensor input module is installed, the offset values for each of the channels is displayed.	32, 34, 36, 38
⑤	When a temperature sensor input module is installed, the gain values for each of the channels is displayed.	33, 35, 37, 39

11.26.3 I/O Monitor

A84AD Input/Output Monitor Screen				SET/ RESET	Data Chg.	MONIT MENU	END
Inputs (X)				Outputs (Y)			
00	10	WDT Error	20	00	10	20	CH1 Enabled
01	11	READY	21	01	11	21	CH2 Enabled
02	12	CH1 Mod. Fault	22	02	12	22	CH3 Enabled
03	13	CH2 Mod. Fault	23	03	13	23	CH4 Enabled
04	14	CH3 Mod. Fault	24	04	14	24	
05	15	CH4 Mod. Fault	25	05	15	25	
06	16		26	06	16	26	
07	17		27	07	17	27	
08	18		28	08	18	28	
09	19		29	09	19	29	
0A	1A		2A	0A	1A	2A	
0B	1B		2B	0B	1B	2B	
0C	1C		2C	0C	1C	2C	
0D	1D		2D	0D	1D	2D	
0E	1E		2E	0E	1E	2E	
0F	1F		2F	0F	1F	2F	

No.	Contents of display
①	The ON/OFF status for the I/O signal corresponding to the PC CPU is displayed. An I/O signal is ON when it is displayed in a reverse display.

11.26.4 Monitoring Graphs



No.	Contents of display	Buffer memory address to reference (decimal)
①	The current I/O value, a value between 0 ~ 1000 or 0 ~ 2000 for the digital I/O value of the various channels, is displayed as a percentage ranging from 0 to 100%.	10~13
②	The temperature detection values for the various channels are displayed.	18~21
③	The module codes for installed modules for the various channels are displayed.	28~31
④	The specified effective/invalid status for the Analog Output Enable signal for each of the channels is displayed. 0: Effective 1: Invalid	27
	The specified status for the Output Enable command of each of the channels is displayed. 0: The offset value is output as an analog value. 1: The analog value following D/A conversion is output.	---
⑤	A "■" is displayed when a watchdog timer error occurs.	---
	A "■" is displayed when an error occurs in a module on the various channels.	---

12. Operating I/O Unit Monitor Screens

This section explains how the various screens are operated in the special unit monitor function, when monitoring input or output units.

12.1 Specifying the Unit to be Monitored

This describes how to start monitoring any desired special input or output unit.

[Operation Procedure]

Display the System Configuration screen.


.... See Section 11.1.1.

Specify the unit to be monitored. (Touch the position at which the unit is displayed.)

(1) Of the units installed in Slot 0 ~ Slot 7 of the base unit, specify a unit for which "Input" or "Output" is displayed. For information on specifying special function units, please see Section 11.1.3.

(2) For information on confirming the displayed contents and subsequent operation, please see Section 12.2.

Display the monitor screen for the specified unit.




* Tests cannot be conducted on input or output units.

To Section 12.2

12.2 Configuration and Key Functions on Monitor Screens

This section describes the configuration of monitor screens displayed by specifying the input unit on the system configuration screen, and explains the functions of the keys displayed on the screen.

(1) Contents displayed on the screen (for an input unit)



The statuses of input and output signals are displayed after being read out from the corresponding unit.
(OS is carried out automatically.)

Statuses for up to 64 can be displayed.
Signal statuses:

- : ON
- : OFF

①	The type of the applicable unit (input or output unit) is displayed.
②	The name of the signal being monitored (X or Y) is displayed.
③	The number and status of the input or output signal is displayed.
④	Keys used in the operations on the monitor screen indicated by (2) are displayed (touch input).

(2) Key functions

The functions of the keys used for operations on the monitor screen are indicated.

Key	Function
END	This concludes the monitoring process and returns to the screen displayed when the special unit monitor function was first started.
sys. conf.	This concludes the current monitor and returns to the system configuration screen.

13. Error Displays and Countermeasures When Monitoring Special Units

This table shows error messages that may be displayed when operating a special unit monitor, and what action should be taken to correct the error.


Error message	Contents of error	Action to take
PC communications error	Communication could not be established with the PC CPU.	(1) To try the operation again, touch "Retry". When the operation is retried, the error message disappears and monitoring resumes automatically, so no action is required. If monitoring is not resumed for a long period of time, however, check the following: ① Connections between the PC CPU and the A870GOT (disconnected or cut cables). ② Has an error occurred in the PC CPU?

Index

(A)		Monitoring input and output	11-24
	About the manuals (before "Common Edition")	Monitoring operation	11-23
(C)		Monitoring the A1S68AD unit	11-29
	Changing from one screen to another	Monitoring graphs	11-31
	Circuit monitor functions	Monitoring input and output	11-30
	Special unit monitor functions	Monitoring operation	11-29
	System monitor functions	Monitoring the A1S68DAI unit	11-38
	Circuit monitor functions	Monitoring graphs	11-40
	Circuit monitor screens	Monitoring input and output	11-39
	Changing the display format	Monitoring operation	11-38
	(decimal/hexadecimal)	Monitoring the A1S68DAV unit	11-38
	Displayed contents and key functions	Monitoring graphs	11-40
	Turning comment displays on and off	Monitoring input and output	11-39
	Configuration of the manuals(before	Monitoring operation	11-38
	"Common Edition")	Monitoring the A1SD61 unit	11-10
(E)		Monitoring input and output	11-11
	Error displays and countermeasures	Monitoring operation	11-10
	Circuit monitor functions	Monitoring the A1SD70 unit	11-56
	Special unit monitor functions	Monitoring an origin point return	11-58
	System monitor functions	Monitoring input and output	11-59
(F)		Monitoring positioning and	
	Future Planning	parameter lists	11-56
(M)		Monitoring the A1SD71 unit	11-73
	Making connections and monitor	Monitoring a parameter list	11-75
	functions that can be used	Monitoring an M code parameter list	11-76
	Circuit monitor functions	Monitoring an origin point return	11-74
	Special unit monitor functions	Monitoring input and output	11-77
	System monitor functions	Monitoring positioning	11-73
	Monitoring the A1S62DA unit	Monitoring positioning data	11-78
	Monitoring operation	Monitoring the A1SD75 unit	11-79
	Monitoring the A1S62RD unit	Monitoring an origin point return	11-92
	Monitoring graphs	Monitoring axis control data	11-93
	Monitoring input and output	Monitoring basic parameters	11-81
	Monitoring operation	Monitoring detailed parameters	11-83
	Monitoring the A1S63ADA unit	Monitoring error history and	
	Monitoring input and output	warning history	11-87
	Monitoring operation	Monitoring error temporary startup	
	Monitoring simple loops	history and startup history	11-88
	Monitoring the A1S64AD unit	Monitoring external I/O signals and	
	Monitoring graphs	statuses	11-96
		Monitoring input and output	11-79
		Monitoring operation	11-80
		Monitoring origin point parameters	11-85
		Monitoring output speed	11-94
		Monitoring positioning information	11-97
		Monitoring special startup, jogging, and	
		manual pulser operation	11-91

Monitoring speed/position control	11-90	Monitoring operation	11-32
Monitoring target values and machine values	11-95	Monitoring the A68RD unit	11-35
Monitoring the A1SJ71ID1 (ID2) -R4 unit	11-103	Monitoring graphs	11-37
Monitoring input and output	11-104	Monitoring input and output	11-36
Monitoring operation	11-103	Monitoring operation	11-35
Monitoring specified information	11-105	Monitoring the A84AD unit	11-106
Monitoring the A1SJ71PT32-S3 unit	11-98	Monitoring graphs	11-109
Monitoring batch refreshing	11-100	Monitoring input and output	11-108
Monitoring input and output (expansion mode)	11-102	Monitoring operation	11-106
Monitoring input and output (I/O mode)	11-98	Monitoring settings	11-107
Monitoring link statuses	11-99	Monitoring the AD61 unit	11-9
Monitoring separate refreshing	11-101	Monitoring operation	11-9
Monitoring the A616AD unit	11-41	Monitoring the AD70 unit	11-56
Monitoring graphs	11-44, 11-45	Monitoring an origin point return	11-58
Monitoring input and output	11-43	Monitoring input and output	11-59
Monitoring operation	11-41, 11-42	Monitoring positioning and parameter lists	11-56
Monitoring the A616DAI unit	11-46	Monitoring the AD70D unit	11-60
Monitoring graphs	11-48	Monitoring a parameter list	11-64
Monitoring operation	11-46	Monitoring an origin point return	11-62
Monitoring input and output	11-47	Monitoring input and output	11-66
Monitoring the A616DAV unit	11-46	Monitoring positioning	11-60
Monitoring graphs	11-48	Monitoring the AD71 unit	11-67
Monitoring input and output	11-47	Monitoring a parameter list	11-69
Monitoring operation	11-46	Monitoring an M code comment list	11-70
Monitoring the A616TD unit	11-49	Monitoring an origin point return	11-68
Monitoring graphs	11-54, 11-55	Monitoring input and output	11-71
Monitoring input and output	11-51	Monitoring positioning	11-67
Monitoring operation	11-49, 11-50	Monitoring positioning data	11-72
Monitoring temperature	11-53	Monitoring the AD72 unit	11-73
Monitoring the list of settings	11-52	Monitoring a parameter list	11-75
Monitoring the A61LS unit	11-7	Monitoring an M code comment list	11-76
Monitoring input and output	11-8	Monitoring an origin point return	11-74
Monitoring operation	11-7	Monitoring input and output	11-77
Monitoring the A62DA-S1 unit	11-12	Monitoring positioning	11-73
Monitoring graphs	11-13	Monitoring positioning data	11-78
Monitoring operation	11-12	Monitoring the AD75 unit	11-79
Monitoring the A62LS unit	11-15	Monitoring an origin point return	11-92
Monitoring input and output	11-16	Monitoring basic parameters	11-81
Monitoring operation	11-15	Monitoring control data	11-93
Monitoring the A68AD unit	11-26	Monitoring detailed parameters	11-83
Monitoring graphs	11-28	Monitoring error history and warning history	11-87
Monitoring input and output	11-27	Monitoring error temporary startup history and startup history	11-88
Monitoring operation	11-26	Monitoring external I/O signals and statuses	11-96
Monitoring the A68ADN unit	11-32	Monitoring input and output	11-79
Monitoring graphs	11-34	Monitoring operation	11-80
Monitoring input and output	11-33		

Monitoring origin point parameters	11-85	Features	1-8
Monitoring output speed	11-94	Monitor Screen Configuration and Key Functions	
Monitoring positioning information	11-97	I/O units	12-2
Monitoring special startup, jogging, and manual pulser operation	11-91	Special functions units	11-2
Monitoring speed/position control	11-90	Monitoring I/O units	12-1
Monitoring target values and machine values	11-95	Monitoring the various special function units (see next page)	
Monitoring the AJ71ID1 (ID2) -R4 unit	11-103	Operation procedures	10-1
Monitoring input and output	11-104	Precautions	3-28
Monitoring operation	11-103	Screen configuration and key functions	11-1
Monitoring specified information	11-105	Selecting items on the monitor menu	11-3
Monitoring the AJ71PT32-S3 unit	11-98	Specifications	3-25
Monitoring batch refreshing	11-100	Specifying items for the I/O unit to be monitored	12-1
Monitoring input and output (expansion mode)	11-102	Specifying items for the special functions unit to be monitored	11-3
Monitoring input and output (I/O mode)	11-98	Tests	11-4
Monitoring link statuses	11-99	System monitor functions	
Monitoring separate refreshing	11-101	Basic screens (menus)	
(N)		Batch monitoring	8-10
Names/abbreviations/terminology	1-10	BM monitoring (monitoring the buffer memory)	8-14
(O)		Changing from one screen to another	8-6
Operation procedures		Features	1-6
Circuit monitor functions	4-1	Operation procedures	7-1
Special unit monitor functions	10-1	Precautions	3-24
System monitor functions	7-1	Registered monitors	8-7
Overview	1-1	Screen configuration and key functions	8-1
(P)		Specifications	3-9
Precautions		TC monitoring	8-12
Special unit monitor functions	3-28	Tests	8-15
System monitor functions	3-24	Turning comment displays on and off (format)	8-2
Precautions regarding safety (after cover)		Changing the display format (decimal/hexadecimal)	8-2
(R)		Specifying a device (settings)	8-4
Required equipment	2-1	Specifying the station to be monitored (settings)	8-4
(S)			
Special unit monitor functions			
Changing from one screen to another	11-6		
Error displays and countermeasures	13-1		





A870/A850/A851GOT Graphic Operation Terminal

Operating Manual (Expanded Functions Manual)

Model	GOT-O-EX-E
Part Number	13J904



MITSUBISHI ELECTRIC CORPORATION

HEAD OFFICE: MITSUBISHI DENKI BLDG. MARUNOUCHI, TOKYO 100, TELEX: J24532, CABLE: MELCO, TOKYO
NAGOYA WORKS: 1-14, YADA-MINAMI 5, HIGASHI-KU, NAGOYA, JAPAN

When exported from Japan, this manual does not require application to the Ministry of International Trade and Industry for service transaction permission.