


**A852GOT Graphic Operation Terminal**

**User's Manual**



**GRAPHIC OPERATION TERMINAL**

**800**

**Series**



Mitsubishi Graphic Operation Terminal

# ● SAFETY PRECAUTIONS ●

(Read these precautions before using.)

When using Mitsubishi equipment, thoroughly read this manual and the associated manuals introduced in this manual. Also pay careful attention to safety and handle the module properly.

These precautions apply only to Mitsubishi equipment. Refer to the CPU module use's manual for a description of the PC system safety precautions.

These ● SAFETY PRECAUTIONS ● classify the safety precautions into two categories: "DANGER" and "CAUTION".



**DANGER**

Procedures which may lead to a dangerous condition and cause death or serious injury if not carried out properly.



**CAUTION**

Procedures which may lead to a dangerous condition and cause superficial to medium injury, or physical damage only, if not carried out properly.

Depending on circumstances, procedures indicated by  CAUTION may also be linked to serious results. In any case, it is important to follow the directions for usage.

Store this manual in a safe place so that you can take it out and read it whenever necessary. Always forward it to the end user.

## [DESIGN PRECAUTIONS]



**DANGER**

- A malfunction in the GOT main module may keep the output ON or OFF. Add a circuit to externally monitor the output which could lead to a serious accident.

An accident may occur by false output or malfunction.

- If a communication error (including by a disconnected cable) occurs while the monitor is running on the GOT, the communication between the GOT and the master station is interrupted, and the GOT stops running.

For a system configuration using a GOT, design the system such that the crucial switching to the system is performed by the equipment other than the GOT with the assumption that a communication error could occur in the GOT.

An accident may occur by false output or malfunction.

## [DESIGN PRECAUTIONS]



- Read Chapter 5 “Data Link Processing Time” in the Master Module User’s Manual carefully regarding the status of each station when the PC CPU operation is stopped or the data link becomes a communication error.

Also, configure an interlocking circuit in the sequence program using the communication status information (SB and SW) so that the overall system is always maintained.

An accident may occur by false output or malfunction.

- Received data from master or local data link faulty station.

① Remote input (RX) and remote output

This varies depending on the setting of the module's condition setting switch and input data (SW4) of the data link faulty station.


OFF : Clear (all off)

ON : Keeps the data right before the error occurrence.

② Remote registers (RWw and RWr)

The data right before the error is kept regardless of the SW4 setting.

- Regardless the touch-switch function is set or not, when multiple touch switches (two places or more) are pressed simultaneously as shown in the following diagram, the GOT is designed to execute a pre-defined operation of the touch switch if a touch switch function is defined at the fourth vertex of the rectangle.



When multiple touch switches are pressed simultaneously under the conditions described above, make sure that the system works safely by carefully considering the location of each touch switch function and adding an interlock circuit to the write device using a sequence program, etc.

A malfunction might cause a breakdown, accident, or damage to the machine.

## [DESIGN PRECAUTIONS]

### CAUTION

- ⊛ Do not bunch the communication cables with the main circuit or power wires, or install them close to each other. They should be installed 100 mm (3.9 inch) or more from each other. Failure to do so may result in noise that would cause malfunctioning.

## [INSTALLATION PRECAUTIONS]

### DANGER

- ⊛ Make sure to switch all phases of the external GOT's power supply off before installing or removing the GOT main module to/from the base.  
If you do not switch off the external power supply, it will cause failure or malfunction of the module.
- ⊛ Make sure to switch all phases of the external GOT's power supply off before mounting or removing the optional module to/from the GOT main module.  
If you do not switch off the external power supply, it will cause failure or malfunction of the module.
- ⊛ Make sure to switch all phases of the external GOT and PC CPU side power supply off before connecting the communication cable to the GOT main module.  
If you do not switch off the external power supply, it will cause failure or malfunction of the module.

## [INSTALLATION PRECAUTIONS]

### CAUTION

- ⊛ Use the GOT in the environment given in the general specifications of the GOT User's Manual. Using the GOT outside the range of the general specifications may result in electric shock, fire or malfunctioning, or may damage or degrade the module.
- ⊛ Tighten the installation screws for installing the GOT main module to the base within the range of specified torque.  
If the installation screws are loose, it may result in fallout, short circuits, or malfunctions.  
Tightening the installation screws too far may cause damages to the screws and/or the module, resulting in fallout, short circuits, or malfunctions.

## [WIRING PRECAUTIONS]

### DANGER

- ⊛ Make sure to switch all phases of the external GOT's power supply off before beginning wiring work. If you do not switch off the external power supply, it will cause electric shock, malfunction, or damage to the module.

## [WIRING PRECAUTIONS]

### CAUTION

- The FG and LG terminals should always be grounded using the class-3 or higher grounding designed specially for the GOT. Failure to ground these terminals may cause electric shock or malfunctions.
- When wiring the GOT, check the rated voltage and terminal layout of the wiring, and make sure the wiring is done correctly. Connecting a power supply that differs from the rated voltage or wiring it incorrectly may cause fire or failure.
- Tighten the GOT's terminal screws within the range of specified torque. If the terminal screws are loose, it may result in fallout, short circuits, or malfunctions. Tightening the terminal screws too far may cause damages to the screws and/or the module, resulting in fallout, short circuits, or malfunctions.
- When wiring the GOT, be careful that foreign objects, such as chips from the braided shield and wiring scraps, don't get caught in the GOT main module and the optional module.  
These can cause fire, failure or malfunctions.

## [PRECAUTIONS WHEN PERFORMING THE TEST OPERATION]

### DANGER

- Read the manual carefully and fully understand the operation before the test operation (ON/OFF of bit devices, modifying current value of a word device, modifying timer/counter setting, modifying the current value, or modifying the current value of a buffer memory) of the user created monitor screen.  
In addition, never modify data in a test operation to a device which performs a crucial operation to the system.  
It may cause an accident by false output or malfunction.

## [STARTING AND MAINTENANCE PRECAUTIONS]

### DANGER

- Do not touch the terminals while the power is on. Doing so may cause electric shock or malfunction.
- Do not change the switch setting while the power is on. It may cause failure or malfunction.
- Make sure to switch all phases of the external GOT's power supply off before cleaning or re-tightening terminal screws. If you do not switch off the external power supply, it will cause electric shock. If the terminal screws are loose, it may result in fallout, short circuits, or malfunctions. Tightening the terminal screws too far may cause damages to the screws and/or the module, resulting in fallout, short circuits, or malfunctions.

## [STARTING AND MAINTENANCE PRECAUTIONS]

### CAUTION

- ⦿ Never disassemble or modify the GOT main module and optional module. This may cause failure, malfunctions, injury, and/or fire.
- ⦿ Don't touch the conductive parts and electronic parts of the GOT main module and optional module. This may cause the module to malfunction or failure.
- ⦿ Because they are made of resin, don't drop or given a strong shock to the GOT main module and optional module.  
This may cause failure.

## [DISPOSAL PRECAUTIONS]

### CAUTION

- ⦿ When disposing of this product, treat it as industrial waste.

## [PRECAUTIONS WHEN REPLACING THE BACKLIGHT]

### DANGER

- ⦿ Make sure to switch all phases of the external GOT's power supply off before replacing the backlight, and first remove the GOT main module from the panel. If you do not switch off the external power supply, it will cause electric shock. If left in the panel, the GOT could fall and cause an injury.

### CAUTION

- ⦿ Perform replacement of the backlight at a place where no other machines exist in order to prevent troubles in case a fixed screw of the backlight or GOT drops.  
If such screw is dropped, it may cause damage to the machine or an accident.
- ⦿ Do not touch the GOT's circuit board or electronic parts when replacing the backlight.  
Doing so could cause failure or malfunction.
- ⦿ Tighten the backlight fixed screws within the range of specified torque. If the fixed screws are loose, it may result in fallout, short circuits, or malfunctions.  
Tightening the fixed screws too far may result in damages, short circuits, or malfunctions of the screw and/or module.
- ⦿ Do not pull the cable connector of the backlight when replacing the backlight. Doing so could cause damage or failure of the backlight.

**[PRECAUTIONS WHEN DISPOSING THE BACKLIGHT]**

 **CAUTION**

- When disposing the backlight, treat it as industrial waste.



# Introduction

Thank you for purchasing the Mitsubishi Graphic Operation Terminal.

Before using the equipment, please read this manual carefully to develop full familiarity with the functions and performance of the graphic operation terminal you have purchased, so as to ensure correct use.

Please forward a copy of this manual to the end user.

## Contents

<b>1. OVERVIEW</b>	<b>1- 1 to 1 -13</b>
1.1 Supplied Parts .....	1- 1
1.2 About A852GOT Compatible Software Packages .....	1- 2
1.3 Software Package Version Checking Method .....	1- 2
1.4 Device Specification Method When Creating the Monitor Screen .....	1- 3
1.5 Features .....	1- 4
1.6 Structure and Guide to the Use of This Manual .....	1- 7
1.7 Abbreviations and Terms Used in This Manual .....	1- 9
1.8 Precautions When Installing the ROM_BIOS/OS .....	1-10
1.9 Procedure Overview Before the Operation .....	1-11
1.10 A852GOT's Monitor Functions .....	1-12
<b>2. SYSTEM CONFIGURATION</b>	<b>2- 1 to 2 - 8</b>
2.1 System Configuration When Creating Monitor Screens .....	2- 1
2.2 System Configuration Used for Data Transfer, Debugging, and Document Creation .....	2- 2
2.2.1 System configuration .....	2- 2
2.2.2 RS-232C cables used for data transfer .....	2- 2
2.3 Necessary Equipment for A852GOT .....	2- 3
2.4 Total Configuration of CC-Link System .....	2- 4
2.5 Twisted Pair Cable Specification .....	2- 5
2.6 Applicable CPU .....	2- 6
2.7 List of Configuration Equipment .....	2- 7
<b>3. SPECIFICATION</b>	<b>3- 1 to 3 - 3</b>
3.1 General Specifications .....	3- 1
3.2 Performance Specifications .....	3- 2
<b>4. MONITOR SPECIFICATION</b>	<b>4- 1 to 4 -28</b>
4.1 Monitor Overview .....	4- 1
4.2 I/O Signals to the Master Module .....	4- 5
4.2.1 List of I/O signals .....	4- 5
4.2.2 Details of the I/O signals .....	4- 6
4.3 Remote Register Allocation .....	4- 8
4.4 Command List for the Dedicated Command Monitor Method .....	4- 9
4.5 Details of Each Command .....	4-10
4.5.1 Initial setting command .....	4-11

4.5.2	Continuous read command .....	4-13
4.5.3	Random read command .....	4-15
4.5.4	Continuous write command .....	4-17
4.5.5	Random write command .....	4-19
4.5.6	Monitor register command .....	4-21
4.5.7	Monitor request command .....	4-21
4.5.8	Always write register command .....	4-24
4.5.9	Always write request command .....	4-24
4.6	List of Accessible Range and Devices for Monitoring .....	4-28
4.7	Data Link Processing Time .....	4-28

---

## **5. SEQUENCE PROGRAM EXAMPLE** **5- 1 to 5 - 9**

---

5.1	Sequence Program Example When Monitoring Using the Normal Monitor Method.....	5- 1
5.2	Sequence Program Example When Monitoring Using Dedicated Command Monitor Method...	5- 4

---

## **6. NAMES OF PARTS AND HANDLING SYSTEM EQUIPMENTS** **6- 1 to 6 - 4**

---

6.1	Names of Parts and Their Settings .....	6- 1
6.2	Protective Sheets .....	6- 2
6.3	Printer Interface Module Connection Method .....	6- 3
6.4	Memory Card Interface Module Connection Method .....	6- 4

---

## **7. OPERATING UTILITY FUNCTIONS** **7- 1 to 7 -10**

---

7.1	List of Utility Functions .....	7- 1
7.2	Procedures to Prepare for Running the Various Functions .....	7- 2
7.3	Selecting Functions on the Utility Menu Screen .....	7- 3
	(Adjusting the Screen Brightness — Brightness Adjustment) .....	7- 3
	(Selecting the Screen Message Display — Message Display Selection) .....	7- 3
7.4	Monitoring PC CPU Device Data on the Dedicated Screen (System Monitor) .....	7- 4
7.5	Copying Monitor Data Between the Internal Memory and Memory Card (Screen Copy).....	7- 4
7.6	Entering GOT Usage Environment Settings (Setup) .....	7- 6
7.7	Self-Test of the GOT Main Module Hardware (Self-Test) .....	7- 7
7.8	Displaying Various Types of GOT Memory Information (System Information) .....	7- 8
7.9	Specifying the PC CPU Clock Data (Clock Setting) .....	7- 9
7.10	Displaying the Display Area Cleaning Screen (Screen Cleaning) .....	7- 9
7.11	Checking Data Information Stored by the Alarm History Function.....	7-10

---

## **8. OFF-LINE FUNCTIONS** **8 - 1**

---

8.1	Table of Off-line Functions .....	8- 1
-----	-----------------------------------	------

---

## **9. INSTALLATION AND WIRING** **9- 1 to 9 - 5**

---

9.1	Precautions Regarding Handling .....	9- 1
9.2	Installation Environment .....	9- 3
9.3	Installation and Wiring Method .....	9- 3

---

<b>10. MAINTENANCE AND INSPECTION</b>	<b>10- 1 to 10- 5</b>
---------------------------------------	-----------------------

---

10.1 Daily Inspection .....	10- 1
10.2 Periodic Inspection .....	10- 1
10.3 Precautions During Maintenance and Inspection .....	10- 2
10.4 Replacing the LCD Backlight .....	10- 3

---

<b>11. LIST OF ERROR CODES AND ERROR MESSAGES</b>	<b>11- 1 to 11- 4</b>
---	-----------------------

---

11.1 Interpreting the Display Contents .....	11- 1
11.2 List of Error Codes and Error Messages .....	11- 2
11.3 Error Cause Confirmation Method from the L.RUN and L.ERR LEDs on GOT .....	11- 4

---

<b>APPENDIX</b>	<b>A - 1</b>
-----------------	--------------

---

Appendix 1 External Dimensions Diagram .....	A - 1
--	-------

---

## About This Manuals

The following product manuals are available. Please use this table as a reference to request the appropriate manual as necessary.

### Related Manuals

Manual Name	Manual No. (Model Code)
AJ61BT11/A1SJ61BT11 CC-Link System Master/Local Module User's Manual	IB-66721 (13J872)
AJ61QBT11/A1SJ61QBT11 CC-Link System Master/Local Module User's Manual	IB-66722 (13J872)
<p>SW2NIW-A8GOTP Graphic Settings Software Package Operating Manual (Introductory Manual)</p> <p>This designed for the first-time user of the GOT. It describes how to create monitor screens with the A8GOTP, how to send monitor data to the A870GOT, and what the various screen displays mean.</p> <p>(Included in the same package.)</p>	IB-66679 (13J900)
<p>SW2NIW-A8GOTP Graphic Settings Software Package Operating Manual (Startup Manual)</p> <p>This describes the configuration of the A8GOTP system, precautions regarding the configuration, and the specifications of the various functions, as well as the installation procedures, startup procedures, screen configurations, and basic operation procedures.</p> <p>(Included in the same package.)</p>	IB-66680 (13J901)
<p>SW2NIW-A8GOTP Graphic Settings Software Package Operating Manual (Monitor Screen Creation Manual)</p> <p>This describes procedures for creating monitor screens, monitor functions that can be used with the A870GOT, procedures for setting the monitor functions, precautions to be observed when creating monitor screens, and precautions to be observed when appropriating conventional GOT monitor data for use with the A870GOT.</p> <p>(Included in the same package.)</p>	IB-66681 (13J902)
<p>SW2NIW-A8GOTP Graphic Settings Software Package Operating Manual (Data Transfer/Debugging/Document Creation Manual)</p> <p>This describes the following items.</p> <ol style="list-style-type: none"> <li>(1) Procedures for downloading project data to the GOT and uploading data from the GOT</li> <li>(2) Procedures for installing the operating system in the GOT</li> <li>(3) Procedures for using the A8GOTP as a virtual PC and for debugging the GOT</li> <li>(4) Procedures for outputting created monitor data as a completed document</li> </ol> <p>(Included in the same package.)</p>	IB-66682 (13J903)
<p>A870/A850/A851GOT Graphic Operation Terminal Operating Manual (Expanded Functions Manual)</p> <p>This describes the operation procedures for using system monitor functions, monitor functions for special function modules, and the dedicated monitor screens used with the circuit monitor functions.</p> <p>(Included in the same package.)</p>	IB-66683 (13J904)

<b>Manual Name</b>	<b>Manual No. (Model Code)</b>
A8GT-50PRF Printer Interface Module User's Manual (Hardware Manual) This describes the specification of the A8GT-50PRF, the name of parts, installation method, and external dimension diagram. (incouded in the A8GT-50PRF.)	IB66730 (13J880)

# 1. OVERVIEW

This manual describes the system configuration, specification, installation, etc. of the A852GOT graphic operation terminal (abbreviated as A852GOT hereafter).

A852GOT is a display device specifically designed for Control & Communication (abbreviated as CC-Link hereafter) connection to perform monitoring.

A852GOT has the following models.

Item	A852GOT-LWD A852GOT-LBD	A852GOT-LWD-M3 A852GOT-LBD-M3	A852GOT-SWD A852GOT-SBD	A852GOT-SWD-M3 A852GOT-SBD-M3
Color of front area	LWD/SWD: Ivory white		LBD/SBD: Dark gray	
Display area	Monochrome LCD (2 colors)		STN color LCD (8 colors)	
Resolution	Horizontal: 320 dots x Vertical: 240 dots			
Display size	Horizontal: 115 mm (4.5 inch) x Vertical: 86 mm (3.4 inch)			
No. of touch switch keys	A maximum of 256 points can be set out of 300 points.			
Internal memory capacity	The following capacity is definite regardless of whether the optional driver OS is installed.			
	A852GOT		A852GOT-M3	
	768 KB		2816 KB	
Connection type	Dedicated to the CC-Link connection (communication module not necessary)			
Extension function	System monitor cannot be used.			
Corresponding software package	SW2NIW-GOT 800 PSET (SW2NIW-A8GOTP version J or later/ SW2NIW A8SYSP version J or later)			

## 1.1 Supplied Parts

Make sure that the following devices are included in the shipment box.

A852GOT main module	1
This manual	1 copy

## 1.2 About A852GOT Compatible Software Packages

When creating the A852GOT screen or installing the OS, always use the following software versions or later.

Graphic software : SW2NIW-A8GOTP software version J or later  
 OS program : SW2NIW-A8SYSP software version J or later  
 Special module monitor data : Cannot be used.


**Point**

When installing the OS, install the A85\*GOT's basic OS.  
 Install the CC-Link connection driver for the communication driver.  
 The A852GOT cannot use the extension functions (system monitor, circuit monitor, and special module monitor).  
 When creating the screen data, set the GOT type to A85\*.

## 1.3 Software Package Version Checking Method

**1** Checking the version of SW2NIW-A8GOTP and SW2NIW-A8SYSP

The version checking method for the software package is described below.  
 The version can be checked by looking at the label on the product floppy disk.




Indicates the software version

**2** Checking the version after installing the OS to the A852GOT

The version checking method of the SW2NIW-A8SYSP version J or later after the OS is installed to the GOT is shown below.

When the SW2NIW-A8SYSP version J or later is installed to GOT, the version is displayed by the GOT memory information function as shown below:



If the SW2NIW-A8SYSP OS version E or later is installed, the version is displayed as 5.0\*.

ROM\_BIOS is displayed as 5.0\* (Q).  
 (Q is for version J.)

## 1.4 Device Specification Method When Creating the Monitor Screen

The A852GOT monitor can access only remote devices with the A852GOT allocated to the master station, and GOT internal devices. (Refer to Section 4.6.)

Other remote devices allocated to the master station cannot be monitored.

When creating the monitor screen, specify with the following device names.

### 1 NW number and station number setting

Always set "0" for NW number and "local" for the station number.

### 2 Device name and device number setting

Set the device name as shown below.


Set the address allocated by the station number setting for the device number of the remote register.

Monitored device		Device name set in the graphic software	Setting device range	
Bit	Remote input	RX	X	X0 to X7FF
	Remote output	RY	Y	X0 to Y7FF
	Bit specification in the remote register (write area)	RWw	Ww	Ww0 to WwFF
	Bit specification in the remote register (read area)	RWr	Wr	Wr0 to WrFF
	GOT internal bit device	GB	GB	GB0 to GB1023
	Bit specification in the GOT internal word device	GD	GD	GB0 to GB1023
Word	Remote register (write area)	RWw	Ww	Ww0 to WwFF
	Remote register (read area)	RWr	Wr	Wr0 to WrFF
	GOT internal word device	GD	GD	GB0 to GB1023

## 1.5 Features

- 1** The connection can be made to the CC-Link system as a CC-Link system remote device station. (Selectable between occupied points 2 stations and 4 stations.)

Since the A852GOT has the built-in communication module for CC-Link connection, the communication module is not necessary.



- The maximum total extension distance of the system is as shown below (varies depending on the transmission speed setting):

156 kbps : 1200 m (3937.2 ft.)  
 625 kbps : 600 m (1968.6 ft.)  
 2.5 Mbps : 200 m (656.2 ft.)  
 5 Mbps : 150 m (492.15 ft.)  
 10 Mbps : 100 m (328.1 ft.)

- A852GOT occupied points can be selected between 2 stations and 4 stations.


	2 stations	4 stations
Remote input/output	48 points	112 points
Remote register	8 points	16 points

The monitor points of the remote register can be extended by monitoring by means of the GOT internal device.

- 2** Read/write can be performed between remote register ↔ GOT internal device using the dedicated commands. By expanding the remote register data to each GOT internal device, several information such as operation status, production amount, operation command, etc. can be monitored in one screen.


(A sequence program for the command execution is required.)

**When writing data to the GOT internal device by command execution**



- ① Using the sequence program, store the write command data and write data to the allocated A852GOT's remote register (RWw).
- ② The command data and write data are stored in the A852GOT's remote register by link scan.
- ③ Write the write data to the specified GOT internal device.
- ④ Monitor the GOT using the GOT internal device.

**When reading data from the GOT internal device by command execution**



- ① Using the sequence program, store the read command data to the allocated A852GOT remote register (RWw).
- ② The command data is stored in the A852GOT's remote register by link scan.
- ③ By the read command, read the data in the specified GOT internal device to the remote register (RWr).
- ④ Read the data to the A852GOT's remote register (RWr) by link scan.
- ⑤ Using the sequence program, read the data in the remote register (RWr) to the PC CPU.




## 1.6 Structure and Guide to the Use of This Manual

When the GOT is purchased, it comes with a user's manual. The graphics software also comes with five operating manuals. Manuals are categorized according to the purpose for which they are used. Please read the manual that corresponds to your particular objective in order to become familiar with the operations and functions of the software.



### SW2NIW-A8GOTP Operating Manual A870GOT Operating Manual

- Install the graphics software in the computer.
- Start up the graphics software.
- Learn fundamental information and basic operations for the graphics software.

SW2NIW-A8GOTP Operating




Startup manual




- Create simple graphics, monitor using the GOT, and learn the flow of a series of operations.

SW2NIW-A8GOTP Operating





Introductory manual

SW2NIW-A8GOTP  
Operating




Monitor screen  
creation manual

- Actually create screens for monitoring using the GOT.
- Drawing graphics
- Sprite settings
- Edit the data which has been created.




SW2NIW-A8GOTP  
Operating



Data transfer  
Debugging  
Document creation  
manual

- Install the OS program and communications driver in the GOT.
- Download created graphics to the GOT.
- Debugging graphics between the personal computer and GOT.
- Create data documents.



## 1.7 Abbreviations and Terms Used in This Manual

---

- (1) GOT.....This is the abbreviation for the A852GOT and A852GOT-M3 Graphic Operation Terminal. When the model name needs to be made explicit, however, "A852GOT/A852GOT-M3" may be used.
- (2) CC-Link ..... This is the abbreviation for the CC-Link system.
- (3) Master station ..... Station which controls remote stations and local stations.  
One station is required for one system.
- (4) Local station ..... Station with CPU which can communicate with master station and other local stations.
- (5) Remote I/O station ..... Remote station which deals with bit information only.  
(AJ65BTB□-□□□, AJ65BTC□-□□)
- (6) Remote device station ..... Remote station which deals with bit information and word information.  
(AJ65BT-64AD, AJ65BT-64DAV, AJ65BT-64DAI)
- (7) Remote station ..... General name for remote I/O station and remote device station. Controlled by a master station.
- (8) Intelligent device station ..... Station that can perform transient transmission. (Including local station) (AJ65BT-R2)
- (9) Master/local module ..... General name for AJ61QBT11 and A1SJ61QBT11.
- (10) Master module ..... General name for AJ61QBT11 and A1SJ61QBT11 when they are used as master station.
- (11) Local module ..... General name for AJ61QBT11 and A1SJ61QBT11 when they are used as local station.
- (12) Remote module ..... General name for AJ65BTB□-□□, AJ65BTC□-□□, AJ65BT-64AD, AJ65BT-64DAV and AJ65BT-64DAI.
- (13) RX..... Remote input
- (14) RY ..... Remote output
- (15) RWw ..... Remote register (write area)
- (16) RWr ..... Remote register (read area)

## 1.8 Precautions When Installing the ROM\_BIOS/OS

Notes about executing the ROM\_BIOS/OS installation are described in the following.

- (1) Before installing the ROM\_BIOS/OS, confirm that the connectors of the communication cable are securely connected to the GOT and the personal computer.

If the ROM\_BIOS/OS installation is executed when the connectors are not connected securely, the GOT might stop operating after installation.

- (2) Note that the ROM\_BIOS/OS installation cannot be interrupted once it is started.


The GOT might stop running if the power of the GOT or personal computer is turned off, or the communication cable is disconnected in order to interrupt in the middle of the installation.

- (3) Do not turn off the power supply of the GOT or personal computer, and do not disconnect the communication cable during the ROM\_BIOS/OS installation.

The GOT might stop running if the power of the GOT or personal computer is turned off, or the communication cable is disconnected during the ROM\_BIOS/OS installation.

- (4) If one of the operations described above was done by mistake, or if the GOT does not work after the ROM\_BIOS/OS installation, follow the steps shown in the following to reinstall the ROM\_BIOS/OS.

- ① Turn off the power supply of the GOT.
- ② If a communication module is installed, disconnect the communication module.
- ③ Turn on the power supply of the GOT while pressing the two locations on the GOT display simultaneously as shown in ■ of the following diagram:




- ④ A message, "Reinstall ROM\_BIOS/OS", will appear on the GOT display area.
- ⑤ Reinstall the ROM\_BIOS/OS. Refer to Section 3.1 of "SW2NIW-A8GOTP Graphic Settings Software Package Operating Manual" (Data Transfer/Debugging/Document Creation Manual).

## 1.9 Procedure Overview Before the Operation

Procedure overview before the operation is shown below.

Refer to the CC-Link Master Module User's Manual for the operation of the entire CC-Link system.



## 1.10 A852GOT's Monitor Functions

The monitor functions that can be performed with the A852GOT is listed below.

Refer to the SW2NIW-A8GOTP Operating Manual (Monitor Screen Creation Manual) for details of each function.

Refer to Section 4.6 regarding the monitor access range.

### 1 Utility functions

Functions	Usability
	(○: Usable △: Usable with restrictions ×: Unusable )
System monitor	×
Screen copy	○
Setup	○
Self-test	○
Memory information	○
Clock setting	×
Screen cleaning	○
File	△ (The time when the data was stored cannot be displayed.)

### 2 Sprite functions


Functions		Usability
		(○: Usable △: Usable with restrictions ×: Unusable )
Numeric value display		○
Data list display		○
ASCII display		○
Clock display		×
Comment display	Bit	○
	word	
Alarm list display	System alarm	△ (The time when it occurred cannot be displayed.)
	User alarm	
Parts	Bit	○
	word	
Parts movement display		○
Lamp display	Bit	○
	word	○
Panel meter display		○
Trend graph display		○
Broken line graph display		○
Bar graph display		○
Level display		○
Touch switch	Bit	○
	Word	
	Base screen switching	
	Window screen switching	
	Extension	
	Key code setting	

Functions	Usability (○: Usable △: Usable with restrictions ×: Unusable )
Numeric value input	○
ASCII input	○
System information	○
Hard copy	○
Report	○
Status monitoring	○
Alarm history	△ (The time when it occurred cannot be displayed.)

## 2. SYSTEM CONFIGURATION

### 2.1 System Configuration When Creating Monitor Screens

This shows the system configuration when using the graphics software to create monitor screens.




- Main module : Personal computer which runs Microsoft Windows Ver. 3.1/95
- Main memory : At least 4 MB is required (8 MB or more is strongly recommended)
- Hard disk : At least 10 MB of space must be available when the program is installed
- CRT : Must be able to connect to main module and be used with Microsoft Windows
- Mouse : Any mouse which can be used with a Windows computer

- Windows 3.1, Windows 95 is a trademark of Microsoft Corporation.

## 2.2 System Configuration Used for Data Transfer, Debugging, and Document Creation


### 2.2.1 System configuration

This shows the system configuration used for transfer data, debugging, and creating documents.



### 2.2.2 RS-232C cables used for data transfer


The cable shown in the internal connections drawing below, or a cable with the model name noted below, is required.



Manufacture	Model Name
Mitsubishi Electric	AC30R2-9P
	F2-232CAB-1 (introductory product)
	AC30R2-9SS (conversion connector is not required)

### 2.3 Necessary Equipment for A852GOT

Necessary equipment for A852GOT are shown below.



## 2.4 Total Configuration of CC-Link System

A total of 64 remote I/O stations, remote device stations (A852GOT included), or local stations can be connected for one master station.


However, the following conditions must be satisfied:

$$(1) \{(1 \times a) + (2 \times b) + (3 \times c) + (4 \times d)\} \leq 64$$

a : Number of modules occupied 1 station      c : Number of modules occupied 3 stations  
 b : Number of modules occupied 2 stations    d : Number of modules occupied 4 stations

$$(2) \{(16 \times A) + (54 \times B) + (88 \times C) + (88 \times D)\} \leq 2304$$


A : Number of remote I/O stations       $\leq 64$   
 B : Number of remote device stations    $\leq 42$   
 C : Number of intelligent device stations  $\leq 26$   
 D : Number of local stations             $\leq 26$



## 2.5 Twisted Pair Cable Specification

The twisted pair cable that can be used with CC-Link the recommended cables are described below: The CC-Link features cannot be guaranteed when cables other than the recommended ones shown below are used.

The model and specification of the recommended cable is shown below:

Item	Specification
Model	FANC-CB 0.5 mm <sup>2</sup> × 3
Contact	Mitsubishi Service Center
Cable type	Twisted pair shield cable
Conductor section area	0.5 mm <sup>2</sup>
Conductor resistor (20°C)	More than 37.8Ω
Insulation resistor	More than 10000Ω-km
Voltage resistance	500VDC, 1 minute
Static capacity (1kHz)	More than 60nF/km
Special impedance (1MHz)	100 ± 15Ω
Sliced diagram	
External dimensions	7 mm (0.28 inch)
Approximate weight	65 kg/km

**Remark**

Consult nearest Mitsubishi representative with connector plug.

## 2.6 Applicable CPU

---

(a) When master module is AJ61BT11

- A0J2CPU      · A0J2HCPU      · A1CPU      · A2CPU (S1)      · A3CPU
- A1NCPU      · A2NCPU (S1)      · A3NCPU      · A3MCPU      · A3HCPU
- A2ACPU (S1)      · A3ACPU      · A2UCPU (S1)      · A3UCPU      · A4UCPU

(b) When master module is AJ61QBT11

- Q2ACPU (S1)      · Q3ACPU      · Q4ACPU
- Q2ASCPU (S1)      · Q2ASHCPU (S1)      · Q4ARCPU

(c) When master module is A1SJ61BT11

- A1SCPU (C24-R2)      · A1SJCPU      · A2SCPU      · A2USCPU (S1)
- A2USHCPU-S1

(c) When master module is A1SJ61QBT11

- Q2ASCPU (S1)      · Q2ASHCPU (S1)

## 2.7 List of Configuration Equipment

Necessary configuration equipment for GOT are shown below.

Refer to CC-Link Master Module User's Manual about the total configuration of CC-Link system.

Component	Model	Remarks	
GOT main module (Internal CC-Link communication module)	A852GOT-LWD	Monochrome LCD, color of front area ivory white (with 24VDC power supply), internal memory 768 KB	
	A852GOT-LBD	Monochrome LCD, color of front area dark gray (with 24VDC power supply), internal memory 768 KB	
	A852GOT-SWD	STN color LCD, color of front area ivory white (with 24VDC power supply), internal memory 768 KB	
	A852GOT-SBD	STN color LCD, color of front area dark gray (with 24VDC power supply), internal memory 768 KB	
	A852GOT-LWD-M3	Monochrome LCD, color of front area ivory white (with 24VDC power supply), internal memory 2816 KB	
	A852GOT-LBD-M3	Monochrome LCD, color of front area dark gray (with 24VDC power supply), internal memory 2816 KB	
	A852GOT-SWD-M3	STN color LCD, color of front area ivory white (with 24VDC power supply), internal memory 2816 KB	
	A852GOT-SBD-M3	STN color LCD, color of front area dark gray (with 24VDC power supply), internal memory 2816 KB	
Backlights	A8GT-50LT	For replacing the backlight	
Protective sheet	A8GT-50PSC	Transparent protective sheet	
	A8GT-50PSN	Anti-reflection protective sheet	
Printer interface module	A8GT-50PRF	For connecting printer	
Memory card interface module	A1SD59-MIF	For loading memory card	
Optional module installation bracket	A8GT-STE	For installing printer interface module GOT main module	
Printer connection cable	AC30PIO-20P	For connecting printer and printer interface module: 3 m (10 feet)	
	AC300PIO-20P	For connecting printer and printer interface module: 30 m (98 feet)	
Memory card cable	A85GT-C05H	For connecting GOT and memory card interface module: 2 m (6.6 feet)	
SRAM memory card conforming to JEIDA Ver. 4.0 standard	MF3257-L5DAT01	SRAM made by Mitsubishi; memory capacity 256 KB	For backup of project data *1 Recommended product
	MF3513-L5DAT01	SRAM made by Mitsubishi; memory capacity 512 KB	
	MF31M1-L5DAT01	SRAM made by Mitsubishi; memory capacity 1 MB	
	MF32M1-L6DAT01	SRAM made by Mitsubishi; memory capacity 2 MB	
	MF3257-J1DAT01	SRAM made by Mitsubishi; memory capacity 256 KB; with backup battery	
	MF3513-J1DAT01	SRAM made by Mitsubishi; memory capacity 512 KB; with backup battery	
	MF31M1-J1DAT01	SRAM made by Mitsubishi; memory capacity 1 MB; with backup battery	For backup of project data
	MF32M1-J1DAT01	SRAM made by Mitsubishi; memory capacity 2 MB; with backup battery	
	Q1MEN-64S	SRAM for QnACPU; memory capacity 64 KB	
	Q1MEN-128S	SRAM for QnACPU; memory capacity 128 KB	
	Q1MEN-256S	SRAM for QnACPU; memory capacity 256 KB	
	Q1MEN-512S	SRAM for QnACPU; memory capacity 512 KB	
	Q1MEN-1MS	SRAM for QnACPU; memory capacity 1 MB	For backup of project data *2 Can be connected
	Q1MEN-2MS	SRAM for QnACPU; memory capacity 2 MB	
		RJB-2000	Product of Melco Co., Ltd. (Contact: 052-619-1827) Memory capacity 2MB SRAM
	Twisted pair shield cable	—	CC-Link connection cable (Refer to Section 2.5)
Corresponding software package	SW2NIW-GOT800PSET	SW2NIW-A8GOTP version J or later SW2NIW-A8SYSP version J or later	

\*1. Recommended product:

This product is guaranteed to have specifications (standards) that can be connected to our modules.  
These products should be used in conformance with the specifications (standards) of that product.

\*2. Can be connected:

Products with this indication have specifications that allow connection to our modules. These products should be used in conformance with the specifications (standards) of that product.

## 3. SPECIFICATIONS

### 3.1 General Specifications

Item	Specifications				
Operating ambient temperature	Display area		Other than display area		
	0 to 40°C		0 to 55°C		
Storage ambient temperature	-20 to 60°C				
Operating ambient humidity	10 to 90% RH, with no condensation				
Storage ambient humidity	10 to 90% RH, with no condensation				
Vibration resistance	Conforming to JIS B 3501, IEC 1131-2	Under intermittent vibration			10 times each in X, Y, Z directions (for 80 min.)
		Frequency	Acceleration	Amplitude	
		10 to 57Hz	—	0.075 mm (0.003 inch)	
		57 to 150Hz	9.8 m/S <sup>2</sup> {1G}	—	
		Under continuous vibration			
		Frequency	Acceleration	Amplitude	
		10 to 57Hz	—	0.0035 mm (0.001 inch)	
57 to 150Hz	4.9 m/S <sup>2</sup> {0.5G}	—			
Shock resistance	Conforming to JIS B 3501, IEC 1131-2 (147 m/s <sup>2</sup> {15 G}), 3 times in each of 3 directions)				
Noise durability	Noise voltage: 1500 Vp-p; noise width: 1 μs Noise frequency: based on noise simulation of 25 to 60 Hz				
Withstand voltage	Batch resistance between external DC terminals ..... 500 VAC for 1 minute between grounding terminals				
Insulation resistance	Batch resistance between external DC terminals ..... 500 VDC at 10 MΩ min. using insulation resistance meter				
Operating ambience	No corrosive gases				
Operating elevation	2000 m (6562 feet) max.				
Installation location	Control panel				
Over-voltage category *1	II max.				
Pollution level *2	2 max.				

\*1. This indicates the section of the power supply to which the equipment is assumed to be connected between the public electrical power distribution network and the machinery within the premises. Category II applies to equipment for which electrical power is supplied from fixed facilities. The surge voltage withstand level for up to the rated voltage of 300 V is 2,500 V.

\*2. This index indicates the degree to which conductive material is generated in terms of the environment in which the equipment is used. Pollution level 2 is when only non-conductive pollution occurs. A temporary conductivity caused by condensation must be expected occasionally.

### 3.2 Performance Specifications

Item		A852GOT-L□□D	A852GOT-L□□D-M3	A852GOT-S□□D	A852GOT-S□□D-M3
Color of front area		LWD/SWD: Ivory white		LBD/SBD: Dark gray	
Display area	Type	Monochrome LCD		STN color LCD	
	Resolution	Horizontal: 320 dots x Vertical: 240 dots			
	Display size	Horizontal: 115 mm (4.5 inch) x Vertical: 86 mm (3.4 inch)			
	Display color	Single color (white, black)		8 colors	
Backlights		Chilled cathode ray tube backlight; Backlight OFF time can be set; Backlights can be replaced			
Touch panel	No. of touch keys	300 (15 rows x 40 columns)			
	Key size	16 dots x 16 dots min. (per key)			
	Repeat function	None			
Memory *1	Type	Internal memory (flash ROM)			
	Application	For storing monitor screen data/for storing optional driver OS			
	Capacity	The following capacity is definite regardless of whether the optional driver OS is installed.			
		A852GOT 768 KB		A852GOT-M3 2816 KB	
RS-232C interface		For connecting personal computer; 1 channel			
Interface for connecting optional module		For connecting memory card interface module/ printer interface module; 1 channel			
Buzzer		Single sound (length of sound can be adjusted)			
Lifetime *2	Display area	50,000 hours (when ambient temperature during use is 25° C)			
	Backlights	10,000 hours (50% of display brightness)			
	Touch keys	1 million times min. (at operational force of 100 g (0.2 lb) or less)			
	Internal memory	No. of writings: 100,000			
Number of stations occupied		Can be selected in 2/4 stations 2 stations: (RX/Ry 64 points each, RW write area/ read area 8 points each) 4 stations: (RX/Ry 128 points each, RW write area/ read area 16 points each)			
CC-Link station type		Remote device station			
Transmission speed/ max. transmission distance		156 kbps: 1200 m (3937.2 ft.)/625 kbps max.: 600 m (1968.6 ft)/2.5Mbps max.: 200 m (656.2 ft.)/ 5Mbpt max.: 150 m (492.2 ft.)/10Mbps max.:100 m (3.281 ft.)			
No. of maximum connection		42 stations max. (Refer to Section 2.4)			
Connection cable		Twisted pair shield cable (Refer to Section 2.5)			
Power supply voltage		24VDC (+30%, -35%)			
Allowable falter time		10 ms			
Noise durability		Using the noise simulator with noise voltage at 500Vp-p, noise width at 1μs, and noise frequency at 25 to 60Hz.			
Applicable wire size		0.75 to 2.00 mm <sup>2</sup>			
Applicable solderess terminal		RAV 1.25 - 3.5/ RAV 2 - 3.5			
Current consumption (24V)		0.6 A (When printer interface is not used) 0.7 A (When printer interface is used)			
Connection type		Dedicated to the CC-Link connection			
Environmental protection construction		IP65 or equivalent (front area)			
External dimentions		192mm (7.6 inch) (W) × 135mm (5.3 inch) (H) × 62mm (2.4 inch) (D)			
Panel cutout dimensions		184mm (7.2 inch) (W) × 124mm (4.9 inch) (H)			
Weight		850 g (1.7 lb)			
Corresponding software package		SW2NIW-GOT 800PSET (SW2NIW A8GOTP version J or later) / SW2NI-A8SYSP version J or later			

- \*1. The internal memory is a ROM which enables overwriting of new data without deleting previously written data.  
(No data backup power supply is required.)
- \*2. When parts need to be replaced, please consult your nearest dealer or branch office.

**Remark**

With the GOT, if a momentary power failure occurs, the screen display disappears. If the power is restored within 20 ms, however, monitor functions and other functions resume normal operation.

# 4. MONITOR SPECIFICATION

## 4.1 Monitor Overview

There are the following two types of monitoring methods for the A852GOT.

**1** Normal monitor method

A method to monitor by specifying the remote input/output allocated to the A852GOT and the remote register.

**2** Dedicated command monitor method


The remote register area is used as the GOT internal device transfer command area, and the monitoring is performed by specifying the GOT internal device.

By expanding the data to the GOT internal word device (GD0 to 1023) using dedicated commands, several information such as the operation status, production amount, and operation command can be monitored in one screen.


The monitor overview is shown below:

**1** Normal monitor method

In the monitor overview, the remote output and remote register (write area) are described separately from the remote input and remote register (read area), but all of the information can be displayed on one screen for monitoring.




Monitor (write from GOT) for remote output and remote register (read area)




**2** Dedicated command monitor method

The remote register (write area) data is stored in the GOT internal device using dedicated commands and monitoring is performed.



When the GOT internal device read command is executed



## 4.2 I/O Signals to the Master Module

### 4.2.1 List of I/O signals

The I/O signal allocation is shown below.

The I/O signals varies depending on the set number of occupied stations (2 stations or 4 stations). The "n" in the table indicates the address allocated to the master module by the station number setting.

1

When monitoring using the dedicated command monitor method

Signal direction: A852GOT → Master module		Signal name	Signal name: Master module → A852GOT		Signal name
Device No.			Device No.		
Occupied points			Occupied points		
2 stations	4 stations	User area	2 stations	4 stations	User area
RXn0 to RX (n+2) F	RXn0 to RX (n+6) F		GOT complete flag	RYn0 to RY (n+2) F	
RX (n+3) 0	RX (n+7) 0	RY (n+3) 0		RY (n+7) 0	
RX (n+3) 1 to RX (n+3) 8	RX (n+7) 1 to RX (n+7) 8	Unusable	RY (n+3) 1	RY (n+7) 1	GOT monitor request flag
			RY (n+3) 2	RY (n+7) 2	GOT always write request flag
			RY (n+3) 3 to RY (n+3) 8	RY (n+7) 3 to RY (n+7) 8	Unusable
RX (n+3) 9	RX (n+7) 9	Initial data setting complete flag	RY (n+3) 9	RY (n+7) 9	Initial data setting request flag
RX (n+3) A	RX (n+7) A	Error status flag	RY (n+3) A	RY (n+7) A	Error reset request flag
RX (n+3) B	RX (n+7) B	Remote ready	RY (n+3) B to RY (n+3) F	RY (n+7) B to RY (n+7) F	Unusable
RX (n+3) C to RX (n+3) F	RX (n+7) C to RX (n+7) F	Unusable			

2

When monitoring using the normal monitor method

Signal direction: A852GOT → Master module		Signal name	Signal name: Master module → A852GOT		Signal name
Device No.			Device No.		
Occupied points			Occupied points		
2 stations	4 stations	User area	2 stations	4 stations	User area
RXn0 to RX (n+2) F	RXn0 to RX (n+6) F		Unusable	RYn0 to RY (n+2) F	
RX (n+3) 0 to RX (n+3) A	RX (n+7) 0 to RX (n+7) A	RY (n+3) 0 to RY (n+3) F		RY (n+7) 0 to RY (n+7) F	
RX (n+3) B	RX (n+7) B	Remote ready	RY (n+3) 0 to RY (n+3) F	RY (n+7) 0 to RY (n+7) F	Unusable
RX (n+3) B to RX (n+3) F	RX (n+7) B to RX (n+7) F	Unusable			

#### Point

If the device that cannot be used is turned on/off with the sequence program, the GOT functions are not guaranteed.

### 4.2.2 Details of the I/O signals


The function of each I/O signal is described below:

#### 1 GOT complete flag and GOT request flag

By turning on the GOT request flag, each command which uses the GOT internal device to monitor (excluding the initial setting command, monitor request command, and always write request command) is executed.

After each command processing is complete, the GOT complete flag turns on.

When the GOT request flag is turned off, the GOT complete flag turns off as well.




#### 2 Initial data setting complete flag and initial data setting request flag

By turning on the initial data setting request flag, the initial setting command to monitor using the GOT internal device, is executed.

When the initial setting command processing is complete, the initial data setting complete flag turns on.


When the initial data setting request flag is turned off, the initial data setting complete flag turns off as well.



#### 3 GOT monitor request flag

When the GOT monitor request flag is on, the data in the GOT internal device registered for monitoring is always read to the remote register.


Refer to 1 when executing the monitor registration command.



**4** GOT always write request flag

When the GOT always write request flag is on, the remote device data is always written to the GOT internal device which has been registered for write.


Refer to **1** when executing the always write register command.



**5** Error status flag and error reset request flag

If an error occurs during execution of a command when communicating with the GOT internal device, the error status flag turns on.

The error status flag is turned off by turning on the error reset request flag,.



**6** Remote ready flag

Turns on during the A852GOT startup.

Turns off during off-line operations (OS installation and screen data download) and initial processing execution.

### 4.3 Remote Register Allocation

The remote register allocation for A852GOT is described below.

The usage of the remote registers is different between the normal monitor method and dedicated command monitor method.

#### 1 When the dedicated command monitor method

The entire area is used for the GOT internal device communication commands.

Refer to Section 4.5 regarding each command for the GOT internal device communication.

The "m" and "n" in the table indicates the address allocated to the master module by the station number setting.

Communication direction	Address		Contents	Default value
	Occupied points			
	2 stations	4 stations		
Master station ↓ Remote device station	RWwm to RWwm+7	RWwm to RWwm+F	Command execution area to be monitored by using GOT internal device	0
Remote device station ↓ Master station	RWrn to RWrn+7	RWrn to RWrn+F	Command response area to be monitored by using GOT internal device	0

#### 2 When the normal monitor method

The entire area is used for user region.

The "m" and "n" in the table indicates the address allocated to the master module by the station number setting.

Communication direction	Address		Contents	Default value
	Occupied points			
	2 stations	4 stations		
Master station ↓ Remote device station	RWwm to RWwm+7	RWwm to RWwm+F	User write area	0
Remote device station ↓ Master station	RWrn to RWrn+7	RWrn to RWrn+F	User read area	0

## 4.4 Command List for the Dedicated Command Monitor Method

The command list for the dedicated command monitor is shown below:

Command name	Contents	Reference Section
Initial setting	Initial setting command when monitoring with dedicated command monitor method (monitoring is performed using the GOT internal device).	Section 4.5.1
Continuous read	Command to read the specified number of points of data from the specified head GOT internal device to the remote register. Maximum read points When the number of stations is set to 4 stations: 14 points When the number of stations is set to 2 stations: 6 points	Section 4.5.2
Random read	Command to read data from several different GOT internal devices to the remote register. Maximum read points When the number of stations is set to 4 stations: 14 points When the number of stations is set to 2 stations: 6 points	Section 4.5.3
Continuous write	Command to write specified number of points of data from the remote register to the specified head GOT internal device. Maximum write points When the number of stations is set to 4 stations: 14 points When the number of stations is set to 2 stations: 6 points	Section 4.5.4
Random write	Command to write remote register data to several different GOT internal devices. Maximum write points When the number of stations is set to 4 stations: 7 points When the number of stations is set to 2 stations: 3 points	Section 4.5.5
Monitor register	Command to register the GOT internal device number that performs the always remote register read command. Maximum registration points When the number of stations is set to 4 stations: 14 points When the number of stations is set to 2 stations: 6 points	Section 4.5.6
Monitor request	Command to always read the GOT internal device data stored by executing the monitor register command to the remote register.	Section 4.5.7
Always write register	Command to always register the GOT internal device number of the GOT internal device that performs the always remote register data write command. Maximum registration points When the number of stations is set to 4 stations: 14 points When the number of stations is set to 2 stations: 6 points	Section 4.5.8
Always write request	Command to always write remote register data to the GOT internal device registered by executing the always write register command.	Section 4.5.9


### 4.5 Details of Each Command

The execution method for each command is described.


The following system example is used to describe the sequence program in this section.

Refer to the CC-Link Master Module User's Manual regarding the sequence program for the entire CC-Link system.

#### System configuration



#### Relationship among the PC CPU, master station buffer memory, and remote device stations



### 4.5.1 Initial setting command


#### 1 Initial setting command

This is the initial setting command for monitoring with the GOT internal device. Create a sequence program for initial setting command to be processed before the commands described in Section 4.5.2 and after are executed.

#### 2 Command format

Communication direction	Address	Write data
Master station ↓ A852GOT	RWwm (H)	1: Initial setting
	RWwm (L)	1: Monitoring by the dedicated command monitor method 2: Switch to the normal monitor method
	RWwm + 1 to RWwm + F	_____
A852GOT ↓ Master station	RWrn to RWrn + F	_____

#### 3 Communication overview




- ① Store the initial setting command data in the master station's remote register (RWw).
- ② Turn on the initial data setting request flag and store the command data in the GOT remote register (RWw).

(Command execution)

The initial data setting complete flag turns on when the command processing is complete.

By executing this command, the A852GOT will be in the monitor status with the dedicated command monitor method.

**4** Sequence program example



### 4.5.2 Continuous read command

#### 1 Continuous read command


This is a command to read data for a specified number of points from the specified head GOT internal device to the remote register.

#### 2 Command format

Communication direction	Address	Contents
Master station ↓ A852GOT	RWwm (H)	2: Continuous read setting
	RWwm (L)	When the occupied points are 2 stations 1 to 6 : GOT internal device point to be read When the occupied points are 4 stations 1 to 14 : GOT internal device point to be read
	RWwm + 1	0 to 1023 : Head GOT internal device numbers to be read
	RWwm + 2 to RWwm + F	_____
A852GOT ↓ Master station	RWrn to RWrn + D	Stores the data to be read from the GOT internal device
	RWrn + E, RWrn + F	_____

#### 3 Communication overview

When reading three points from the GOT internal device GD100 to the remote register (RWr)




- ① Store the continuous read command data in the master station's remote register (RWw).
- ② Turn on the GOT request flag, and read the data in GD100 to 102 are read to the remote register (RWr) by storing the command data in the GOT remote register (RWw).

(Command execution)

The GOT complete flag turns on when the command processing is complete.

- ③ By link scan, the read data is stored in the master station's remote register (RWr).
- ④ Read the data to the PC CPU using the FROM instruction, etc.

4 Sequence program example



### 4.5.3 Random read command

#### 1 Random read command


This is a command to read data from several different GOT internal devices to the remote register.

#### 2 Command format

Communication direction	Address	Contents
Master station ↓ A852GOT	RWwm (H)	3: Random read setting
	RWwm (L)	When the occupied points are 2 stations 1 to 6 : GOT internal device point to be read When the occupied points are 4 stations 1 to 14 : GOT internal device point to be read
	RWwm + 1 to RWwm + F	0 to 1023 : GOT internal device numbers to be read (Storage for the setting mentioned above)
A852GOT ↓ Master station	RWrn to RWrn + D	Stores the data to be read from the GOT internal device (Storage for the setting mentioned above)
	RWrn + E, RWrn + F	

#### 3 Communication overview

When reading data from the GOT internal device GD100, 200, and 300 to the remote register




- ① Store the random read command data in the master station's remote register (RWw).
- ② Turn on the GOT request flag, and read the data in GD100, 200, and 300 are read to the remote register (RWr) by storing the command data in the GOT remote register (RWw).

(Command execution)

The GOT complete flag turns on when the command processing is complete.

- ③ By link scan, the read data is stored in the master station's remote register (RWr).
- ④ Read the data to the PC CPU using the FROM instruction, etc.

4 Sequence program example



### 4.5.4 Continuous write command

#### 1 Continuous write command


This is a command to write data from a specified number of points of remote registers to the specified head GOT internal device.

#### 2 Command format

Communication direction	Address	Contents
Master station ↓ A852GOT	RWwm (H)	4: Continuous write setting
	RWwm (L)	When the occupied points are 2 stations 1 to 6 : Points to be written to the GOT internal device  When the occupied points are 4 stations 1 to 14 : Points to be written to the GOT internal device
	RWwm + 1	0 to 1023 : Head GOT internal device numbers to be written
	RWwm + 2 to RWwm + F	Stores the data to be written to the GOT internal device
A852GOT ↓ Master station	RWrn to RWrn + F	_____

#### 3 Communication overview

When writing remote register data to the GOT internal device GD100, 101, and 102 (3 points)




- ① Store the continuous write command data in the master station's remote register (RWw).
- ② Turn on the GOT request flag, and store the command data in the GOT remote register (RWw). Store the data in GD100, 101, and 102.

(Command execution)

The GOT complete flag turns on when the command processing is complete.

4 Sequence program example



### 4.5.5 Random write command

#### 1 Random write command


This is a command to write remote register data to several different GOT internal devices.

#### 2 Command format

Communication direction	Address	Contents
Master station ↓ A852GOT	RWwm (H)	5: Random write setting
	RWwm (L)	When the occupied points are 2 stations 1 to 3 : Points to be written to the GOT internal device When the occupied points are 4 stations 1 to 7 : Points to be written to the GOT internal device
	RWwm + 1	0 to 1023 : GOT internal device numbers to be written
	RWwm + 2	Stores the data to be written to the GOT internal device described above
	RWwm + 3 to RWwm + E	Stores the data to be written and GOT internal device numbers for the setting points like mentioned above.
	RWwm + F	_____
A852GOT ↓ Master station	RWrn to RWrn + F	_____

#### 3 Communication overview

When writing remote register data to the GOT internal device GD100, 200, and 300 (3 points)




- ① Store the random write command data in the master station's remote register (RWw).
- ② Turn on the GOT request flag, and store the command data in the GOT remote register (RWw). Store the write data in GD100, 200, and 300.

(Command execution)

The GOT complete flag turns on when the command processing is complete.

**4** Sequence program example



**4.5.6 Monitor register command**

**1 Monitor register command**

This is a command to always register the device number of the GOT internal device which reads the remote register.

After executing the monitor register command, always execute the monitor request command.

**2 Command format**

Communication direction	Address	Contents
Master station ↓ A852GOT	RWwm (H)	6: Monitor register setting
	RWwm (L)	When the occupied points are 2 stations 1 to 6 : GOT internal device points to be registered for monitoring When the occupied points are 4 stations 1 to 14 : GOT internal device points to be registered for monitoring
	RWwm + 1 to RWwm + E	0 to 1023 : GOT internal device numbers to be registered (Storage for the setting mentioned above)
	RWwm + F	_____
A852GOT ↓ Master station	RWrn to RWrn + F	_____

**3 Communication overview**

Refer to Section 4.5.7.

**4.5.7 Monitor request command**

**1 Monitor request command**

This is a command to always read the data in the GOT internal device registered by the monitor register command execution to the remote register.


Execute the monitor request command after the monitor register command is executed.

**2 Command format**

Communication direction	Address	Contents
Master station ↓ A852GOT	RWwm to RWwm + F	_____
A852GOT ↓ Master station	RWrn to RWrn + E	Store the data in the GOT internal device for the number of points registered with the monitor register command
	RWrn + F	_____

### 3 Communication overview

When always reading the data in the GOT internal device GD100, 200, and 300 to the remote register




- ① Store the monitor register command data in the master station's remote register (RWw).
- ② Turn on the GOT request flag, and store the command data in the GOT remote register (RWw).

(Command execution)

The GOT complete flag turns on when the command processing is complete.

- ③ By turning on the GOT monitor request flag, always read the data in the GD100, 200, and 300 to the remote register (RWr).
- ④ By link scan, the read data is stored in the master station's remote register (RWr).
- ⑤ Read the data to the PC CPU using the FROM instruction, etc.

4 Sequence program example



**4.5.8 Always write register command**

**1 Always write register command**

This is a command to always register the device number of the GOT internal device that performs the remote register data write.

After executing the always write register command, always execute the always write request command.

**2 Command format**

Communication direction	Address	Contents
Master station ↓ A852GOT	RWwm (H)	8: Always write register setting
	RWwm (L)	When the occupied points are 2 stations 1 to 6 : GOT internal device points to be registered for monitoring When the occupied points are 4 stations 1 to 14 : GOT internal device points to be registered for monitoring
	RWwm + 1 to RWwm + E	0 to 1023 : GOT internal device numbers to be registered (Storage for the settings mentioned above)
	RWwm + F	_____
A852GOT ↓ Master station	RWrn to RWrn + F	_____

**3 Communication overview**

Refer to Section 3.5.9.

**4.5.9 Always write request command**

**1 Always write request command**

This is a command to always write data in the remote register to the GOT internal device registered by executing the always write register command.


Execute the always write request command after executing the always write register command.

**2 Command format**

Communication direction	Address	Contents
Master station ↓ A852GOT	RWwm to RWwm + D	Store write data for the number of points registered with the always write register command
	RWwm + E, RWwm + F	_____
A852GOT ↓ Master station	RWrn to RWrn + F	_____

**3** Communication overview

When always writing data in the remote register to the GOT internal device GD100, 110, and 120




- ① Store the always write register command data in the master station's remote register (RWw).
- ② Turn on the GOT request flag, and store the command data in the GOT remote register (RWw).


(Command execution)

The GOT complete flag turns on when the command processing is complete.

- ③ Store the always write data in the master station's remote register (RWw).
- ④ Always write the write data to the GOT internal device GD100, 200, and 300 by turning on the GOT always write request flag.

**4** Sequence program example





## 4.6 List of Accessible Range and Devices for Monitoring

### 1 Monitor accessible range

The monitor accessible range is the remote input/output for the A852GOT allocated to the master station, remote device (write area and read area), and the GOT internal device. Remote devices allocated to device other than the A852GOT cannot be monitored.

### 2 Devices that can be monitored

The "n" and "m" in the table indicates the address allocated to the master station by the station number setting.

Accessible devices for monitoring		Device range	
		Number of stations occupied: 2 stations	Number of stations occupied: 4 stations
Bit device	Remote input (RX)	RXn0 to RX (n + 3) F	RXn0 to RX (n + 7) F
	Remote output (RY)	RYn0 to RY (n + 3) F	RYn0 to RY (n + 7) F
	Bit specification in the remote register (write area) (RWw)	RWwm to RWwm + 7	RWwm to RWwm + F
	Bit specification in the remote register (read area) (RWr)	RWrn to RWrn + 7	RWrn to RWrn + F
	GOT internal bit device (GB)	GB0 to GB1023	
	Bit specification in the GOT internal word device (GD)	GD0 to GD1023	
Word device	Remote register (write area) (RWw)	RWwm to RWwm + 7	RWwm to RWwm + F
	Remote register (read area) (RWr)	RWrn to RWrn + 7	RWrn to RWrn + F
	GOT internal word device (GD)	GD0 to GD1023	

#### Point

When creating the monitor screen, set the following device names:

Refer to Section 1.4 for details; Remote input: X; Remote output: Y; Remote register (write/read area): Ww/Wr.

## 4.7 Data Link Processing Time

Refer to the CC-Link Master Module User's Manual for link scan time of the entire system and transmission delay time.


GOT is treated as a remote device station, so read the descriptions for remote device stations.

# 5. SEQUENCE PROGRAM EXAMPLE


## 5.1 Sequence Program Example When Monitoring Using the Normal Monitor Method

The following system example is used to describe the sequence program in this section. Refer to the CC-Link Master Module User's Manual regarding the sequence program for the entire CC-Link system.

### 1 System configuration of the program example




### 2 Relationship among the PC CPU, master station buffer memory, and remote device stations



**3** Monitor screen data creation example

Common setting: Base screen switch device: Ww0


Base screen No.1



**Contents of sprite setting**

- ① Touch switch function  
Bit SET: X1 (RX1) → M1  
Bit RST: X0 (RX0) → M0  
Bit RST: X2 (RX2) → M2
- ② Touch switch function  
Bit SET: X2 (RX2) → M2  
Bit RST: X0 (RX0) → M0  
Bit RST: X1 (RX1) → M1

Base screen No.2




**Contents of sprite setting**

- ① Numeric value input function  
Write device: Wr0 → D200
- ② Numeric value input function  
Write device: Wr1 → D201
- ③ Numeric value input function  
Write device: Wr2 → D202
- ④ Touch switch function  
Bit alternate: X3 (RX3) → M3
- ⑤ Touch switch function  
Bit alternate: X4 (RX4) → M4
- ⑥ Touch switch function  
Bit alternate: X5 (RX5) → M5

- ⑦ Touch switch function  
Bit SET: X2 (RX2) → M2  
Bit RST: X0 (RX0) → M0  
Bit RST: X1 (RX1) → M1
- ⑧ Touch switch function  
Bit SET: X0 (RX0) → M0  
Bit RST: X1 (RX1) → M1  
Bit RST: X2 (RX2) → M2

Base screen No.3




**Contents of sprite setting**

- ① Numeric value display function  
Monitor device: Ww1 (RWw1) ← D101
- ② Numeric value display function  
Monitor device: Ww2 (RWw2) ← D102
- ③ Numeric value display function  
Monitor device: Ww3 (RWw3) ← D103
- ④ Numeric value display function  
Monitor device: Ww4 (RWw4) ← D104
- ⑤ Numeric value display function  
Monitor device: Ww5 (RWw5) ← D105
- ⑥ Numeric value display function  
Monitor device: Ww6 (RWw6) ← D106

- ⑦ Lamp display function  
Monitor device: Y0 (RY0) ← M100
- ⑧ Lamp display function  
Monitor device: Y1 (RY1) ← M101
- ⑨ Lamp display function  
Monitor device: Y2 (RY2) ← M102
- ⑩ Touch switch function  
Bit SET: X1 (RX0) → M1  
Bit RST: X0 (RX0) → M0  
Bit RST: X2 (RX2) → M2
- ⑪ Touch switch function  
Bit SET: X0 (RX0) → M0  
Bit RST: X1 (RX1) → M1  
Bit RST: X2 (RX2) → M2

**4** Sequence program example

Refer to the Master Module User's Manual about the program for setting CC-Link parameter.




## 5.2 Sequence Program Example When Monitoring Using Dedicated Command Monitor Method


The following system example is used to describe the sequence program in this section.

Refer to the CC-Link Master Module User's Manual regarding the sequence program for the entire CC-Link system.

### 1 System configuration of the program example




### 2 Relationship among the PC CPU, master station buffer memory, and remote device stations



**3** Monitor screen data creation example

Common setting: Base screen switch device: GD100


Base screen No.1



**Contents of sprite setting**

- ① Touch switch function  
Base screen switch fixed value: 2
- ② Touch switch function  
Base screen switch fixed value: 3


Base screen No.2



**Contents of sprite setting**

- ① Numeric value input function  
Monitor device: GD200
- ② Numeric value input function  
Monitor device: GD201
- ③ Numeric value input function  
Monitor device: GD202
- ④ Numeric value input function  
Monitor device: GD203
- ⑤ Numeric value input function  
Monitor device: GD204
- ⑥ Numeric value input function  
Monitor device: GD205
- ⑦ The monitor devices for the touch switch function of switches 1 to 8 are as follows:  
Switch 1: GD250 b0  
Switch 2: GD250 b1  
Switch 3: GD250 b2  
Switch 4: GD250 b3  
Switch 5: GD250 b4  
Switch 6: GD250 b5  
Switch 7: GD250 b6  
Switch 8: GD250 b7
- ⑧ Touch switch function  
Bit alternate: GD255 b0
- ⑨ Touch switch function  
Bit alternate: GD255 b1
- ⑩ Touch switch function  
Bit alternate: GD255 b2
- ⑪ Touch switch function  
Base screen switch fixed value: 3
- ⑫ Touch switch function  
Base screen switch fixed value: 1


Base screen No.3


**Contents of sprite setting**


- ① Numeric value display function  
Monitor device: GD101
- ② Numeric value display function  
Monitor device: GD102
- ③ Numeric value display function  
Monitor device: GD103
- ④ Numeric value display function  
Monitor device: GD104
- ⑤ Numeric value display function  
Monitor device: GD105
- ⑥ Numeric value display function  
Monitor device: GD106
- ⑦ Touch switch function  
Base screen switch fixed  
value: 2
- ⑧ Touch switch function  
Base screen switch fixed  
value: 1

**4** Sequence program example

Refer to the Master Module User's Manual about the program for setting CC-Link parameter.








# 6. NAMES OF PARTS AND HANDLING SYSTEM EQUIPMENTS

## 6.1 Names of Parts and Their Settings



No.	Name	Contents
①	Display module	Displays monitor screens
②	Power supply LED	Lights when power supply is on
③	Reset switch	Resets the GOT hardware
④	RS-232C interface	RS-232C interface for connecting a personal computer
⑤	Power supply terminal block	For input of 24 VDC power supply (M3 × 3 screws) <div style="text-align: center;">                     INPUT                      24V <math>\equiv</math>                      +                       -                       (FG)  </div>
⑥	Communications module installation screw hole	Hole for screw used to attach a communications module to the GOT
⑦	Installation hook installation section	installation hook is installed here
⑧	Ratings plate	
⑨	Optional module interface	For connecting printer interface module/ memory card interface module
⑩	Operation display LED L. RUN	ON : Normal communication OFF: Discommunication (Refer to Section 11.3)
⑪	Operation display LED L. ERR	ON : Communication data error (Refer to Section 11.3) OFF: Normal communication
⑫	Number of stations occupied setting switch	Set number of stations occupied (2/4 stations) (Factory-set: 4 stations)
⑬ ⑭	Station number setting switch	Set the station No. of A852GOT within the range of 1 to 64. (Factory-set: 0 station)
⑮	Terminal block	For connecting cable (8 points terminal block M3 × 8 screws)

## 6.2 Protective Sheets

The A8GT-50PSC and A8GT-50PSN are protective sheets for the display area of the GOT.

Protective sheets are used for the following purposes:


- ① To protect the touch keys from scratches and dirt when using the touch key panel on the display area
- ② To prevent reflection from external disturbance light on the display area

The protective sheet used should be selected in accordance with the purpose for which it is used, from among those listed here.

Purpose	Model	Contents
Protection of display area	A8GT-50PSC	Transparent protective sheet
Display area protection + anti-reflection	A8GT-50PSN	Anti-reflection protective sheet


### • Installation method

- ① Peel off the old protective sheet from the GOT display area.



- ② Peel off the protective backing from the adhesive tape on the new protective sheet, and affix it to the display area of the GOT.

**(Note)** When affixing the protective sheet to the display area, make sure it is flat and tight, with no looseness or gaps at the adhesive sections.



### 6.3 Printer Interface Module Connection Method

The connection method for the printer interface module to be installed to the GOT is described.


Refer to the A8GT-50PRF User's Manual for the details of installation method and specification of the printer interface module.

Refer to the A8GT-50STE User's Manual when using the installation metal clamps to install the printer interface module to the GOT main module.



#### **DANGER**


- Make sure to switch all phases of the external GOT's and PC's power supply off before loading or removing the printer interface to/from the GOT.



- ① Make screw holes on the control panel, etc. for the A8GT-50PRF installation. (2  $\phi$  3.5 installation holes)

The A8GT-50PRF GOT connection cable is 50cm; set in the position where the GOT side connector can securely be installed to the GOT connector. When installing it behind the lid of the A8GT-50PRF control panel, make sure that the screw holes do not protrude the surface of the control panel.

- ② Tighten the installations screws within the range of specified torque 39 to 59 N·cm(4 to 6kg·cm).



- ③ Install the GOT side connector to the GOT lower connector.
- ④ Connect the A8GT-50PRF and printer with the connection cable.


## 6.4 Memory Card Interface Module Connection Method

The connection method for the memory card interface module to be installed to GOT is described.

Refer to the A1SD59J-MIF User's Manual (Hardware Manual) for details of installation and specification of the memory card interface module.

**DANGER**

⊗ Make sure to switch all phases of the external GOT's and PC's power supply off before loading or removing the memory card interface module to/from the GOT.



- ① Install the A1SD59J-MIF to the control panel, etc.  
(Refer to the A1SD59J-MIF User's Manual.)
- ② Install the GOT side connector to the GOT lower connector.
- ③ Install the A1SD59J-MIF side connector to the A1SD59J-MIF connector.

# 7. OPERATING UTILITY FUNCTIONS

## 7.1 List of Utility Functions


Item	Contents	Remarks	Ref. Page
Brightness adjustment Message display selection	Adjusts the backlight brightness Selects the screen message display (Japanese/English)		Section 7.3
System monitor	Unusable		Section 7.4
Screen copy	Transfers data between internal memory of screen data and memory card (Only when using A1SD59-MIF)	Only screen data created by the user	Section 7.5
Setup	Sets the following items: <ul style="list-style-type: none"> <li>• Message display selection (Japanese/English)</li> <li>• Buzzer sound adjustment</li> <li>• Screen saver time setting</li> <li>• Backlight automatic off function</li> <li>• Select the display mode (for either the A852GOT-LWD (-M3) and A852GOT-LBD (-M3), normal/reversed display can be selected).</li> <li>• Transmission speed setting</li> </ul>		Section 7.6
Self-test	Tests the following hardware of the GOT main module: <ul style="list-style-type: none"> <li>• Drawing check</li> <li>• Font check</li> <li>• Memory card check</li> <li>• Internal memory user area check</li> <li>• Internal memory OS area check</li> <li>• CPU communications check (CC-Link communication check)</li> <li>• Touch switches check</li> </ul>		Section 7.7
Memory information	Displays the following information: <ul style="list-style-type: none"> <li>• OS version</li> <li>• Format of communications with PC CPU</li> <li>• Available capacity in internal memory</li> <li>• Whether or not memory card is inserted, and available capacity</li> <li>• Whether or not optional module exists</li> </ul>		Section 7.8
Clock function	Unusable		Section 7.9
Screen cleaning	Displays screen in order to clean display area		Section 7.10
File function	The following information of the data stored by the alarm history function is display, data deletion: <ul style="list-style-type: none"> <li>• Data capacity, and storage date and time</li> <li>• Memory card format</li> </ul> (Only when using A1SD59-MIF)		Section 7.11

## 7.2 Procedures to Prepare for Running the Various Functions

This section outlines the various procedures used to prepare for running the utility functions. All of the utility functions can be operated using the touch keys on the monitor screen.


There are two ways to start up the utility functions, as described below.

- (1) Touch the top right and top left corners of the monitor screen at the same time.



- (2) On the monitor screen, specify the touch key (extension) function, and input the settings using the touch keys. (For information on entering settings using touch keys, please refer to the A8GOTP Operating Manual (Monitor Screen Creation Manual).)

The following shows an outline of the utility function procedures.




## 7.3 Selecting Functions on the Utility Menu Screen

(Adjusting the Screen Brightness — Brightness Adjustment)

(Selecting the Screen Message Display — Message Display Selection)



### 1 Display screen



### 2 Functions

- This is the menu screen where the various utility functions are selected.
- The brightness of the screen can be adjusted on this screen.
- The screen message display (Japanese/English) can be selected on this screen.

### 3 Operations

- Basic operation
  - Directly touch the section where the function to be selected is displayed.
- Return to the monitor screen
  - Touching the  returns to the monitor screen.
- Brightness adjustment
  - Touch  .
  - The brightness can be adjusted in 50 steps.
- Message display selection
  - Touch  or . ( : English,  : Japanese)

#### POINT

- If the OS has not been installed in the GOT, the items for system monitoring are displayed, but cannot be selected.
- If the PC CPU connected to the GOT does not have a clock function, the clock setting is displayed, but cannot be selected.

### 4 Error messages displayed in response to operations

Message	Cause	Corrective Action
Can't be selected (When system monitor or clock setting is selected)	<ul style="list-style-type: none"> <li>• System monitoring function OS has not been installed in GOT</li> <li>• PC CPU connected to GOT has no clock function</li> </ul>	<ul style="list-style-type: none"> <li>• Install the OS.</li> <li>• Replace the PC CPU with one that has a clock function, or do not use the clock function.</li> </ul>

## 7.4 Monitoring PC CPU Device Data on the Dedicated Screen (System Monitor)


The system monitor function cannot be used.

## 7.5 Copying Monitor Data Between the Internal Memory and Memory Card (Screen Copy)

When the alarm history function data is stored in the memory card that uses this function the screen data copied using the screen copy function is deleted. Use separate memory cards of the memory cards for the screen copy function and the alarm history function.

### 1 Display screen

Example of screen



### 2 Functions

- Project data can be backed up from the internal memory to a memory card.
- Project data backed up from the memory card to the internal memory can be copied.

### 3 Operations

#### (a) Basic operations

- Items are selected by touching the and keys.
- Touching the key displays the message "OK to execute?".
- To execute the function, touch the key once again. To select an item, use the and keys. To interrupt a function, touch the key. However, please be aware that this returns to the utility menu screen.

#### (b) Returning to the utility menu screen

- Touching the returns to the utility menu screen.


4	<b>Error messages displayed in response to operations</b>
---	---

Message	Cause	Corrective action
Cancel write protect function	The write protect function has been specified on the memory card.	Cancel the write protect function on the memory card.
Install memory card	No memory card has been installed in the GOT.	Install a memory card in the GOT.
Format memory card	The memory card installed in the GOT has not been formatted.	Format the memory card. (Refer to Section 8.4.)
Insufficient memory on card	The amount of available capacity on the memory card which has been installed is less than the contents of the internal memory.	Replace the memory card with one which has sufficient available capacity.
Memory card error	There is a hardware problem with the memory card which has been installed.	Replace the memory card.

## 7.6 Entering GOT Usage Environment Settings (Setup)

### 1 Display screen

Example of screen



### 2 Functions

- The length of the buzzer can be selected. (When shipped from the factory, this is set to "Short".)
- The timing of the screen saver function can be set.
  - Screen saver function
    - ① In order to keep the display module from burning out, this function turns off the display if it is not touched within a specified period of time.
    - ② If the display has been turned off, it can be turned on again simply by touching it.
    - ③ If this timing is set to "0", the screen is always displayed.
- The back light can be automatically turned off along with the screen saver. (When shipped from the factory: ON)
- The display mode (normal display (No)/inverted display (Yes)) can be selected. (When shipped from the factory: No)  
A852GOT-LWD, A852GOT-LBD, A852GOT-LWD, or A852GOT-LBD can be selected.
- The language for displaying messages can be selected.
- The transmission speed can be set. (When shipped from the factory: 0: 156K)


### 3 Operations

#### (a) Basic operations

- Items are selected by touching the and keys.
- Settings are changed by pressing the and keys.
- The setting for the screen saver time can be changed by touching the and keys to highlight the digits, and then the and keys to set the numeric value. (If another item is selected right after this setting is entered, touching the key returns the highlighted display to the "Screen Saver Time" parameter, where the and keys can be used for selection.)
- After entering a setting, touch the key.  
When the key is pressed, the GOT is reset automatically, and the monitor screen is displayed.

## 7.7 Self-Test of the GOT Main Module Hardware (Self-Test)

### 1 Display screen



### 2 Functions

This tests the hardware modules of the GOT listed below.

- Drawing check ..... Checks visually for sections of the display module where colors or display elements are missing.
- Font check ..... Checks visually for distortion in the character font.
- Memory card check ..... Checks the memory card hardware.
- Internal memory user area check ... Checks the user area of the internal memory.
- Internal memory OS area check..... Checks the OS area of the internal memory.
- CPU communications check ..... Checks the status of communications between the CC-Link.  
(CC-Link communication check)
- Touch switches check ..... Checks the touch switches.

} These are checked by the GOT.

### 3 Operations


#### (a) Basic operations

- Touch the display area of the item to be run.
- To operate the various items, follow the messages displayed on the screen.
- When an item has been completed without errors, a message is displayed, indicating that no problems occurred.
- If a problem is detected, an error message is displayed, stating the content of the error.
- The following three types of screens are drawn during the drawing check:
  - ① The entire screen is displayed in one color. The colors used for display change in the order of: blue → red → purple → green → blue/green → yellow → white.
  - ② Basic graphics such as circles and squares are displayed.
  - ③ Ovals and checked patterns are displayed either alternately, or in a superimposed display.
- Perform the CC-Link communication check (communication status). If an error is displayed, the case of error need to be corrected by referring to Section 11.3.

## 7.8 Displaying Various Types of GOT Memory Information (System Information)

### 1 Display screen

Example of screen



### 2 Functions

This displays the various types of memory information for the GOT shown below.

- OS version
- Format for communications with the PC CPU
- Available capacity in internal memory
- Whether or not memory card is installed, and available capacity
- Whether or not optional module exists

### 3 Operations

#### (a) Basic operations

The screen can be scrolled by touching the  and  keys.

#### (b) Returning to the utility menu screen

- Touching the  returns to the utility menu screen.


## 7.9 Specifying the PC CPU Clock Data (Clock Setting)

The clock setting function cannot be used.

## 7.10 Displaying the Display Area Cleaning Screen (Screen Cleaning)

### 1 Display screen

Example of screen




### 2 Functions

- When cleaning the display area, displaying a completely black screen makes the surface easier to see.

### 3 Operations

#### (a) Basic operations

- Touching the upper right and left corners of the screen simultaneously returns to the utility menu.




## 7.11 Checking Data Information Stored by the Alarm History Function

The same memory card cannot be used for the alarm history function and the screen copy function. If the alarm history function data is stored in the memory card in which the screen copy function screen data is stored the data stored by the screen copy will be deleted, so take due precautions.

Use separate memory cards for the memory cards for the screen copy function and the alarm history function.

If a different memory card (several memory cards for alarm history can be used) is switched in while this screen is displayed, the data information of this switched in memory card cannot be displayed. Redisplay this screen from the utility screen.

### 1 Display screen



### 2 Functions

- The file name, capacity, date, and time of the data stored by the alarm history function can be checked. (The file name of the data stored by the alarm history function is set to the above ALARMHST.DAT. fixed)
- The memory card can be formatted.
- The data stored by the alarm history function can be deleted.

### 3 Operations

- Operation for deleting the data stored by the alarm history function  
Touch the to select the data to be deleted.  
After making the selection touch the **DELETE**.
- Operation for formatting the memory card  
Touch **FORMAT**.
- To return to the utility menu  
Touch **END** to return to the utility menu.

## 8. OFF-LINE FUNCTIONS

All off-line functions are processed from the graphics software in relation to the GOT.

### Point

There are no operations on the GOT side.

For detailed information on operation with the graphics software, please refer to the A8GOTP Operating Manual (Data Transfer/Debugging/Document Creation Manual) Section "Communication menu".

### 8.1 Table of Off-line Functions

Item	Contents	Remarks
Install	Installs the OS from the computer to the internal memory of the GOT.	
Download	Downloads project data and special module monitor data from the computer to the internal memory of the GOT.	
Upload	Uploads project data from the internal memory of the GOT to the computer.	
Memory card format	Formats the memory card installed in the GOT.	
Memory information	Transfers the following information to the computer: the version of the OS currently installed in the GOT, the space available in the internal memory, and the available capacity on the memory card.	This can also be checked using "Memory Information" under the GOT utility functions (Refer to Section 7.8).

## 9. INSTALLATION AND WIRING

### 9.1 Precautions Regarding Handling

This section explains precautions which should be observed when handling the GOT.



#### DANGER

- Make sure to switch all phases of the external GOT's power supply off before beginning installing and wiring work. If you do switch off the external power supply, it will cause electric shock, malfunction, or damage to the module.




#### CAUTION

- When wiring the GOT, be careful that foreign objects, such as chips from the braided shield and wiring scraps, don't get caught in the GOT main module and the optional module.  
These can cause fire, failure or malfunctions.
- Do not bunch the communication cables with the main circuit or power wires, or install them close to each other.
- The FG and LG terminals should always be grounded using the class-3 or higher grounding designed specially for the GOT. Failure to ground these terminals may cause electric shock or malfunctions.
- When wiring the GOT, check the rated voltage and terminal layout of the wiring, and make sure the wiring is done correctly. Connecting a power supply that differs from the rated voltage or wiring it incorrectly may cause fire or failure.
- Tighten the GOT's terminal screws within the range of specified torque. If the terminal screws are loose, it may result in fallout, short circuits, or malfunctions. Tightening the terminal screws too far may cause damages to the screws and/or the module, resulting in fallout, short circuits, or malfunctions.
- Never disassemble or modify the each module.  
This may cause failure, malfunctions, injury, and/or fire.
- Don't touch the conductive parts and electronic parts of the GOT main module and optional module. This may cause the module to malfunction or failure.
- When disposing of this product, treat it as industrial waste.
- Because they are made of resin, don't drop or give a strong shock to the GOT main module and optional module.  
This may cause failure.

**1** When installing the main module to the control panel, position the display module as shown below.

- If the temperature inside the panel is 55°C, the display module should be installed at an angle within the range of 60 to 105°.



- Using the display module at an angle outside the range noted above may cause the GOT to wear out faster than it would otherwise. Make sure the temperature inside the panel does not exceed 40°C.

**2** Refer to Section 2.5 about usable model name of cable, specification and manufacture.

## 9.2 Installation Environment

### CAUTION

When installing the equipment, make sure the location satisfies the general specifications, and avoid locations like those listed below. Using the equipment in an environment outside the range of the general specifications could result in electrical shock, fire, malfunctioning, and damage to or deterioration of the product.


- ⊗ Locations where the temperature changes drastically and condensation occurs
- ⊗ Locations where the equipment is exposed to direct sunlight
- ⊗ Locations where strong electrical or magnetic fields are generated
- ⊗ Locations where the main module is exposed to direct vibration or impact

## 9.3 Installation and Wiring Method

Use the fittings that installation come with the main module to assemble it.


### 1 Installation panel and processing

If modules such as the control panel door and an installation base made by the user are to be installed, the door and installation base need to be processed as shown in the illustration below.




### 2 Installation position

When installing the GOT, it should be separated from other equipment by the clearances indicated below.




**3 Installation method**

- (a) Insert the front of the main module first.
- (b) The module is installed at four places on the top and bottom of the GOT, as shown below.




- (c) Install the installation hooks as shown below. The specified torque should be 62 to 83.5 N-cm (6 to 8 kg-cm).



- ① Fit the installation hook onto the GOT main module.
- ② Slide the installation hook in the direction indicated by ②.
- ③ Slide the installation hook in the direction of the notch provided for the hook.
- ④ Secure the installation hook to the panel with the screw.

**4 Wiring method**


- (a) Wire the twisted pair cables between A852GOT and the master module, etc. in the following manner:



- (b) About the FG terminal grounding method for the power supply terminal block and cable connection terminal block  
 The FG terminals of the power-supply terminal block and cable connection terminal block are not internally connected.  
 Be sure to ground the FG terminal of the power supply terminal block and that of cable connection terminal block separately.

**5 When the A852GOT is the final station**

When the A852GOT is the final station, be sure to connect a terminal resistor at the following position:



- 6 Tighten the connection terminal screws and power supply terminal screws in the following range:

Connected terminal block terminal screw	39 to 59 N·cm (4 to 6 kg·cm)
Connected terminal block installation screw	59 to 88 N·cm (6 to 9 kg·cm)
Terminal block screw for power supply	39 to 59 N·cm (4 to 6 kg·cm)

# 10. MAINTENANCE AND INSPECTION

In order to make sure your PC is kept operating in optimum condition, certain items should be inspected daily, and others on a regular basis. These items are described below.

## 10.1 Daily Inspection

The items noted in Table 10.1 should be inspected daily.

Table 10.1 Daily inspection

Item	Item to inspect	Inspection method	Judgment criteria	Corrective action
1	Module installation conditions	Check for loose installation screws and covers that are not tightly attached.	Make sure they are firmly attached.	Tighten screws securely.
2	Connections	Loose terminal screws	There should be no loose screws.	Tighten terminal screws securely.
		Proximity to crimping terminals	There should be appropriate spacing.	Space appropriately.
		Connector area of cables	There should be no loose connectors.	Tighten connector fixed screws securely.

## 10.2 Periodic Inspection

The items noted below should be inspected once or twice every six months. If the equipment is moved or renovated, or if wiring is changed, these items should be inspected at that time.

Table 10.2 Periodic Inspection

Item	Item to inspect	Item method	Judgment criteria	Corrective action	
1	Ambient environment	Ambient temperature	Measure with thermometer/barometer.	Display area 0 to 40°C	If used inside the panel, inpanel temperature should be same as ambient temperature
		Ambient humidity	Measure corrosive gases.	Other parts 0 to 55°C	
		Atmosphere		10 to 90% RH No corrosive gases	
2	Power supply voltage check	Measure voltage between 24 VAC terminals.	15.6 to 31.2 VDC	Change power supply	
3	Installation conditions	Looseness, rattling	Try moving the module.	Should be installed firmly and securely	Tighten screws
		Dirt or foreign matter	Check visually.	Should not be any adhering to equipment	Remove/clean
4	Connections	Loose terminal screws	Tighten with a screwdriver.	No loose screws	Tighten
		Proximity to crimping terminals	Check visually.	Appropriate spacing	Correct spacing
		Loose connectors	Check visually.	No loose connectors	Tighten connector screws

### 10.3 Precautions During Maintenance and Inspection

This section explains precautions which should be observed when carrying out maintenance and inspections.

**DANGER**

- ⦿ Do not touch the terminals while the power is on. Doing so may cause electric shock or malfunction.
- ⦿ Make sure to switch all phases of the external GOT's power supply off before cleaning or retightening terminal screws. If you do not switch off the external power supply, it will cause electric shock.

**CAUTION**

- ⦿ Never disassemble or modify the module. This may cause failure, malfunctions, injury, and/or fire.
- ⦿ Make sure to switch all phases of the external GOT's power supply off before mounting or removing the system equipment.  
If you do not switch off the external power supply, it will cause failure or malfunction of the module.
- ⦿ When disposing of this product, treat it as industrial waste.

## 10.4 Replacing the LCD Backlight

The GOT has a backlight built into the LCD of the display area. As time goes by, this backlight gradually becomes dimmer. When the display area screen becomes hard to see, the backlight should be replaced.



### DANGER

- Make sure to switch all phases of the external GOT's power supply off before replacing the backlight, and first remove the GOT main module from the panel. If you do not switch off the external power supply, it will cause electric shock. If left in the panel, the GOT could fall and cause an injury.




### CAUTION

- Perform replacement of the backlight at a place where no other machines exist in order to prevent troubles in case a fixed screw of the backlight or GOT drops. If such screw is dropped, it may cause damage to the machine or an accident.
- Do not touch the GOT's circuit board or electronic parts when replacing the backlight. Doing so could cause failure or malfunction.
- Tighten the backlight fixed screws within the range of specified torque. If the fixed screws are loose, it may result in fallout, short circuits, or malfunctions. Tightening the fixed screws too far may result in damages, short circuits, or malfunctions of the screw and/or module.
- Do not pull the cable connector of backlight when replacing the backlight. Doing so could cause damage or failure of the backlight.


1

### Removing the backlight


- ① Loosen the GOT installation hooks, and remove the GOT from the base.
- ② Using a screwdriver, remove the four fixed screws from the back corners of the GOT, and the one fixed screw in the center. If a communications module has been installed, remove it before taking out the fixed screws.




- ③ Remove the case from the back of the GOT.




- ④ Disconnect the backlight cable connector from the display area connectors.



- ⑤ Using a screwdriver, remove the fixed screws of the backlight.




- ⑥ Remove the backlight from the display area.




## 2 Installing the backlight

- ① Fit the backlight cable connector into the display area connector.



- ② Align the left side of the backlight with the backlight holder on the display area, and fit the backlight in position.



- ③ Tighten the backlight fixed screw to secure the backlight.
- ④ Install the case from the back of the GOT to the display area, and tighten the fixed screws. Make sure the fixed screws are tightened within the range of the specified torque (39 to 59 N·cm(4 to 6 kg·cm)).

# 11. LIST OF ERROR CODES AND ERROR MESSAGES


This section explains the error codes and error messages displayed in the alarm list display of the monitor function.

## 11.1 Interpreting the Display Contents

This section explains how to look at the error codes and error messages displayed on the monitor screen, and to decipher the correct response and the reference page.

First, let's look at error codes for the system which are displayed on the monitor screen from the alarm list display of the monitor function.

- 1 Display format on monitor screen ..... Displayed at position specified by user



- 2 Error codes and reference manuals

Location where error occurred	Error code	Reference
GOT	300 to 499	Section 11.2
QnACPU	1000 to 9999 (SDO value)	User's manual for the QnACPU of the master/local station

## 11.2 List of Error Codes and Error Messages

### 1 Error messages displayed before monitoring

Error message	Error contents	Corrective action
Check communication circuit. (cable, driver, module)	Cable, installed communications driver, or communications module is faulty	Check for loose cables and mounting status of communications module. Also check the installed communications driver.
Check memory information.	Arrangement of each installed OS program version is improper.	Check each installed OS program version.

### 2 Error code and error message during monitoring

Error codes and error messages detected by GOT are shown below.

The error code can be checked with the system information function of the error code storage area and with the alarm list (system alarm) function.

For information on the system information function and the alarm list function, refer to the SW2NIW-A8GOTP Operating Manual (Monitor Screen Creation Manual).

Error code	Error message	Error contents	Corrective action
303	Number of specified monitoring points is excessive.	System work area cannot be secured because sprite settings of the screen to be shown are excessive.	Reduce the number of sprite setting points.
304	Number of specified trigger points is excessive.		
305	Number of specified printout points is excessive.		
306	No monitor data	Screen data is not downloaded to internal memory.	Download screen data to internal memory.
310	Specified monitor data does not exist or is outside range.	(1) Specified base screen/window screen does not exist in project data. (2) Specified base screen/window screen is outside permissible range (1 to 1024)	(1) Specify base screen/window screen that exists. (2) Specify base screen/window screen of 1 to 1024 that exists.
320	Specified parts do not exist or are outside range.	Parts number set in parts display does not exist.	Check specified parts numbers of screen data parts display.
321	Specified station number of monitor device is incorrect.	Specified station number of applicable monitor does not exist or is not an applicable monitor station.	Check station number of target monitor in screen data.
322	Specified device is outside range.	The number of the device to be monitored is outside the permissible range of the applicable PC CPU.	Set device in the permissible monitoring range by setting parameter and PC CPU to be monitored.
323	Specified file register is outside range.		
330	Memory card capacity is insufficient.	Memory card capacity is insufficient.	Check capacity.
331	Memory card is not mounted or M-CARD switch is OFF.	Memory card is not mounted or the memory card access switch has turned OFF.	Mount memory card and/or turn access switch to ON.
332	Format error	Memory card is not formatted.	Format memory card.

Error code	Error message	Error contents	Corrective action
333	Write not possible because memory card is write protected.	Memory card is write protected.	Cancel write protection of memory card.
334	Memory card is faulty.	Memory card is defective.	Replace memory card.
335	Memory card battery voltage is low.	Memory card battery voltage has dropped.	Replace memory card battery.
340	Error generated by printer or power is disconnected.	Printer is faulty, or printer power supply is not engaged.	Check printer and/or engage printer power supply.
341	Printer is faulty.		
350	RS-232C communication error	Cable connecting GOT to personal computer is faulty.	Check for loose connectors of communications cable and check cable in use.

### 11.3 Error Cause Confirmation Method from the L.RUN and L.ERR LEDs on GOT


The LED displays of GOT that indicate cause of error are described.

Refer to the PC CPU User's Manual and Master Module User's Manual regarding errors for the PC CPU and the master module.

L. RUN	L. ERR	Cause of error
On ●	Off ○	Data link is normal
Off ○	Off ○	Possible causes are as follows: Refer to the Master Module User's Manual for details. <ul style="list-style-type: none"> <li>· The cable is disconnected. (The L.RUN LEDs are turned off at all modules beyond the disconnected cable.)</li> <li>· The cable shorted-circuited. (The L.RUN LEDs are turned off at all station modules.)</li> <li>· The master station has stopped the link. (The L.RUN LEDs are turned off at all station modules except for the master station.)</li> <li>· The power supply to the GOT is off. (The ERR LEDs on the master station and local stations are turned off.)</li> <li>· The station number settings overlap between the GOT station and another station. (The L.RUN LED on the overlapping station is turned off.)</li> <li>· The transmission speed setting is incorrect.</li> <li>· The GOT station is not set in the parameter.</li> </ul>
Off ○	On ●	The GOT was started up with the station number setting switch set to out of range.
Off ○	On ★	The station number setting switch or transmission speed setting was changed during data link.

# APPENDIX

## Appendix 1 External Dimensions Diagram



Dimensions

(Unit: mm (inch))

A	B	C	D	E	F	G	H	I	J
192	135	132	183	123	62	6	46	18	7
(7.6)	(5.3)	(5.2)	(7.2)	(4.8)	(2.4)	(0.2)	(1.8)	(0.7)	(0.3)

# A852GOT Graphic Operation Terminal

---

## User's Manual

MODEL	A852GOT-U-E
MODEL CODE	13JL15



**mitsubishi** MITSUBISHI ELECTRIC AUTOMATION, INC.

500 CORPORATE WOODS PARKWAY • VERNON HILLS, ILLINOIS 60061

When exported from Japan, this manual does not require application to the Ministry of International Trade and Industry for service transaction permission.