Changes for the Better

GT10 Protective Cover for Oil

User's Manual



Manual Number	JY997D39601
Revision	В
Date	Apr. 2011

his manual describes the part names installation, and specifications of the product. Before use, read this manual and manuals of relevant products fully to acquire proficiency in handling and operating the product. Make sure to learn all the product information, safety information, and precautions.

And, store this manual in a safe place so that you can take it out and read it whenever necessary. Always forward it to the end user. Registration

The company name and the product name to be described in this manual are the registered trademarks or trademarks of each company.

Specifications are subject to change without notice.

Safety Precaution (Read these precautions before using.)

Before using this product, please read this manual and the relevant manuals introduced in this manual carefully and pay full attention to safety to handle the product correctly

The precautions given in this manual are concerned with this product.

In this manual, the safety precautions are ranked as ODANGER and ACAUTION



Indicates that incorrect handling may cause hazardou conditions, resulting in death or severe injury.

Indicates that incorrect handling may cause hazardous conditions, resulting in medium or slight personal injury or physical damage.

Depending on circumstances, procedures indicated by ACAUTION may also be linked to serious results.

In any case, it is important to follow the directions for usage.

MOUNTING PRECAUTIONS

DANGER

Be sure to shut off all phases of the external power supply used by the system before mounting or removing the GOT to/from the panel Not doing so can cause the unit to fail or malfunction

MOUNTING PRECAUTIONS

!CAUTION

When mounting the GOT to the control panel, tighten the mounting screws in the specified torque range.

Undertightening can cause the GOT to drop, short circuit or malfunction, and deteriorate the waterproof effect and oilproof effect.

Overtightening can cause a drop, short circuit or malfunction due to the damage of the screws or the GOT, and deteriorate the waterproof effect and oilproof effect due to distortion of the protective cover for oil, GOT or panel.

DISPOSAL PRECAUTIONS ! CAUTION

When disposing of the product, handle it as industrial waste.

Related Manuals

The following manuals are relevant to this product. When these loose manuals are required please consult with our local distributor.

Manual name	Manual Number (Model Code)	Contents
GT10 User's Manual	JY997D24701 (09R819)	Describes the GT10 hardware-relevant content such as part names, external dimensions, mounting, wiring, specifications, and introduction to option devices. (sold separately)

Bundled Items

Bundled item	Quantity
GT10 protective cover for oil	1
GT10 Protective Cover for Oil User's Manual (This manual)	1

1. Overview


User of the GT10 protective cover for oil (hereinafter referred to as "protective cover for oil") improves oil performance, and chemical performance of the GOT.*1

*1 It is not the one to guarantee all customer's environments. Moreover, it is not likely to be able to use it in the environment to which oil or the medicine splashes for a long time and the environment with which Oilmist is

The following GOT models support the protective cover for oil.

Model	GOT
GT10-20PCO	GT1020-L□D(W), GT1020-L□D(W)2, GT1020-L□L(W)
GT10-30PCO	GT1030-L□D(W), GT1030-L□D(W)2, GT1030-L□L(W), GT1030-H□D(W), GT1030-H□D(W)2, GT1030-H□L(W)
GT10-40PCO	GT1045-QSBD, GT1040-QBBD

2. Part Names and External Dimensions



Model	Α	В	С
GT10-20PCO	85(3.35")	124(4.89")	10(0.4")
GT10-30PCO	87(3.43")	156(6.15")	10(0.4")
GT10-40PCO	123(4.85")	150(5.91")	11(0.44")

3. Specifications

3.1 Performance Specifications

The performance specifications of the protective cover for oil are indicated below. The general specifications of the protective cover for oil are the same as those of the

*1 It is not the one to guarantee all customer's environments Moreover, it is not likely to be able to use it in the environment to which oil splashes for a long time and the environment with which Oilmist is filled.

For the general specifications of the GOT, refer to GT10 User's Manual.

Item	GT10-20PCO	GT10-30PCO	GT10-40PCO
Level of protection	IP67 Caution: Oil or the medicine might not be able to splash for a long time, and to use it in the environment with which Oilmist is filled.		
Material	Cover: Nitrile rubber, Display: PET sheet		
Weight	0.030kg	0.040kg	0.050kg

CAUTION: For installing the GOT with the protective cover for oil, the control panel thickness must be 1 to 3mm because of the cover thickness. (Control panel thickness without the cover: 1 to 4mm

3.2 Oil resistance, chemical resistance

The protective cover for oil is made of materials with high oil and chemical resistance so that the cover can be used in various oil and chemical atmospheres. Because oils, including cutting oils, contain a small amount of additives depending on oil products, oil resistance of the cover cannot be stated.

Prior to use the cover, test the cover in operating environments, and then check the oil and chemical resistance of the cover

. Test contents and oil resistance of cover

The protective cover for oil is soaked in the following oils for 2000 hours, and then oil resistance of the cover is checked

Oil type	Product	Change in appearance and dimension	Adhesion between cover and sheet	Oil resistance
Water-insoluble cutting oil	Grinding oil (Yushiron oil CL35)	No change	No change	0
Water-soluble cutting oil	Grinding oil (Noritake cool CG-50P)	No change	No change	0


4. Installation

4.1 Before attaching protective cover for oil

A protective film is attached on the display area when the GOT is shipped. Make sure to remove the protective film before attaching the protective cover for oil. For attaching the protective cover for oil to the GOT already mounted on the control nanel follow the procedures as below

- Remove the GOT from the control panel. Make sure to externally shut off all phases of the power supply and remove all cables from the GOT in advance.
- . Clean dirt off surfaces of the GOT and control panel.
- 1) Prepare the GOT and protective cover for oil, and check the direction of the protective cover for oil. In the case of GT10-30PCO, let the wider side of the under side be located upward.





2) One corner of the cover is pulled outside, and it hangs it on the corner of the front panel of GOT. Please do not pull the oil cover more than the necessity, and do not bend it extremely The seat part and the rubber part in the display part might flake off.




3) The oil cover was hung and the edge of the oil cover is sequentially obtained and obtain the oil cover to cover rubber packing parts in the back of GOT of the front

. (It is the order of the arrow from A side to D side.)



The corner is hung. Protective Cover For oil

The corner on the left is hung and the oil cover is hung from A side to D side on the starting point sequentially.




Please confirm all surroundings. Check whether the rubber packing is fitted correctly into the groove on the under side of the GOT front panel, and then whether the protective cover for oil securely covers the rubber packing part to prevent invasion of liquids into the board



Make sure that corners of protective cover for oil match those of GOT front 4) Mount the GOT onto the control panel.

When the control panel is dirty, clean the control panel.

The panel cutting dimensions and mounting screw tightening torque with the protective cover for oil are the same as those without the cover Mount the GOT onto the control panel by referring to GT10 User's . Manual



Cautions on installation

Tighten the mounting screw with the specified torque.

GOT	GT1020, GT1030, GT104□
Tightening torque	0.20 to 0.25 N·m

Undertightening of mounting screws can cause a drop, and deteriorate the

waterproof effect and oilproof effect. Overtightening of mounting screws can cause a drop due to damage of the GOT or mounting fixtures, and deteriorate the waterproof effect and oilproof effect.

5. Precautions for protective cover for oil

- 1) The protective cover for oil is consumable product
- Check the cover for scratch, damage or dirt at regular intervals, and replace with new one if necessary
- 2) Do not push the protective cover for oil with pointed tools, including mechanical nencils and screwdrivers
- Doing so causes scraches and damages of the cover
- 3) Do not clean the protective cover for oil with bleaches, thinners, organic solvents, corrosive chemicals, and others,
- Doing so causes changes in shape and color of the cover. 4) When the protective cover for oil is attached to the GOT, do not stretch and
- bend the cover too much. Doing so may cause a separation between the sheet and rubber.
- 5) Do not place or use the protective cover for oil in direct sunshine.
- 6) When the protective cover for oil gets dusts, wine the dusts off with a damp
- 7) Do not do a frequent detaching the protective cover for oil. It causes deterioration in the oil performance, and the medicine performance
- 8) It is not the one to guarantee all customer's environments. Moreover, it is not likely to be able to use it in the environment to which oil splashes for a long time and the environment with which Oilmist is filled.

This manual confers no industrial property rights or any rights of any other kind, nor does it confer any patent licenses. Mitsubishi Electric Corporation cannot be held responsible for any problems involving industrial property rights which may occur as a result of using the contents noted in this manual.

Mitsubishi will not be held liable for damage caused by factors found not to be the cause of Mitsubishi; opportunity loss or lost profits caused by faults in the Mitsubishi products; damage, secondary damage, accident compensation caused by special factors unpredictable by Mitsubishi; damages to products other than Mitsubishi products; and to other duties.

✓ For safe use

- This product has been manufactured as a general-purpose part for general industries, and has not been designed or manufactured to be incorporated in a device or system used in purposes related to human life.
- Before using the product for special purposes such as nuclear power, electric power, aerospace, medicine or passenger movement vehicles, consult with Mitsuhishi Flectric
- This product has been manufactured under strict quality control. However when installing the product where major accidents or losses could occur if the product fails, install appropriate backup or failsafe functions in the system

A MITSUBISHI ELECTRIC CORPORATION

HEAD OFFICE: TOKYO BUILDING, 2-7-3 MARUNOUCHI, CHIYODA-KU, TOKYO 100-8310, ΙΔΡΔΝ

HIMEJI WORKS: 840, CHIYODA CHO, HIMEJI, JAPAN